

# TeSys T LTMR

## Motor Management Controller

### Ethernet Communication Guide

07/2017



---

The information provided in this documentation contains general descriptions and/or technical characteristics of the performance of the products contained herein. This documentation is not intended as a substitute for and is not to be used for determining suitability or reliability of these products for specific user applications. It is the duty of any such user or integrator to perform the appropriate and complete risk analysis, evaluation and testing of the products with respect to the relevant specific application or use thereof. Neither Schneider Electric nor any of its affiliates or subsidiaries shall be responsible or liable for misuse of the information contained herein. If you have any suggestions for improvements or amendments or have found errors in this publication, please notify us.

You agree not to reproduce, other than for your own personal, noncommercial use, all or part of this document on any medium whatsoever without permission of Schneider Electric, given in writing. You also agree not to establish any hypertext links to this document or its content. Schneider Electric does not grant any right or license for the personal and noncommercial use of the document or its content, except for a non-exclusive license to consult it on an "as is" basis, at your own risk. All other rights are reserved.

All pertinent state, regional, and local safety regulations must be observed when installing and using this product. For reasons of safety and to help ensure compliance with documented system data, only the manufacturer should perform repairs to components.

When devices are used for applications with technical safety requirements, the relevant instructions must be followed.

Failure to use Schneider Electric software or approved software with our hardware products may result in injury, harm, or improper operating results.

Failure to observe this information can result in injury or equipment damage.

© 2017 Schneider Electric. All Rights Reserved.

# Table of Contents



<b>Safety Information.</b> . . . . .	5
<b>About the Book</b> . . . . .	7
<b>Chapter 1 Introducing the TeSys T Motor Management System</b> . . . . .	9
Presentation of the TeSys T Motor Management System	9
<b>Chapter 2 Wiring of the Ethernet Network</b> . . . . .	11
Ethernet Network Characteristics	12
Ethernet Network Port Wiring Terminal Characteristics	13
Ethernet Architecture Selection	15
Wiring of the Ethernet Network	22
<b>Chapter 3 Using the Ethernet Communication Network</b> . . . . .	25
3.1 Using Ethernet Services	26
Configuration of the LTMR Ethernet Network Port	27
Ethernet Link Management	30
Master IP	31
IP Addressing	32
Faulty Device Replacement	36
Discovery Procedure	42
Ethernet Diagnostics	43
Simple Network Management Protocol	48
3.2 Using the Modbus/TCP Communication Protocol	50
Modbus/TCP Protocol Principle	51
Modbus/TCP Requests	53
Modbus Exception Management	54
I/O Scanning Configuration	55
3.3 Using the EtherNet/IP Communication Protocol	57
EtherNet/IP Protocol Principles	59
Connections and Data Exchange	60
Device Profiles and EDS Files	61
Object Dictionary	62
Identity Object	63
Message Router Object	65
Assembly Object	67
Connection Manager Object	72
TCP/IP Object	74
Ethernet Link Object	76
Control Supervisor Object	78
Overload Object	81
Periodically Kept Acyclic Words (PKW) Objects	83
TeSys T Monitoring Control Object	86
EtherNet/IP Interface Diagnostic Object	87
I/O Connection Diagnostic Object	90
Explicit Connection Diagnostic Object	92
Explicit Connection Diagnostic List Object	93
3.4 Communication Variables	95
Communication Parameter Clear Commands	96
Simplified Control and Monitoring	98
Organization of Communication Variables	100
Data Formats	101
Data Types	102
Identification Variables	108
Statistics Variables	109

---

Monitoring Variables .....	116
Configuration Variables .....	125
Command Variables .....	134
User Map Variables .....	135
Custom Logic Variables .....	137
Mirroring Variables .....	138
<b>Chapter 4 Using the Standard Web Server User Interface .....</b>	<b>141</b>
Description of the Standard Web Server User Interface .....	142
Home Page .....	146
Login Page .....	148
Documentation Page .....	149
Monitoring Page .....	150
Product Status Page .....	151
Metering Page .....	153
Diagnostics Page .....	154
Ethernet Basic Page .....	155
Ethernet Extended Diagnostics Page .....	156
RSTP Bridge Statistics Page .....	157
RSTP Port Statistics Page .....	158
Faults & Warnings Page .....	159
Fault History Page .....	160
Maintenance Page .....	162
Counters Page .....	163
Setup Page .....	164
Product Thermal Settings Page .....	165
Product Current Settings Page .....	166
Product Voltage Settings Page .....	167
Product Power Settings Page .....	168
RSTP Configuration Page .....	169
Communication Page .....	170
Password Page .....	171
<b>Glossary .....</b>	<b>173</b>
<b>Index .....</b>	<b>177</b>

# Safety Information



## Important Information

### NOTICE

Read these instructions carefully, and look at the equipment to become familiar with the device before trying to install, operate, service, or maintain it. The following special messages may appear throughout this documentation or on the equipment to warn of potential hazards or to call attention to information that clarifies or simplifies a procedure.



The addition of this symbol to a “Danger” or “Warning” safety label indicates that an electrical hazard exists which will result in personal injury if the instructions are not followed.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

### ⚠ DANGER

**DANGER** indicates a hazardous situation which, if not avoided, **will result in** death or serious injury.

### ⚠ WARNING

**WARNING** indicates a hazardous situation which, if not avoided, **could result in** death or serious injury.

### ⚠ CAUTION

**CAUTION** indicates a hazardous situation which, if not avoided, **could result in** minor or moderate injury.

### NOTICE

**NOTICE** is used to address practices not related to physical injury.

## PLEASE NOTE

Electrical equipment should be installed, operated, serviced, and maintained only by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this material.

A qualified person is one who has skills and knowledge related to the construction and operation of electrical equipment and its installation, and has received safety training to recognize and avoid the hazards involved.



# About the Book



## At a Glance

### Document Scope

This guide describes the Ethernet TCP/IP network protocol version of the TeSys™ T LTMR motor management controller and LTME expansion module.

The purpose of this guide is to:

- describe and explain the monitoring, protection, and control functions of the LTMR controller and LTME expansion module
- provide all the information necessary to implement and support a solution that best meets your application requirements

The guide describes the four key parts of a successful system implementation:

- installing the LTMR controller and LTME expansion module
- commissioning the LTMR controller by setting essential parameter values
- using the LTMR controller and LTME expansion module, both with and without additional human-machine interface devices
- maintaining the LTMR controller and LTME expansion module

This guide is intended for:

- design engineers
- system integrators
- system operators
- maintenance engineers

### Validity Note

This guide is valid for LTMR Ethernet controllers. Some functions are available depending on the software version of the controller.

### Related Documents

Title of Documentation	Description	Reference Number
TeSys T LTMR Motor Management Controller - User Guide	This is the main user guide that introduces the complete TeSys T range and describes the main functions of the TeSys T LTMR motor management controller and LTME expansion module.	<a href="#">DOCA0127EN</a>
TeSys T LTMR Motor Management Controller - Installation Guide	This guide describes the installation, commissioning, and maintenance of the TeSys T LTMR motor management controller.	<a href="#">DOCA0128EN</a>
TeSys T LTMR Modbus Communication Guide	This guide describes the Modbus network protocol version of the TeSys T LTMR motor management controller.	<a href="#">DOCA0130EN</a>
TeSys T LTMR PROFIBUS-DP Communication Guide	This guide describes the PROFIBUS-DP network protocol version of the TeSys T LTMR motor management controller.	<a href="#">DOCA0131EN</a>
TeSys T LTMR CANopen Communication Guide	This guide describes the CANopen network protocol version of the TeSys T LTMR motor management controller.	<a href="#">DOCA0132EN</a>
TeSys T LTMR DeviceNet Communication Guide	This guide describes the DeviceNet network protocol version of the TeSys T LTMR motor management controller.	<a href="#">DOCA0133EN</a>
TeSys T LTMCU Control Operator Unit - User Manual	This manual describes how to install, configure, and use the TeSys T LTMCU Control Operator Unit.	<a href="#">1639581EN</a>
Magelis XBT-N User Manual	This manual describes the characteristics and presentation of the XBT N/XBT R display units.	<a href="#">1681029</a>
TeSys T LTMR Ethernet/IP - Quick Start Guide	This guide provides a single reference for configuring and connecting the TeSys T and the Allen-Bradley programmable logic controller (PLC).	<a href="#">DOCA0119EN</a>
TeSys T LTMR Modbus - Quick Start Guide	This guide uses an application example to describe the different steps to quickly install, configure, and use TeSys T for Modbus network.	<a href="#">1639572EN</a>
TeSys T LTMR PROFIBUS-DP - Quick Start Guide	This guide uses an application example to describe the different steps to quickly install, configure, and use TeSys T for PROFIBUS-DP network.	<a href="#">1639573EN</a>

<b>Title of Documentation</b>	<b>Description</b>	<b>Reference Number</b>
TeSys T LTMR CANopen - Quick Start Guide	This guide uses an application example to describe the different steps to quickly install, configure, and use TeSys T for CANopen network.	<a href="#"><u>1639574EN</u></a>
TeSys T LTMR DeviceNet - Quick Start Guide	This guide uses an application example to describe the different steps to quickly install, configure, and use TeSys T for DeviceNet network.	<a href="#"><u>1639575EN</u></a>
Elecromagnetic Compatibility Practical Installation Guidelines	This guide provides an insight to the electromagnetic compatibility.	<a href="#"><u>deg999en</u></a>
TeSys T LTMR... Instruction Sheet	This document describes the mounting and connection of the TeSys T LTMR motor management controller.	<a href="#"><u>AAV7709901</u></a>
TeSys T LTME... Instruction Sheet	This document describes the mounting and connection of the TeSys T LTME expansion module.	<a href="#"><u>AAV7950501</u></a>
XBT-N Instruction Sheet	This document describes the mounting and connection of the Magelis XBT-N display units.	<a href="#"><u>1681014</u></a>
TeSys T LTMCU Instruction Sheet	This document describes the mounting and connection of the TeSys T LTMCU control unit	<a href="#"><u>AAV6665701</u></a>
TeSys T DTM Online Help	This online help describes the TeSys T DTM and the custom logic editor embedded in the for TeSys T DTM which allows customization of the control functions of the TeSys T motor management system.	<a href="#"><u>1672614EN</u></a>
BMXNOC0401 Ethernet Communication Module User Manual	This manual describes the use of the Modicon M340 BMX NOC 0401 Ethernet communication module and describes the creation of a complete configuration.	<a href="#"><u>S1A34009</u></a>
TCSMCNAM3M002P USB to RS485 Converter Quick Reference Guide	This instruction guide describes the configuration cable between computer and TeSys T: USB to RS485	<a href="#"><u>BBV28000</u></a>
Electrical Installation Guide (Wiki version)	The aim of the Electrical Installation Guide (and now Wiki) is to help electrical designers and contractors to design electrical installations according to standards such as the IEC60364 or other relevant standards.	<a href="#"><u>www.electrical-installation.org</u></a>
Modbus Official Site	This site describes about Modbus and its various products.	<a href="#"><u>www.modbus.org</u></a>

You can download these technical publications and other technical information from our website at [www.schneider-electric.com](http://www.schneider-electric.com).

#### Trademark Notice

All trademarks are owned by Schneider Electric Industries SAS or its affiliated companies.

---

# Chapter 1

## Introducing the TeSys T Motor Management System

---

### Presentation of the TeSys T Motor Management System

#### Aim of the Product

The TeSys T motor management system offers protection, control, and monitoring capabilities for single-phase and three-phase AC induction motors.

The system is flexible, modular, and can be configured to meet the requirements of applications in industry. The system is designed to meet the needs for integrated protection systems with open communications and a global architecture.

Highly accurate sensors and solid-state full motor protection provide better utilization of the motor. Complete monitoring functions enable analysis of motor operating conditions and faster responses to prevent system downtime.

The system offers diagnostic and statistics functions and configurable warnings and faults, allowing better prediction of component maintenance, and provides data to continuously improve the entire system.

For more details on the product, refer to the [TeSys T LTMR Motor Management Controller User Guide](#).



---

## Chapter 2

### Wiring of the Ethernet Network

---

#### Overview

This chapter describes how to connect an LTMR controller to an Ethernet network using an RJ45 connector.

#### **WARNING**

##### **LOSS OF CONTROL**

- The designer of any control scheme must consider the potential failure modes of control paths and, for certain critical functions, provide a means to achieve a safe state during and after a path failure. Examples of critical control functions are emergency stop and overtravel stop.
- Separate or redundant control paths must be provided for critical control functions.
- System control paths may include communication links. Consideration must be given to the implications of anticipated transmission delays or failures of the link.<sup>(1)</sup>
- Each implementation of an LTMR controller must be individually and thoroughly tested for proper operation before being placed into service.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

(1) For additional information, refer to NEMA ICS 1.1 (latest edition), *Safety Guidelines for the Application, Installation, and Maintenance of Solid State Control*.

#### What Is in This Chapter?

This chapter contains the following topics:

Topic	Page
Ethernet Network Characteristics	12
Ethernet Network Port Wiring Terminal Characteristics	13
Ethernet Architecture Selection	15
Wiring of the Ethernet Network	22

## Ethernet Network Characteristics

### Overview

The LTMR Ethernet TCP/IP controller complies with the specifications of the EtherNet/IP and the Modbus/TCP protocols.

### Characteristics for Connection to the Ethernet Network

Characteristics	Value
Maximum number of LTMR controllers per subnet	A network with a DHCP server is limited to 160 LTMR controllers.
Maximum number of LTMR controllers per segment	Install a maximum of 16 LTMR controllers on a daisy chain network to avoid material damage and a decrease in performance.
Type of cable	Straight or crossed category 5 shielded twisted pair
Maximum cable length (daisy chain)	100 m (328 ft)
Transmission speed	10 MB/100 MB

## Ethernet Network Port Wiring Terminal Characteristics


### General

The main physical characteristics of Ethernet ports are:

Physical interface	Ethernet 10/100BASE-T
Connector	RJ45

### Physical Interface and Connectors


The LTMR controller is equipped with three female shielded RJ45 connectors on its front face. Two of these connectors (circled below) provide access to the controller's Ethernet network port:



- 1 Ethernet port number 1
- 2 Ethernet port number 2

### RJ45 Ethernet Network Connector Pinout

The LTMR controller is connected to the Ethernet network using either or both of its RJ45 Ethernet network port connectors in compliance with the following wiring:



The RJ45 wiring layout is:

Pin No.	Signal	Pair	Description
1	TD+	A	Transmit +
2	TD-	A	Transmit -
3	RD+	B	Receive +
4	Do not connect	-	-
5	Do not connect	-	-
6	RD-	B	Receive -
7	Do not connect	-	-
8	Do not connect	-	-

### Auto-MDIX

Each RJ45 connector on the LTMR controller Ethernet network port is an MDIX (media-dependent interface crossover) interface. Each connector automatically senses the:

- Cable type-straight or crossed-plugged into the connector, and
- Pin requirements of the device to which the controller is connected

Using this information, each connector assigns transmit and receive functions to pin combinations 1 & 2 and 3 & 6 as necessary to communicate with the device on the other end of the cable.

**NOTE:** Auto-MDIX allows using either straight or crossed category 5 twisted-pair Ethernet cable to connect an LTMR controller to another device.

## Ethernet Architecture Selection

### Overview

This section is meant to help determine which architecture to choose according to the needs of your installation.

A global view of the advantages of each architecture is provided and each of the following architectures is described:

- Star ([see page 16](#))
- Daisy Chain ([see page 17](#))
- Daisy Chain With one By- Pass Switch Per Node ([see page 18](#))
- Daisy Chain Loop With one Ring Switch ([see page 19](#))
- Daisy Chain Loop With two Ring Switches ([see page 20](#))
- Daisy Chain Loop With two Ring Switches and one By- Pass Switch Per Node ([see page 21](#))

### Dependability Comparison Rating

Dependability evaluates how the system reacts with an unexpected situation (for example: a device failure).

Network Architecture	Tolerant to First Switch Failure	Tolerant to First Node Failure	Tolerant to Second Node Failure	Tolerant to Several Nodes Failures	One or More Common Modes	Additional Failure Modes	Score
Star	:)	:)	:)	:)	:)	:)	:)
Daisy Chain	:)	:)	:)	:)	:)	:)	:)
Daisy Chain With one By-Pass Switch Per node	:)	:)	:)	:)	:)	:)	:)
Daisy Chain Loop With one Ring Switch	:)	:)	:)	:)	:)	:)	:)
Daisy Chain Loop With two Ring Switches	:)	:)	:)	:)	:)	:)	:)
Daisy chain Loop With two Ring Switches and one By-Pass Switch Per node	:)	:)	:)	:)	:)	:)	:)


### Operability Comparison Rating

Operability evaluates how the system reacts with normal operation and functions (for example: withdraw a drawer in operation).

Network Architecture	Withdrawability One Functional Unit (FU)	Withdrawability Two FUs	Withdrawability Several FUs	Score
Star	:)	:)	:)	:)
Daisy Chain	:)	:)	:)	:)
Daisy Chain With one By-Pass Switch Per node	:)	:)	:)	:)
Daisy Chain Loop With one Ring Switch	:)	:)	:)	:)
Daisy Chain Loop With two Ring Switches	:)	:)	:)	:)
Daisy Chain Loop With two Ring Switches and one By-Pass Switch Per node	:)	:)	:)	:)

**Star**

Removal of any number of nodes does not affect the other nodes.



Dependability rating


Tolerant to First Switch Failure	Tolerant to First Node Failure	Tolerant to Second Node Failure	Tolerant to Several Nodes Failures	One or More Common Modes	Additional Failure Nodes	Score
:(	:)	:)	:)	:(	:)	:(

Operability rating

Withdrawability One Functional Unit (FU)	Withdrawability Two FUs	Withdrawability Several FUs	Score
:)	:)	:)	:)

## Daisy Chain

Removal of one node breaks the communication with all the nodes following the removed node.



Dependability rating


Tolerant to First Switch Failure	Tolerant to First Node Failure	Tolerant to Second Node Failure	Tolerant to Several Nodes Failures	One or More Common Modes	Additional Failure Modes	Score
:(	:(	:(	:(	:)	:)	:(

Operability rating

Withdrawability One Functional Unit (FU)	Withdrawability Two FUs	Withdrawability Several FUs	Score
:(	:(	:(	:(

**Daisy Chain with One By-Pass Switch Per Node**

Removal of any nodes does not affect the remaining nodes since the LTM9BPS by-pass switch re-establishes the ring automatically.



Dependability rating


Tolerant to First Switch Failure	Tolerant to First Node Failure	Tolerant to Second Node Failure	Tolerant to Several Nodes Failures	One or More Common Modes	Additional Failure Modes	Score
:(	:)	:(	:(	:)	:(	:(

Operability rating

Withdrawability One Functional Unit (FU)	Withdrawability Two FUs	Withdrawability Several FUs	Score
:)	:)	:)	:)

### Daisy Chain Loop with One Ring Switch

Removal of one node does not break the communication with all the nodes following the removed node. If the switch fails, it breaks the communication.



Dependability rating


Tolerant to First Switch Failure	Tolerant to First Node Failure	Tolerant to Second Node Failure	Tolerant to Several Nodes Failures	One or More Common Modes	Additional Failure Modes	Score
:(	:)	:(	:(	:(	:)	:(

Operability rating

Withdrawability One Functional Unit (FU)	Withdrawability Two FUs	Withdrawability Several FUs	Score
:)	:(	:(	:(

### Daisy Chain Loop with Two Ring Switches

Removal of one node does not break the communication with all the nodes following the removed node. If one switch fails, it does not break the communication.



Dependability rating


Tolerant to First Switch Failure	Tolerant to First Node Failure	Tolerant to Second Node Failure	Tolerant to Several Nodes Failures	One or More Common Modes	Additional Failure Modes	Score
😊	😊	😐	😐	😊	😊	😐

Operability rating

Withdrawability One Functional Unit (FU)	Withdrawability Two FUs	Withdrawability Several FUs	Score
😊	😐	😐	😐

### Daisy Chain Loop with Two Ring Switches and One By-Pass Switch Per Node

Removal of any nodes does not affect the remaining nodes since the LTM9BPS by-pass switch repairs the ring automatically.



Dependability rating

Tolerant to First Switch Failure	Tolerant to First Node Failure	Tolerant to Second Node Failure	Tolerant to Several Nodes Failures	One or More Common Modes	Additional Failure Modes	Score
😊	😊	😊	😊	😊	🙁	🙁

Operability rating

Withdrawability One Functional Unit (FU)	Withdrawability Two FUs	Withdrawability Several FUs	Score
😊	😊	😊	😊

## Wiring of the Ethernet Network

### Overview

This section describes how to connect an LTMR controller to an Ethernet network via the female shielded RJ45 connector.

### Ethernet Wiring Rules

The following wiring rules must be respected in order to reduce disturbance due to EMC on the behavior of the LTMR controller:

- Keep a distance as large as possible between the communication cable and the power or control cables (minimum 30 cm or 11.8 in.).
- Cross over the Ethernet cable and the power cables at right angles, if necessary.
- Install the communication cables as close as possible to the grounded plate.
- Do not bend or damage the cables. The minimum bending radius is 10 times the cable diameter.
- Avoid sharp angles of paths or passage of the cable.
- Use the recommended cables only.
- All RJ45 connectors must be metallic.
- An Ethernet cable must be shielded:
  - The cable shield must be connected to a protective ground.
  - The connection of the cable shield to the protective ground must be as short as possible.
  - Connect together the shields, if necessary.
  - Perform the grounding of the shield with a collar.
- When the LTMR controller is installed in a withdrawable drawer:
  - Connect together all the shield contacts of the withdrawable drawer part of the auxiliary connector to the ground of the withdrawable drawer to create an electromagnetic barrier. Refer to the *Okken Communications Cabling & Wiring Guide* (available on request).
  - Do not connect the cable shield at the fixed part of the auxiliary connector.
- Wire the bus between each connector directly, without intermediate terminal blocks.
- The common polarity (0 V) must be connected directly to protective ground, preferably at one point only for the entire bus. In general, this point is chosen either on the master device or on the polarization device.

For more information, refer to the *Electrical Installation Guide* (available in English only), chapter *ElectroMagnetic Compatibility (EMC)*.

### **NOTICE**

#### COMMUNICATION MALFUNCTION

Respect all the wiring and grounding rules in order to avoid communication malfunctions due to EMC disturbance.

**Failure to follow these instructions can result in equipment damage.**

### Connection to the Network

Every LTMR controller includes an embedded two-port Ethernet switch, with two ports and one IP address.

**NOTE:** The two Ethernet ports have the same IP address.

The IEEE 802.3 standard defines Ethernet as implemented in the LTMR controller.


### LTMR Controllers Installed in a Blokset or Okken Motor Control Switchboard

The installation of LTMR controllers in withdrawable drawers of a switchboard presents constraints specific to the type of switchboard:

- For installation of LTMR controllers in an Okken switchboard, refer to the *Okken Communications Cabling & Wiring Guide* (available on request).
- For installation of LTMR controllers in a Blokset switchboard, refer to the *Blokset Communications Cabling & Wiring Guide* (available on request).
- For installation of LTMR controllers in other types of switchboard, follow the specific EMC instructions described in this guide and refer to the relative instructions specific to your type of switchboard.

### Wiring Diagram Example

The wiring diagram below indicates how to connect LTMR controllers installed in withdrawable drawers to the Ethernet network via the RJ45 connector and hardwired cables.



- 1 Master (PLC, PC, or communication module) with line terminator
- 2 By-pass switch LTM9BPS
- 3 Ethernet shielded cable 590 NTW 000
- 4 Grounding of the Ethernet cable shield
- 5 Withdrawable drawer
- 6 Withdrawable drawer part of the auxiliary connector
- 7 Fixed part of the auxiliary connector



---

# Chapter 3

## Using the Ethernet Communication Network

---

### Overview

This chapter describes the user interface devices and the hardware configurations you can use to operate the LTMR controller.

### What Is in This Chapter?

This chapter contains the following sections:

Section	Topic	Page
3.1	Using Ethernet Services	26
3.2	Using the Modbus/TCP Communication Protocol	50
3.3	Using the EtherNet/IP Communication Protocol	57
3.4	Communication Variables	95

## Section 3.1

### Using Ethernet Services

#### Overview

This section describes the Ethernet services, and the related Ethernet configuration parameters, supported by EtherNet/IP and Modbus/TCP.

**NOTE:** Changes in parameter settings for any Ethernet service take effect only after a power cycle of the LTMR controller.

#### WARNING

##### LOSS OF CONTROL

- The designer of any control scheme must consider the potential failure modes of control paths and, for certain critical functions, provide a means to achieve a safe state during and after a path failure. Examples of critical control functions are emergency stop and overtravel stop.
- Separate or redundant control paths must be provided for critical control functions.
- System control paths may include communication links. Consideration must be given to the implications of anticipated transmission delays or failures of the link.<sup>(1)</sup>
- Each implementation of an LTMR controller must be individually and thoroughly tested for proper operation before being placed into service.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

(1) For additional information, refer to NEMA ICS 1.1 (latest edition), "Safety Guidelines for the Application, Installation, and Maintenance of Solid State Control".

#### WARNING

##### UNEXPECTED RESTART OF THE MOTOR

Check that the PLC application software

- Considers the change from local to remote control,
- Manages appropriately the motor control commands during those changes.
- Manages appropriately the motor control to avoid contradictory commands from all possible Ethernet connections

When switching to the Network control channels, depending on the communication protocol configuration, the LTMR controller can take into account the latest known state of the motor control commands issued from the PLC and restart automatically the motor.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

#### What Is in This Section?

This section contains the following topics:

Topic	Page
Configuration of the LTMR Ethernet Network Port	27
Ethernet Link Management	30
Master IP	31
IP Addressing	32
Faulty Device Replacement	36
Discovery Procedure	42
Ethernet Diagnostics	43
Simple Network Management Protocol	48

## Configuration of the LTMR Ethernet Network Port

### Communication Parameters

Before network port communication can begin, configure the following Ethernet communication services and settings:

- Master IP address setting
- Frame type setting
- Stored IP addressing settings
- Network port endian setting
- Faulty device replacement (FDR) service
- Network Protocol selection
- Rapid Spanning Tree Protocol (RSTP)
- SNMP service
- Communication loss settings
- Configuration control

**NOTE:** Only the TeSys T DTM software can configure all of these services and settings. Other HMI devices can configure all settings and all services except SNMP.

### Master IP Address Setting

Configure the Ethernet Master IP Address Setting parameter to add the IP address of the client device ([see page 31](#)) dedicated to remotely control the motor. This parameter consists of four integer values, from 0-255, separated by dots (xxx.xxx.xxx.xxx).

### Frame Type Setting

Configure the Network Port Frame Type Setting parameter by selecting an Ethernet frame type:

- Ethernet II (Factory setting)
- 802.3 (recommended)

### IP Addressing Settings

Unique IP address settings must be assigned to the LTMR controller (including an IP address, a subnet mask, and a gateway address) to be able to communicate over an Ethernet network. The positions of the controller's two rotary switches determine the source of the controller's IP address settings ([see page 32](#)), which can be:

- A DHCP server
- A BootP server
- Stored IP address settings

If the controller's *Ones* rotary switch is set to **Stored IP**, the controller will apply its stored IP address settings ([see page 33](#)).

To input the LTMR controller's stored IP address settings, configure the following parameters:

- Ethernet IP Address Setting
- Ethernet Subnet Mask Setting
- Ethernet Gateway Address Setting

Each of these parameters consists of four integer values, from 0-255, separated by dots (xxx.xxx.xxx.xxx).

### Network Port Endian Setting

The Network port endian setting allows to swap the two words in a double word.

- 0 = least significant word first (little endian)
- 1 = most significant word first (big endian, factory setting)

## Faulty Device Replacement Service

The Faulty Device Replacement (*see page 36*) (FDR) service stores the LTMR controller's operating parameters on a remote server and, if the controller fails and is replaced, sends the replacement controller a copy of the original device's operating parameters.

To insure the server always contains an accurate, updated copy of the controller's operating parameters, the FDR service can be configured to automatically backup these parameter settings to the FDR server.

To enable the automatic backup of the controller's operating parameters to the FDR server, configure the following parameters:

- Network Port FDR Auto Backup Enable parameter. It can be set to:
  - No auto backup
  - Automatic backup (copies the parameters from the controller to the FDR server)
- Network Port FDR Controller Interval parameter: the time (in seconds) between automatic backup transmissions.
  - Range = 1...65535 s
  - Factory setting = 120 s

## Network Protocol Setting

Select with this parameter the network protocol you want to use:

- Modbus/TCP
- EtherNet/IP

## Rapid Spanning Tree Protocol

The Rapid Spanning Tree Protocol (RSTP) service manages the state on every port of each device in the local area network (LAN) loop. The RSTP is configured to respond, and resolve a communication loss of a device on the network from 50...150 ms for 16-32 devices. Reconnection performances vary depending on PLC, services used, and IP address mode.

To enable the Rapid Spanning Tree Protocol (RSTP) service, set the parameter RSTP Disable to No.

On every network topology change, RSTP recalculates the optimum network path. It is important that network configuration does not change during RSTP operation. Following actions should be avoided on an operating network or network configuration that can be temporarily impacted:

- A network cable plug-in/plug-out or device power ON/OFF in less than 2 s
- A daisy chain loop, remove/add two nodes in less than 30 s

## SNMP Service

The LTMR controller supports the simple network management protocol (*see page 48*) (SNMP). The LTMR controller includes a configurable SNMP agent that can communicate with up to two SNMP managers.

**NOTE:** SNMP parameters can be configured only using the TeSys T DTM software.

Refer to the topic Configuring the SNMP Service (*see page 49*) for more information about configuring SNMP parameters.

## Network Port Comm Loss Settings

Configure the following parameters to determine how the LTMR controller will handle communication loss with the PLC:

- Network Port Comm Loss Timeout: the length of time communication with the PLC defined as Master IP must be lost before the controller will trigger a fault or warning.
  - Range = 0...9999 s
  - Increments = 0.01 s
  - Factory setting = 2 s
- Network Port Fallback Setting: determines-with the controller's operating mode, the behavior of logic outputs 1 and 2 when communication with the PLC is lost. For more information, refer to the explanation of the Fallback Condition. Values include:
  - Hold
  - Run
  - O.1, O.2 OFF
  - O.1, O.2 ON
  - O.1 ON
  - O.2 ON
- The factory setting is O.1, O.2 OFF.
- Network Port Fault Enable: reports a network fault after the Network Port Comm Loss Timeout setting has expired.
- Network Port Warning Enable: reports a network warning after the Network Port Comm Loss Timeout setting has expired.

## Ethernet Link Management

### Overview

The LTMR controller can receive or provide Ethernet services only if an Ethernet communications link exists. An Ethernet communications link can exist only when a cable connects one of the controller's network ports to the network. If no network cable connection exists, no Ethernet service can start.

The behavior of the controller is described in each of the following situations:

- The LTMR powers up with no network cable connected.
- A network cable is connected to a previously unconnected controller after startup.
- All network cables are disconnected from the controller after startup.
- One (or more) network cables are reconnected to a controller after all network cables had previously been disconnected.

### No Link while LTMR is Powered Up

When the LTMR powers up with no network cable connected, the LTMR

- goes into an FDR Fault if the rotary switches are in DHCP position,
- Goes into an FDR Fault for 10 s and then clears the fault automatically if the rotary switches are in Stored, BootP, ClearIP, or Disabled positions.

### No Link at Startup

When, after controller startup, an Ethernet network cable is initially attached to a previously unconnected controller

- The controller starts its IP addressing service (*see page 32*), which
  - Obtains IP address settings,
  - Validates IP address settings,
  - Checks that the obtained IP address settings are not duplicate,
  - Assigns the received IP address settings to the controller.
- After its IP address settings are assigned, the controller
  - Starts the FDR service and obtains its operating parameter settings, then
  - Starts its Modbus service.

The time to recover the link and start Ethernet services takes about 1 second.

### Link Disconnected After Startup

When all Ethernet network cables are disconnected from the controller after startup:

- The FDR service is disabled,
- All Modbus service connections are reset,
- If a Master IP connection exists and:
  - The link cannot be re-established, that is, the cable is not plugged back into the controller before the Network Port Comm Loss Timeout expires, the controller enters its pre-configured fallback state if the LTMR is in Network control,
  - The link is re-established before the Network Port Comm Loss Timeout expires, the connection to the Master IP is maintained, and the controller does not enter its fallback state.

### Link Reconnected After Disconnection

When one or more Ethernet network cables are reattached to the controller, after all network cables had been detached after startup, the controller performs many, but not all, of the same tasks as when there is No Link at Startup (*see page 30*). Specifically, the controller

- Presumes the previously obtained IP address settings remain valid, then
  - Checks that the IP address settings are not duplicate,
  - Re-assigns the IP address settings to the controller.
- After the IP address settings are assigned, the controller
  - Starts its FDR service and obtains its operating parameter settings, then
  - Starts its Modbus service.

The time to recover the link and start Ethernet services takes about 1 second.

## Master IP

### Overview

Each LTMR controller, in its role as communication server, could be configured to recognize another Ethernet device (typically a PLC) as the client device that controls the motor. This device is usually a device that initiates communication to exchange Process Data (control and status). The Master IP is the IP address of this device.

The PLC should continuously maintain at least one connection, called a virtual connection ([see page 52](#)) or socket, with the communication server.

If all connections between the communication clients and the LTMR server fail, the LTMR controller waits a prescribed time, the Network Port Comm Loss Timeout, for a new connection to be established and messages sent between the PLC and the communication server.

If a connection is not opened and messages are not received, the LTMR controller assumes its fallback state, set by the Network Port Fallback Setting.

### WARNING

#### LOSS OF CONTROL

- Configure a server IP on the Ethernet network.
- Do not use an IP address other than Master IP to send network start and stop commands to the LTMR controller.
- Design the Ethernet network to block unauthorized network start and stop commands sent to the LTMR controller.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

### Prioritized Master IP Connections with Modbus/TCP

Connections between the LTMR controller and the Modbus client has a priority over connections between the controller and other Ethernet devices.

After the controller has reached its maximum number of eight simultaneous Modbus connections, the controller must close an existing connection to be able to open a new connection. The controller closes existing connections based on the time of a connection's most recent transaction, closing the connection whose most recent transaction is the oldest.

However, all connections between the LTMR controller and the Modbus client are preserved. The controller will not close a connection with the Modbus server in order to open a new connection.

### Configuring Master IP


To enable connections to be made to a Modbus client, use a configuration tool to configure the following parameters:

Parameter	Setting Range	Factory Setting
Ethernet Master IP address setting (3010-3011)	Valid Class A, B, and C addresses in the range: 0.0.0.0-223.255.255.255	0.0.0.0
Network port comm loss timeout (693)	0...9999 s In increments of 0.01 s	2 s
Network port fallback setting (682)	<ul style="list-style-type: none"> <li>● Hold</li> <li>● Run</li> <li>● O.1, O.2 OFF</li> <li>● O.1, O.2 ON</li> <li>● O.1 OFF</li> <li>● O.2 OFF</li> </ul>	O.1, O.2 OFF

## IP Addressing

### Overview

The LTMR controller must obtain a unique IP address, subnet mask, and gateway address to communicate over an Ethernet network. The settings of the two rotary switches on the front of the LTMR controller determine the source of these essential settings. These settings are applied only on power-up. The rotary switches look like this:



The settings of the rotary switches determine the source of the LTMR controller's IP address parameters and the FDR service activation, as follows:

Left Switch (Tens)	Right Switch (Ones)	Source of IP Parameters
0-15 <sup>(1)</sup>	0-9 <sup>(1)</sup>	DHCP server and FDR service
N/A <sup>(2)</sup>	BootP	BootP server
N/A <sup>(2)</sup>	Stored	The rotary switch is not used to determine IP parameters. LTMR configured settings are used. If none, IP parameters are derived from the MAC address. Modbus service is disabled.
N/A <sup>(2)</sup>	Clear IP	Clears the stored IP settings. No IP addressing settings are assigned. The network port is disabled.
N/A <sup>(2)</sup>	Disabled	The LTMR controller is not available for network communication. The LTMR controller does not initiate any IP acquisition process (host register, DHCP...) or announcements of IP on the network. Network-related errors do not occur. However, the LTMR controller stays active on at the Ethernet switch level allowing the daisy chain to function normally.

(1) The two switches yield a value from 000-159, which uniquely identifies the device to the DHCP server. In the above figure, this value is 084, which is the concatenation of the:  
 Tens switch (08), and the  
 Ones switch (4)

The individual values of each rotary switch - in this case 08 and 4 - are incorporated into the device name, as described below.

(2) The left (Tens) rotary switch is not used. The right (Ones) rotary switch alone determines the source of IP parameters.

IP settings are assigned to the following parameters:

- Ethernet IP Address
- Ethernet subnet Mask
- Ethernet Gateway

### Getting IP Parameters from a DHCP Server

To obtain IP parameters from a DHCP server, point each rotary switch to a numerical setting, as follows:

Step	Description
1	Set the left-Tens-switch to a value from 0-15, and
2	Set the right-Ones-switch to a value from 0-9

**Device Name:** The settings of the two rotary switches are used to determine each LTMR controller's device name. The device name consists of a fixed part ("TeSys T") and a dynamic part, composed of:

- The two-digit value (00-15) of the Tens rotary switch ( $xx$ ), and
- The one-digit value (0-9) of the Ones rotary switch ( $y$ )

The DHCP server must be pre-configured with the LTMR controller's device name and its associated IP parameters. When the DHCP server receives the LTMR controller's broadcast request, it returns:

- The LTMR controller's:
  - IP address
  - Subnet mask
  - Gateway address
- The DHCP server's IP address

**NOTE:** While the IP address is not provided by the DHCP server, the TeSys T product declares a major fault network port FDR (Alarm LED steady red).

**NOTE:** The LTMR controller uses the DHCP server's IP address during the Faulty Device Replacement (FDR) process ([see page 32](#)), when making an FTP or TFTP request for device configuration parameters. In the figure, above, the device name is: TeSysT084.

**NOTE:** The DHCP server can provide an IP address to a server device only after the DHCP server has been configured with the Device Name, described above, for a server device.

### Getting IP Parameters from a BootP Server

To obtain IP parameters from a BootP server, point the right-Ones-rotary switch to either of the two **BootP** settings. (The left-Tens-rotary switch is not used.) The LTMR controller broadcasts a request for IP parameters to a BootP server, and includes its MAC address in the request.

The BootP server must be pre-configured with the LTMR controller's MAC address and associated IP parameters. When the BootP server receives the LTMR controller's broadcast request, it returns to the LTMR controller its:

- IP address
- Subnet mask
- Gateway address

**NOTE:** The Faulty Device Replacement (FDR) service is not available if the LTMR controller is configured to receive IP parameters from a BootP server.

### Using Stored IP Parameters

You can configure the LTMR controller to apply IP settings that have been previously configured and stored in the device itself. These stored IP parameters can be configured using your choice of configuration tool.

To apply stored IP parameters set the right–Ones–switch to either of the **Stored** positions. (The left-Tens–switch is not used.)

The LTMR controller uses as its:

- IP address: the Ethernet IP Address Setting parameter
- Subnet mask: the Ethernet Subnet Mask Setting parameters
- Gateway address: the Ethernet Gateway Address Setting parameter

**NOTE:** If these parameters are not pre-configured, the LTMR controller cannot apply stored settings, but instead applies default IP parameters, as described below.

**NOTE:** The FDR service is not available when the LTMR controller is configured to use stored IP parameters.

### Configuring Default IP Parameters from the MAC Address

The LTMR controller derives its default IP parameters from its MAC address (stored in the device's Ethernet MAC Address parameter). The MAC address is a unique identifier associated with the device's network interface card (NIC).

As a prerequisite for using the default IP address, all bytes of the configured IP address must be set to zero.

To apply the LTMR controller's default IP parameters, you must proceed in two steps:

Step	Action
1	Clear the existing IP address by setting the right-Ones-rotary switch to <b>Clear IP</b> , then cycle power.
2	Apply the stored IP address settings by setting the right-Ones-rotary switch to <b>Stored</b> , then cycle power.

The default IP parameters are generated as follows:

- The first two byte values of the IP address are always 85.16
- The last two byte values of the IP address are derived from the last two bytes of the MAC address
- The default subnet masks are always 255.0.0.0
- The default gateway is the same as the device's default IP address


For example, for a device with a hexadecimal MAC address of 0x000054EF1001, the last two bytes are 0x10 and 0x01. These hexadecimal values translate to decimal values of 16 and 01. The default IP parameters for this MAC address are:

- IP address: 85.16.16.01
- Subnet mask: 255.0.0.0
- Gateway address: 85.16.16.01

**NOTE:** Both the Faulty Device Replacement (FDR) service and the Modbus service are not available when default IP parameters are used.


### IP Assignment Process

As depicted in the following graphic, the LTMR controller performs a sequence of inquiries to determine its IP address:



**NOTE:** Both the Faulty Device Replacement (FDR) service and the Modbus service are not available when default IP parameters are used.

The following diagram depicts the *assign default IP address* process, referenced above:



### IP Assignment and STS/NS LED

During the IP address assignment process while the LTMR is operating normally and is not experiencing an internal fault, the green STS/NS LED may indicate the following conditions:

Switch Setting(s)	STS/NS LED Behavior	Description
BootP	Flashes five times, then repeats	The controller sent a BootP request, but the BootP server did not deliver valid, unique IP address settings. Waiting for BootP server.
	Flashes five times, then solid ON	The controller sent a BootP request, and the BootP server delivered valid and unique IP address settings.
Stored	Solid ON	The LTMR controller is configured with valid, unique stored IP address settings.
	Flashes six times, then repeats	No valid, unique IP parameters are stored. Default IP settings are generated using the MAC address.
Clear IP	Flashes two times, then repeats	IP address settings have been cleared. No IP address settings are available. Controller cannot communicate using its Ethernet network ports.
Disabled	Solid ON	The LTMR controller is configured with valid, unique stored IP address settings.
	Flashes six times, then repeats	No valid, unique IP parameters are stored. Default IP settings are generated using the MAC address.
Left (Tens) switch set to 0-15 (xx) Right (Ones) switches set to 0-9 (y)	Flashes five times, then repeats	The controller sent a DHCP request for device name (TeSysTxy), but the DHCP server did not deliver valid, unique IP address settings. Waiting for DHCP server.
	Flashes five times, then solid ON	The controller sent a DHCP request for device name (TeSysTxy), and the DHCP server delivered valid and unique IP address settings.

**NOTE:** A repeating series of eight flashes by the STS/NS LED indicates an unrecoverable FDR fault condition. The causes and potential cures for an unrecoverable FDR fault include:

- An internal communication failure within the LTMR controller: Cycle power to the controller; if that fails, replace the controller.
- An invalid configuration of the Ethernet properties (typically IP address settings or the Master IP address): Verify the IP address parameter settings.
- An invalid or corrupt operating parameter file: Transfer a corrected parameter file from the controller to the parameter file server ([see page 39](#)). The transfer of a parameter file to the FDR server is only available with the LTMR controller Ethernet version.

## Faulty Device Replacement

### Overview

The FDR service employs a central server to store both the IP addressing parameters and the operating parameters for an LTMR controller. When a failed LTMR controller is replaced, the server automatically configures the replacement LTMR controller with the same IP addressing and operating parameters as the failed controller.

**NOTE:** The FDR service is available only when the controller's Ones rotary switch is set to integers. The FDR service is not available when the Ones rotary switch is set to *BootP*, *Stored*, *Clear IP*, or *Disabled*.

The FDR service includes configurable commands and settings that you can access using your choice of configuration tool. These commands and settings include:

- Commands that let you manually:
  - Backup the LTMR controller's operating parameters, by uploading a copy of the device's parameter file to the server from the controller, or
  - Restore the LTMR controller's parameters, by downloading a copy of the device's operating parameter file from the server to the controller.
- Settings that cause the FDR server to automatically synchronize the operating parameter files, in both the LTMR controller and the server, at configurable time intervals. If a difference is detected, a parameter file is sent from the controller to the FDR server (auto backup).

### Preconditions to FDR

Before the FDR service can function, the FDR server must be configured with:

- The LTMR controller's network address and related IP addressing parameters, this is done as part of the IP addressing service ([see page 32](#)),
- A copy of the LTMR controller's operating parameter file, this can be sent from the controller to the server either manually or automatically, as described below.

### FDR and Custom Logic File

The FDR service save custom logic to the operating parameters file if the custom logic file size is lower than 3 Kb.

If the custom logic file size is bigger than 3 Kb, only the operating parameters file is saved.

In this case, when you are replacing a device with a custom logic file size bigger than 3 Kb, the STS/NS LED of the new device flashes eight times signaling a critical error.

To resolve the error and resume operations:

Step	Action
1	Use the TeSys T DTM software to download the configuration
2	Cycle power to the LTMR controller

### FDR Process

The FDR process consists of three parts:

- The assignment of IP address settings,
- A check of the operating parameter file at every LTMR controller startup,
- If auto-synchronization is enabled, periodic checks of the LTMR controller's operating parameter file.

These three processes are described below:

#### IP address settings assignment process:

Sequence	Event
1	Your service personnel uses the rotary switches on the front of the replacement LTMR controller to assign it the same network address (000-159) as the failed device.
2	Your service personnel places the replacement LTMR controller on the network.
3	The LTMR controller automatically sends a DHCP request to the server for its IP parameters.

Sequence	Event
4	The server sends the LTMR controller: <ul style="list-style-type: none"> <li>● IP parameters, including: <ul style="list-style-type: none"> <li>○ IP address</li> <li>○ Subnet mask</li> <li>○ Gateway address</li> </ul> </li> <li>● The server's IP address</li> </ul>
5	The LTMR controller applies its IP parameters.

**Startup FDR process:**


Sequence	Event
6	<ul style="list-style-type: none"> <li>● If FDR is enabled in the FDR configuration screen: <ul style="list-style-type: none"> <li>a The controller sends a request to the FDR server for a copy of the served configuration file.</li> <li>b The FDR server sends the controller a copy of the served file.</li> <li>c The controller checks the served file's version number and size for compatibility with the device. If the served file is <ul style="list-style-type: none"> <li>● Compatible, the served file is applied,</li> <li>● Not compatible, the controller enters a critical internal error state<sup>(1)</sup>.</li> </ul> </li> </ul> </li> </ul> <p><b>Notes:</b></p> <ol style="list-style-type: none"> <li>1. Because the factory setting of <b>FDR Enable</b> is <b>selected</b>, a new LTMR controller always downloads and attempts to apply a served file on initial startup.</li> <li>2. If the downloaded file is empty, the controller will use its local file and send a copy of that file to the server.</li> </ol> <ul style="list-style-type: none"> <li>● If <b>FDR Enable</b> is de-selected: The controller applies the operating parameter file stored in the LTMR controller's non-volatile memory.</li> </ul>
7	The LTMR controller resumes operation.
(1) In the event of an internal critical error, the underlying problem must be resolved and power must be cycled to the controller before operations can resume.	


**Auto-synchronization FDR process:**

Sequence	Event
8	The controller checks the <i>Network Port FDR Auto Backup Period Setting</i> (697) parameter to determine if the FDR auto-synchronization timer has expired.
9	If the timer has: <ul style="list-style-type: none"> <li>● <b>Not expired</b>: No action is taken.</li> <li>● <b>Expired</b>: The controller checks the <i>Network Port FDR Auto Backup Enable</i> (690.3) parameter.</li> </ul>
10	If the <i>Network Port FDR Auto Backup Enable</i> (690.3) parameter is: <ul style="list-style-type: none"> <li>● <b>Auto backup (1)</b>: The controller sends a copy of the local file to the FDR server.</li> <li>● <b>No synchro (0)</b>: The controller takes no action.</li> </ul>
11	The LTMR controller resumes operation.

The following diagrams describe the controller's FDR processes after the assignment of an IP address:

FDR Startup Process:





## Configuring FDR

The FDR service monitors the operating parameter file maintained in your LTMR controller and compares it against the corresponding operating parameter file stored in the server.

When the FDR service detects a discrepancy between these two files:

- The Network Port FDR Status ([see page 40](#)) parameter is set, and
- The two operating parameter files, one in the server, the other in the controller, must be synchronized.

Synchronizing operating parameter files can be performed either automatically or manually, using your choice of configuration tool.

**Automatically Backup Settings:** By setting the following parameters, you can configure your LTMR controller to automatically synchronize its operating parameters with the FDR server:

Parameter Name	Description
Network Port FDR Auto Backup Enable	Use this setting to enable/disable automatic synchronization of the operating parameter files. Selections are: <ul style="list-style-type: none"> <li>• <b>No auto backup:</b> Automatic file synchronization is turned OFF (parameter = 0).</li> <li>• <b>Auto backup:</b> Automatic file synchronization is turned ON, and the file in the controller will be copied to the server in case of discrepancy (parameter = 1).</li> </ul>
Network Port FDR Auto Backup Period Setting	The frequency, in seconds, between comparisons of the parameter file in the controller against the parameter file stored in the server. <ul style="list-style-type: none"> <li>• Range = 1...65535 s</li> <li>• Increments = 1 s</li> <li>• Factory setting = 120 s</li> </ul>

**NOTE:** When automatic synchronization is enabled, it is recommended to set the *Network Port FDR Auto Backup Period Setting* parameter to a value greater than **120 s**.

**Manually Backup and Restore Settings:** By executing the commands described below, you can manually synchronize the operating parameter files in the controller and server:

Command Name	Description
FDR Data Backup Command	Copies the operating parameter file in the controller to the server.
FDR Data Restore Command	Copies the operating parameter file in the server to the controller.

**NOTE:**

- If FDR Data Backup Command and FDR Data Restore Command bits are set to 1 simultaneously, an FDR Data Restore Command is proceeded.
- FDR Data Restore Command is active whether Config via network is enabled or not.
- FDR Data Restore Command cannot be done while the LTMR detects line currents.
- Any time the LTMR controller configuration changes, you should manually backup the new configuration file to the server by clicking **Device → File transfert → backup command**.

## Error Recovery

When the LTMR controller experiences a critical error during the FDR startup process, the STS/NS LED flashes as follows:

Number of Flashes...	Indicates the Error is...
Eight flashes per second	Unrecoverable
10 flashes per second	Recoverable

**Recoverable errors:**

Operations can resume after fixing the error. Recoverable errors include:

- No file on the parameter server (Network Port FDR Status = 3)
- The parameter file server, or TFTP service, is down (Network Port FDR Status = 2)

**Unrecoverable errors:**

When the parameter file in the server is invalid or corrupt, the error is not recoverable. Operations can resume only after a new parameter file is manually copied from the controller to the server using the FDR Data Backup Command and power is cycled to the controller. Non-recoverable errors include:

- Version mismatch of the parameter file on the parameter server and the LTMR controller (Network Port FDR Status = 13)
- CRC mismatch between parameter file on the server and the LTMR controller (Network Port FDR Status = 9)
- Content of the parameter file is invalid (Network Port FDR Status = 4)

## FDR Status

The Network Port FDR Status parameter describes the state of the FDR service, as described below.

**NOTE:** FDR status values are valid only when the LTMR controller is in an error condition.

FDR Status:

Value	Description
0	Ready, IP available, no error
1	No response from IP server
2	No response from parameter server
3	No file on parameter server
4	Corrupt file on parameter server
5	Empty file on parameter server
6	Internal communication fault (from network port to HMI port)
7	Write error copying settings to parameter server
8	Invalid settings provided by the controller

Value	Description
9	CRC mismatch between parameter server and controller
10	Invalid IP
11	Duplicate IP
12	FDR disabled
13	Device Parameter File Version Mismatch (for example, when attempting to replace an LTMR 08 EBD with an LTMR 100 EBD)

## Discovery Procedure

### Overview

Discovery is an automated method to identify and connect to a device with an unknown IP address, using a direct PC connection and a webpage access interface.

Discovery is only available on Microsoft Windows Vista, 7, and 8 operating systems.

Step	Automated Action
1	Connect the PC to the TeSys T using a RJ45 cable.
2	<ul style="list-style-type: none"><li>● Open Windows Explorer</li><li>● Expand Network to view all network connections</li><li>● The Connected device should appear in the list within a few seconds</li></ul>
3	Double-click the connected TeSys T. The name of the TeSys T is: <ul style="list-style-type: none"><li>● <b>TeSys T-XXYYZZ</b> (where XXYYZZ are the last three bytes of MAC address in hexadecimal format) if TeSys T is not configured in DHCP mode.</li><li>● <b>TeSys T-XYZ</b> (where XY is the position of Tens rotary switch and Z is the position of Ones rotary switch) if TeSys T is configured in DHCP mode.</li></ul>
4	Access the TeSys T in the webpage interface.

**NOTE:** If the product cannot be detected, deactivate the antivirus and the firewall and then retry. Do not forget to restart the antivirus when finished.

## Ethernet Diagnostics

### Overview

The LTMR controller reports diagnostic data describing its Ethernet network communications interface, including:

- Data parameters that describe the controller's:
  - IP addressing settings
  - IP address assignment processes
  - Virtual connections
  - Communication history
  - Communication services and their status
- One parameter that describes the validity of the data in each data parameter

**NOTE:** It is recommended to read the diagnostics registers every second.

**NOTE:** The response to the first request contains either all zeros or old data. The response to the second and subsequent requests contains current network port diagnostic data.

### Ethernet Basic HW Diag Validity

The Ethernet Basic HW Diag Validity parameter evaluates and reports the validity of Ethernet network diagnostic data. A bit in this parameter represents the state of an associated Ethernet network data parameter.

Bit values are:

Value	Indicates the Parameter Data is...
0	Invalid
1	Valid

The Ethernet Basic HW Diag Validity parameter is 32 bits long.

The bits of this parameter represent the validity of the following Ethernet data parameters:

Bit	Describes the Validity of Data in this Parameter...
0	IP address assignment mode
1	Ethernet device name
2	Ethernet MB messages received counter
3	Ethernet MB messages sent counter
4	Ethernet MB error messages sent counter
5	Ethernet opened servers counter
6	Ethernet opened clients counter
7	Ethernet transmitted correct frames counter
8	Ethernet received correct frames counter
9	Ethernet frame format
10	Ethernet MAC address
11	Ethernet gateway
12	Ethernet subnet mask
13	Ethernet IP address
14	Ethernet service status
15	(not applicable - always 0)
16	Ethernet services
17	Ethernet global status
18-31	(Reserved - always 0)

### Ethernet Global Status

The Ethernet Global Status parameter indicates the status of the following services provided by the LTMR controller:

- Faulty device replacement (FDR)
- SNMP network management
- Modbus port 502 messaging (Modbus/TCP only)

This parameter is 2 bits long.

Parameter values are:

Bit	Indicates...
0	At least one enabled service is operating with an unresolved found error
1	All enabled services are operating without error

Ethernet Global Status is cleared on power cycle and controller reset.

### Ethernet Services Validity

The Ethernet Services Validity parameter indicates whether the LTMR controller supports the port 502 messaging service.

**NOTE:** Port 502 is exclusively reserved for Modbus messages.

The Ethernet Supported Services parameter is 1 bit long.

Parameter values are:

Value	Indicates the Port 502 Messaging Service is...
0	Not supported
1	Supported

### Ethernet Services Status

The Ethernet Services Status parameter indicates the status of the Ethernet Supported Services parameter, that is, the status of the controller's port 502 messaging service.

This parameter is 3 bits long.

Parameter values are:

Value	Indicates the Port 502 Messaging Service is...
1	Idle
2	Operational

Ethernet Services Status is cleared on power cycle and controller reset.

### Ethernet IP Address

The Ethernet IP Address parameter describes the IP address that has been assigned to the LTMR controller by the IP address assignment process ([see page 32](#)).

The Ethernet IP Address consists of 4 byte values, in dot-decimal notation. Each byte value is an integer from 000-255.

### Ethernet Subnet Mask

The Ethernet Subnet Mask parameter is applied to the Ethernet IP Address value to define the host address of the LTMR controller.

The Ethernet Subnet Mask consists of 4 byte values, in dot-decimal notation. Each byte value is an integer from 000-255.

### Ethernet Gateway Address

The Ethernet Gateway Address parameter describes the address of the default gateway, that is, the node that serves as an access point to other networks for communications from or to the LTMR controller.

The Ethernet Gateway Address consists of 4 byte values, in dot-decimal notation. Each byte value is an integer from 000-255.

## Ethernet MAC Address

The Ethernet MAC Address parameter describes the media access control (MAC) address, or hardware identifier, uniquely assigned to an LTMR controller.

The Ethernet MAC Address consists of six hexadecimal byte values, from 0x00-0xFF.

## Ethernet II Framing

The Ethernet II Framing parameter describes the Ethernet frame formats supported by the LTMR controller, including:

- Capability: can the device support a frame format?
- Configuration: is the device configured to support a frame format?
- Operational: is the configured frame format operating successfully?

**NOTE:** The Ethernet frame type, Ethernet II or 802.3, is configured using the Network Port Frame Type Setting parameter.

This parameter is three words long.

Ethernet II framing data is stored as follows:

Word	Bit	Description	Values
1	0	Ethernet II framing <b>supported</b>	<ul style="list-style-type: none"> <li>● 0 = not supported</li> <li>● 1 = supported</li> </ul>
	1	Ethernet II framing receiver <b>supported</b>	<ul style="list-style-type: none"> <li>● 0 = not supported</li> <li>● 1 = supported</li> </ul>
	2	Ethernet II framing sender <b>supported</b>	<ul style="list-style-type: none"> <li>● 0 = not supported</li> <li>● 1 = supported</li> </ul>
	3	Ethernet auto detection <b>supported</b>	<ul style="list-style-type: none"> <li>● 0 = not supported</li> <li>● 1 = supported</li> </ul>
	4-15	( <i>Reserved</i> )	always 0
2	0	Ethernet II framing <b>configured</b>	<ul style="list-style-type: none"> <li>● 0 = not configured</li> <li>● 1 = configured</li> </ul>
	1	Ethernet II framing receiver <b>configured</b>	<ul style="list-style-type: none"> <li>● 0 = not configured</li> <li>● 1 = configured</li> </ul>
	2	Ethernet II framing sender <b>configured</b>	<ul style="list-style-type: none"> <li>● 0 = not configured</li> <li>● 1 = configured</li> </ul>
	3	Ethernet auto detection <b>configured</b>	<ul style="list-style-type: none"> <li>● 0 = not configured</li> <li>● 1 = configured</li> </ul>
	4-15	( <i>Reserved</i> )	always 0
3	0	Ethernet II framing <b>operational</b>	<ul style="list-style-type: none"> <li>● 0 = not operational</li> <li>● 1 = operational</li> </ul>
	1	Ethernet II framing receiver <b>operational</b>	<ul style="list-style-type: none"> <li>● 0 = not operational</li> <li>● 1 = operational</li> </ul>
	2	Ethernet II framing sender <b>operational</b>	<ul style="list-style-type: none"> <li>● 0 = not operational</li> <li>● 1 = operational</li> </ul>
	3	Ethernet auto detection <b>operational</b>	<ul style="list-style-type: none"> <li>● 0 = not operational</li> <li>● 1 = operational</li> </ul>
	4-15	( <i>Reserved</i> )	always 0

## Ethernet Received Correct Frames Counter

The Ethernet Received Correct Frames Counter parameter contains a count of the total number of Ethernet frames that have been successfully received by the LTMR controller.

This parameter is an UDInt parameter. It is cleared on power cycle and controller reset.

The Ethernet Received Correct Frames Counter consists of four hexadecimal values, from 0x00-0xFF.

### Ethernet Transmitted Correct Frames Counter

The Ethernet Transmitted Correct Frames Counter parameter contains a count of the total number of Ethernet frames that have been successfully transmitted by the LTMR controller.

This parameter is an UDInt parameter. It is cleared on power cycle and controller reset.

The Ethernet Transmitted Correct Frames Counter consists of four hexadecimal values, from 0x00-0xFF.

### Ethernet Opened Clients Counter

The Ethernet Opened Clients Counter parameter contains a count of the number of open TCP client connections. It applies only to devices with TCP clients.

This parameter is an UInt parameter. It is cleared on power cycle and controller reset.

The Ethernet Opened Clients Counter consists of two hexadecimal values, from 0x00-0xFF.

### Ethernet Opened Servers Counter

The Ethernet Opened Servers Counter parameter contains a count of the number of open TCP server connections. It applies only to devices with TCP servers.

This parameter is an UInt parameter. It is cleared on power cycle and controller reset.

The Ethernet Opened Servers Counter consists of two hexadecimal values, from 0x00-0xFF.

### Ethernet MB Error Messages Sent Counter

The Ethernet MB Error Messages Sent Counter parameter contains a count of the number of:

- EtherNet/IP or Modbus/TCP request packets with errors in the header that have been received by this LTMR controller (does not count errors in the data portion of EtherNet/IP or Modbus/TCP request packets)
- EtherNet/IP or Modbus/TCP exceptions due to incorrect combination of physical port and Unit ID (*see page 53*)

This parameter is an UDInt parameter. It is cleared on power cycle and controller reset.

### Ethernet MB Messages Sent Counter

The Ethernet MB Messages Sent Counter parameter contains the total number of Modbus messages, excluding Modbus error messages, that have been sent by this LTMR controller.

This parameter is an UDInt parameter. It is cleared on power cycle and controller reset.

### Ethernet MB Messages Received Counter

The Ethernet MB Messages Received Counter parameter contains the total number of Modbus messages that have been received by this LTMR controller.

This parameter is an UDInt parameter. It is cleared on power cycle and controller reset.

### Ethernet Device Name

The Ethernet Device Name parameter contains the 16 character string used to identify the LTMR controller.

This parameter is 16 bytes long.

## Ethernet IP Assignment Capability

The Ethernet IP Assignment Capability parameter describes the available IP addressing sources for the LTMR controller. Up to four different IP addressing sources can be described.

This parameter is 4 bits long.

The Ethernet IP Assignment Capability parameter stores data as follows:

Bit	IP Addressing Source...	Values
0	A DHCP server, using the device name set by the two rotary switches	<ul style="list-style-type: none"> <li>● 0 = not available</li> <li>● 1 = available</li> </ul>
1	Derived from the MAC address. The Ones rotary switch is set to BootP, but no IP address was received from the server.	<ul style="list-style-type: none"> <li>● 0 = not available</li> <li>● 1 = available</li> </ul>
2	Derived from the MAC address. Both rotary switches are set to integers, but no IP address was received from the DHCP server.	<ul style="list-style-type: none"> <li>● 0 = not available</li> <li>● 1 = available</li> </ul>
3	The stored configuration parameters: <ul style="list-style-type: none"> <li>● Ethernet IP Address Setting</li> <li>● Ethernet Subnet Mask Setting</li> <li>● Ethernet Gateway Address Setting</li> </ul>	<ul style="list-style-type: none"> <li>● 0 = not available</li> <li>● 1 = available</li> </ul>

## Ethernet IP Assignment Operational

The Ethernet IP Assignment Operational parameter describes how the current IP address was assigned to the LTMR controller. Only 1 (of 4) different IP address sources can be operational at any one time.

This parameter is 4 bits long.

The Ethernet IP Assignment Operational parameter stores data as follows:

Bit	IP Addressing Source...	Values
0	A DHCP server, using the device name set by the two rotary switches	<ul style="list-style-type: none"> <li>● 0 = not operational</li> <li>● 1 = operational</li> </ul>
1	Derived from the MAC address. The Ones rotary switch is set to BootP, but no IP address was received from the server.	<ul style="list-style-type: none"> <li>● 0 = not operational</li> <li>● 1 = operational</li> </ul>
2	Derived from the MAC address. Both rotary switches are set to integers, but no IP address was received from the DHCP server.	<ul style="list-style-type: none"> <li>● 0 = not operational</li> <li>● 1 = operational</li> </ul>
3	The stored configuration parameters: <ul style="list-style-type: none"> <li>● Ethernet IP Address Setting</li> <li>● Ethernet Subnet Mask Setting</li> <li>● Ethernet Gateway Address Setting</li> </ul>	<ul style="list-style-type: none"> <li>● 0 = not operational</li> <li>● 1 = operational</li> </ul>

## Simple Network Management Protocol

### Overview

The LTMR controller includes an SNMP version 3.0 *agent* that can connect to and communicate with an SNMP *manager* via the UDP transport protocol over port 161.

The SNMP service includes:

- Automatic discovery and identification of the LTMR by an SNMP manager over an Ethernet network
- Authentication checking, by the LTMR controller, of any SNMP manager that sends requests to the controller
- Management of event, or trap, reporting by the LTMR controller, including the identification of two SNMP managers authorized to receive reports
- Full support of MIB-II (standard TCP/IP) parameters

**NOTE:** Access to, and configuration of, the SNMP parameters is available only using the TeSys T DTM.

### SNMP Agents and Managers

The SNMP management model uses the following terms and definitions:

- Manager, the client application (for example, Connexium Network Manager (CNM) or a simple MIB browser) running on the PC
- agent, the server application running on a network device, in this case the LTMR controller

An SNMP manager communicates with an agent by sending queries for the purpose of reading data from, and writing data to, the agent. An SNMP manager uses UDP to establish communications with an agent via an open Ethernet interface.

Agents can also initiate communications with a manager by sending unsolicited trap messages, which report the occurrence of specific events.

### SNMP Messages

SNMP supports the following types of messages between the manager and the agent:

- Get: the manager requests an agent to send information.
- Set: the manager requests an agent to change information stored by the agent.
- Response: the client replies to a Get or Set request.
- Trap: the agent sends an unsolicited report to the manager that an event has occurred.

MIB-II defines the agent properties that the manager can Get or Set.

### Trap Reporting

A trap is an agent-detected event that indicates either

- A change has occurred in the status of the agent, or
- An unauthorized manager device has attempted to get data from, or change data on, the agent

Configure the LTMR controller's SNMP agent to report traps to one or two authorized SNMP managers. Allows to enable or to disable certain traps.

The LTMR controller supports the following traps:

Trap	Description	Configurable in the TeSys T DTM?
Authentication Failure	The agent received a request from an unauthorized manager.	Yes (enable/disable)
Cold Start	The agent is reinitializing and its configuration may be altered.	No (always enabled)
Link Down	One of the agent's communication links has failed.	No (always enabled)
Link Up	One of the agent's communication links has turned on.	No (always enabled)
Warm Start	The agent's configuration has changed.	No (always enabled)

## Security

SNMP uses community names to provide security against the unauthorized access to the LTMR's configuration settings and trap notifications. A community name acts a password. Each type of communication (Get, Set, and Trap) can be separately configured with a password.

Both the manager and the agent must be configured with the same password, for a communication type, to permit:

- The agent to accept gets or set requests from the manager, and
- The manager to accept trap notifications from the agent

## Configuring the SNMP Service

Using the TeSys T DTM, you can access the following SNMP-related parameters:

TeSys T DTM Field Name	Parameter Name	Value
SNMP Manager Address 1	Ethernet SNMP Manager Address 1 Setting.	0.0.0.0-255.255.255.255 default = 0.0.0.0
SNMP Manager Address 2	Ethernet SNMP Manager Address 2 Setting.	0.0.0.0-255.255.255.255 default = 0.0.0.0
SNMP System Name <sup>(1)</sup>	Ethernet SNMP System Name Setting.	LTMR••E••
SNMP System Location <sup>(1)</sup>	Ethernet SNMP System Location Setting.	0-32 characters
SNMP System Contact <sup>(1)</sup>	Ethernet SNMP System Contact Setting.	0-32 characters
GET Community Name	Ethernet SNMP Community Name Get Setting.	0-16 characters; default = public
SET Community Name	Ethernet SNMP Community Name Set Setting.	0-16 characters; default = private
TRAP Community Name	Ethernet SNMP Community Name Trap Setting.	0-16 characters; default = public
"Authentication failure" Trap	Network Port SNMP Trap Authentication Failure Enable.	Yes/No; default = Yes

**(1)** It is recommended practice that any change to these parameter values be made using the TeSys T DTM software, and not via the SNMP manager.

## Section 3.2

### Using the Modbus/TCP Communication Protocol

#### Overview

This section describes how to use the controller over a Modbus/TCP communication protocol network.

#### WARNING

##### LOSS OF CONTROL

- The designer of any control scheme must consider the potential failure modes of control paths and, for certain critical functions, provide a means to achieve a safe state during and after a path failure. Examples of critical control functions are emergency stop and overtravel stop.
- Separate or redundant control paths must be provided for critical control functions.
- System control paths may include communication links. Consideration must be given to the implications of anticipated transmission delays or failures of the link.<sup>(1)</sup>
- Each implementation of an LTMR controller must be individually and thoroughly tested for proper operation before being placed into service.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

(1) For additional information, refer to NEMA ICS 1.1 (latest edition), "Safety Guidelines for the Application, Installation, and Maintenance of Solid State Control".

#### WARNING

##### UNEXPECTED RESTART OF THE MOTOR

Check that the PLC application software:

- considers the change from local to remote control,
- manages appropriately the motor control commands during those changes.

When switching to the Network control channels, depending on the communication protocol configuration, the LTMR controller can take into account the latest known state of the motor control commands issued from the PLC and restart automatically the motor.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

#### What Is in This Section?


This section contains the following topics:

Topic	Page
Modbus/TCP Protocol Principle	51
Modbus/TCP Requests	53
Modbus Exception Management	54
I/O Scanning Configuration	55

## Modbus/TCP Protocol Principle

### Overview

The Modbus/TCP protocol is a client/server protocol:



**1** Client (PLC, PC, or communication module)

**2** Straight or crossed category 5 shielded/unshielded twisted-pair Ethernet cable with RJ45 connector

Only one device can transmit in one direction over a segment at any time.

The client manages and initiates the exchange. It interrogates each of the servers in succession. No server can send a message unless it is invited to do so.

The client repeats the question when there is an incorrect exchange, and declares the interrogated server absent if no response is received within a given time period.

If a server does not understand a message, it does nothing. It sends an exception response to the client when a message is understood but contains errors, or when the server is not able to handle the request (for example, due to resource problems). The client may or may not retransmit the request.

**NOTE:** For further details on Modbus function codes visit the website: <http://modbus.org/specs.php>

### Modbus/TCP Dialog

Modbus/TCP supports only unicast dialogs, comprising requests made by a client to a server and the server's response.

Direct server-to-server communications are not possible. For server-to-server communication, the client must therefore interrogate a server and send back data received to the other server.

### Modbus/TCP Messaging

Modbus/TCP is the Modbus protocol encapsulated in TCP. The Modbus/TCP communications protocol combines the:

- Modbus application layer protocol (layer 7 of OSI model), which provides the messaging structure for organizing and interpreting data, and
- TCP transport layer protocol (layer 4 of the TCP/IP stack), which provides a reliable transmission medium for communications between devices on an Ethernet network

The TCP frame, with embedded Modbus data, is sent via TCP to system port 502, which is exclusively reserved for Modbus applications, and added to a TCP/IP Ethernet data packet for network transmission.

## Virtual Connections

Although there can be either one or two *physical* connections between a client and a server-depending upon the network topology (star ([see page 16](#)) or daisy chain ([see page 17](#)))-Modbus/TCP supports the use of multiple *virtual* connections.

A virtual connection - or socket - combines:

- The client IP address (for example, the Modbus/TCP client)
- A unique port on the server
- The server IP address (the LTMR controller server)
- A unique port on the client
- The TCP protocol

Multiple virtual connections enable multiple simultaneous - instead of serial - transactions between the client and the server.

Modbus/TCP supports several types of simultaneous client/server transactions, as follows:

Transaction Type	Limits on the Number of Simultaneous Virtual Connections
Modbus	Eight maximum Notes: <ul style="list-style-type: none"> <li>● If a new connection is created when eight connections already exist, the new connection replaces the pre-existing connection, whose most recent transaction is the oldest.</li> <li>● You can identify a connection as a Master IP connection, thereby preventing it from being automatically replaced when the maximum number of connections is exceeded.</li> </ul>
SNMP	unlimited
FDR	one maximum
FTP	one minimum

## Modbus/TCP Requests

### Modbus/TCP Requests

You can use all physical ports—the LTME/HMI port and either of the two Ethernet communications ports—to send and receive Modbus/TCP requests. However, specific communications functions can be performed only using specific combinations of:

- Physical port, and
- Unit ID

**NOTE:** Failure to use the correct combination of physical port and Unit ID will cause the LTMR controller to report a Modbus/TCP exception.

Modbus/TCP supports the following requests, which can be performed using the physical ports and Unit ID codes set forth below:

Function Code/Subcode	Request Description	Using These Port and Unit ID Combinations...	
		Ethernet Ports	LTME/HMI Port
3/-	Read N output words (multiple registers)	Unit ID = 0-254	Modbus address = 1-247
6/-	Write one output word (single register)	Unit ID = 0-254	Modbus address = 1-247
8/22	Read or clear diagnostic data	Unit ID = 255	(Not available)
16/-	Write N output words (multiple registers)	Unit ID = 0-254	Modbus address = 1-247
23/-	Read/write multiple registers	Unit ID = 0-254	Modbus address = 1-247
43/14	Read identification (identification register)	(Reserved)	Modbus address = 1-247

The maximum number of registers per request is limited to 100.

**NOTE:** For further details on Modbus function codes visit the following website:  
<http://modbus.org/specs.php>

<b>⚠ WARNING</b>	
<b>UNINTENDED EQUIPMENT OPERATION</b>	
Use of this device on a Modbus network that uses the broadcast function should be considered with caution.	
This device has a large number of registers that must not be modified during normal operation. Unintended writing of these registers by the broadcast function may cause unexpected and unwanted product operation.	
For more information, refer to the Communication variables list.	
<b>Failure to follow these instructions can result in death, serious injury, or equipment damage.</b>	

## Modbus Exception Management

### Overview

The LTMR controller generally follows the Modbus requirements for the Exception Management.

Three special cases apply to the LTMR controller:

- Bit-Field Registers
- Exception Code 02 - Illegal Data Address
- Exception Code 03 - Illegal Data Value

### Bit-Field Registers

Some registers in the Register Map are Bit field. Based on the LTMR controller state, some bits in those registers shall not be writable. In this case, the LTMR controller shall reject the write to those bits meaning that no exception shall be returned. For example, bits that can be written only in configuration mode will be ignored (no exception returned) if the LTMR controller is out of the Sys Config State. The write to the bits not constrained by the LTMR controller state shall however occur.

### Exception Code 02 - Illegal Data Address

In general, the LTMR controller shall return an illegal data address exception code if the address is out of range or inaccessible. Specifically, the LTMR controller shall return an illegal data address if:

- A Write request is sent to a Read only register.
- The permission to write a register is not granted because of the LTMR controller state: this is the case, for example, when a register that can be written only in configuration mode is written while the LTMR controller is out of Sys Config state.

### Exception Code 03 - Illegal Data Value

In general, the LTMR controller shall return an illegal data value exception code if there is a problem with the structure of the message, such as an invalid length. The LTMR controller shall also use this exception code if:

- The data to be written is out of range (for standard and Bit field registers): this is the case if a write request of 100 is sent to a R/W register with a range of 0-50.
- A reserved bit or register is written to a value different than 0.
- Motor low speed command (bit 704.6) is set while the motor controller mode selected is not a two-speed mode of operation.

## I/O Scanning Configuration

### Mirroring High Priority Registers

The LTMR controller provides a block of nine contiguous registers dedicated to scanning that mirror the values and functionality of selected high priority registers ([see page 138](#)).

The LTMR controller reads the values of all high priority registers whenever it detects a change to any single high priority register, and writes the values of all high priority registers to the mirroring registers.

Because the mirroring registers are contiguous, it is possible to execute a single Modbus block read or block write request to these registers, thereby saving the time it would take to make separate Modbus read/write requests directly to each underlying high priority register.

### Mirroring Status

Mirroring status ([see page 138](#)) is the first register, in the sequence of eight contiguous mirroring registers. Bits 0-2 of this register describe the status of read-only commands, and bits 8-10 describe the status of read/write commands ([see page 138](#)).

**NOTE:** Use only the two Ethernet ports to read mirroring status register bit values. Using the HMI/LTME port produces an invalid, constant value of 0 for each bit.

All other mirroring status registers can be read accurately using either the HMI/LTME port or the two Ethernet ports.

### Configuring I/O Scanning

Your success in configuring I/O scanning of registers depends upon:

- The register type
- The I/O scanning period
- The I/O scanning health timeout period

Total number of registers accessed (read and write) in I/O scan (counting the repeated registers also) shall not exceed 500 registers per second. This limit shall be calculated with all the combinations of request and also take into account multiple connections. If there are multiple connections to the LTMR Controller, the I/O scanning and I/O scanning health timeout settings for read and write transactions for registers are reduced. Any settings for I/O scan period or I/O scan health timeout, lower than described below, can cause the LTMR controller to send Modbus exception packets.

For high performance, It is recommended to use the mirror registers. Using the command register 704 will add overload on LTMR controller as the register 704 is already treated and refreshed in mirroring register

- Instead of register 457 use mirroring register 2504
- Instead of register 704 use mirroring register 2507

Purpose of I/O scanning is to be used for fast control command. Settings by network or value checking should be done by acyclic request.

The following table describes the I/O scanning and I/O scanning health timeout settings for read and write transactions for registers of varying types with only one connection on the LTMR controller:

Transaction I/O	Register Type	I/O Scan Period (Minimum)	Health Timeout: Set to 3 Times Scan Period. Minimum 900 ms
Read/Write mirroring registers transaction	Mirroring registers: ● register 2500...2505: read ● register 2506...2508: write	5 ms for Read 50 ms for Read/Write	900 ms
Standard transaction	Monitoring register 450...539	200 ms	900 ms
Others		1,000 ms	3,000 ms

**NOTE:** All connections and I/O scanning line should not exceed limit of 500 registers per second for one LTMR controller. Each PLC have their own data connection limits and register per second limit. I/O scanning table should not be build only considering the LTMR controller performance but also the PLC bandwidth.

**Example for a Stable I/O Scanning**

Example 1: For a large site with 150 LTMR controllers and PLC connection at 3,400 Words: Per LTMR: 10 read and 3 write, 200 registers per second.

Register Type	Registers	I/O Scan Period	Health Timeout
Mirroring register 2500...2505 Register 2506...2508	6 read 3 write	50 ms	900 ms
Monitoring register 450...539	4 read	200 ms	900 ms

Example 2: Small site with less than 50 LTMR controllers and PLC connection at 3,400 Words: Per LTMR: 30 read and 3 write, 250 registers per second.

Register Type	Registers	I/O Scan Period	Health Timeout
Mirroring register 2500...2505 Register 2506...2508	6 read 3 write	50 ms	900 ms
Monitoring register 450...539	20 read	300 ms	900 ms
Statistics register 100...149	4 read	1,000 ms	3,000 ms

## Section 3.3

### Using the EtherNet/IP Communication Protocol

#### Overview

This section describes how to use the controller over an EtherNet/IP communication protocol network.

#### WARNING

##### LOSS OF CONTROL

- The designer of any control scheme must consider the potential failure modes of control paths and, for certain critical functions, provide a means to achieve a safe state during and after a path failure. Examples of critical control functions are emergency stop and overtravel stop.
- Separate or redundant control paths must be provided for critical control functions.
- System control paths may include communication links. Consideration must be given to the implications of anticipated transmission delays or failures of the link.<sup>(1)</sup>
- Each implementation of an LTMR controller must be individually and thoroughly tested for proper operation before being placed into service.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

(1) For additional information, refer to NEMA ICS 1.1 (latest edition), "Safety Guidelines for the Application, Installation, and Maintenance of Solid State Control".

#### WARNING

##### UNEXPECTED RESTART OF THE MOTOR

Check that the PLC application software:

- Considers the change from local to remote control,
- Manages appropriately the motor control commands during those changes.

When switching to the Network control channels, depending on the communication protocol configuration, the LTMR controller can take into account the latest known state of the motor control commands issued from the PLC and restart automatically the motor.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

#### What Is in This Section?

This section contains the following topics:

Topic	Page
EtherNet/IP Protocol Principles	59
Connections and Data Exchange	60
Device Profiles and EDS Files	61
Object Dictionary	62
Identity Object	63
Message Router Object	65
Assembly Object	67
Connection Manager Object	72
TCP/IP Object	74
Ethernet Link Object	76
Control Supervisor Object	78
Overload Object	81
Periodically Kept Acyclic Words (PKW) Objects	83
TeSys T Monitoring Control Object	86
EtherNet/IP Interface Diagnostic Object	87
I/O Connection Diagnostic Object	90

Topic	Page
Explicit Connection Diagnostic Object	92
Explicit Connection Diagnostic List Object	93

## EtherNet/IP Protocol Principles

### Overview

EtherNet/IP is an application layer protocol treating devices on the network as a series of objects. It is an implementation of the common industrial protocol (CIP) over TCP/IP.

The network carries control data and the properties of the device being controlled. It enables you to operate either in a client/server mode or a peer-to-peer mode.

Two main types of messages can be exchanged:

- I/O messaging, dedicated to fast exchanges of process data.
- Explicit messaging, dedicated to slower exchanges such as configuration, settings, or diagnostics data.

## Connections and Data Exchange

### I/O Messaging

I/O messages contain application-specific data. They are communicated across single or multicast connections between an application producer and its corresponding consuming application. Because I/O messages carry time-critical messages, they have high-priority identifiers.

An I/O Message consists of a Connection ID and associated I/O data. The meaning of the data within an I/O Message is implied by the associated Connection ID. The connection endpoints are assumed to have knowledge of the intended use or meaning of the I/O Message.

### Connection ID

Connection ID is the identifier assigned to a transmission that is associated with a particular connection between producers and consumers that identifies a specific piece of an application information.

### I/O Message Types

Slave devices are configured to produce a cyclic I/O message.

They produce their data at a precisely defined interval. This type of I/O messaging enables to configure the system to produce data at a rate appropriate for the application. Depending on the application, this can reduce the amount of traffic on the wire and more efficiently use the available bandwidth.

The following connections are defined:

ID	Name	Output Assembly	Input Assembly
1	Basic Overload	Instance 2	Instance 50
2	Extended Overload	Instance 2	Instance 51
3	Basic Motor Starter	Instance 3	Instance 52
4	Extended Contactor	Instance 4	Instance 53
5	Extended Motor Starter 1	Instance 4	Instance 54
6	Extended Motor Starter 2	Instance 5	Instance 54
7	LTMR Control and Monitoring	Instance 100	Instance 110
8	PKW	Instance 101	Instance 111
9	PKW and Extended Motor Starter	Instance 102	Instance 112
10	PKW and LTM1 Management	Instance 103	Instance 113
11	E_TeSys T Fast Access	Instance 105	Instance 115
12	EIOS_TeSys T	Instance 106	Instance 116

### Explicit Messaging

Explicit messaging connections provide multipurpose point-to-point communication paths between two particular devices. Explicit messages are used to command the performance of a particular task and to report the results of performing the task. You can, therefore, use explicit messaging connections to configure nodes and diagnose problems.

### RPI Parameter

The Request Packet Interval (RPI) parameter defines the rate at which a remote device periodically sends its data.

In daisy chain, adapt RPI value according to number of information exchanged per device and number of devices connected:

- With five devices connected, the RPI value is 30 ms for five devices in Basic Overload profile selected (value is calculated with M340 and NOC card (BMX NOC0401)).
- With 16 devices connected, the RPI value is 80 ms for 16 devices in Basic Overload profile selected (value is calculated with M340 and NOC card (BMX NOC0401)).

## Device Profiles and EDS Files

### Device Profiles

EtherNet/IP's device models define the physical connections and promote interoperability among standard devices.

Devices that implement the same device model must support common identity and communications status data. Device-specific data is contained in *device profiles* that are defined for various device types.

Typically, a device profile defines the device's:

- Object model
- I/O data format
- Configurable parameters

The above information is made available to other vendors through the device's EDS (electronic data sheet).

For a full description of the objects in the LTMR device profile, refer to LTMR Object Dictionary ([see page 62](#)).

### What is an EDS?

The EDS is a standardized ASCII file that contains information about a network device's communications functionalities and the contents of its object dictionary ([see page 62](#)), as defined by ODVA (Open EtherNet/IP Vendor Association). The EDS also defines device-specific and manufacturer-specific objects.

Using the EDS, you can use standardized tools to:

- Configure EtherNet/IP devices
- Design networks for EtherNet/IP devices
- Manage project information on different platforms

The parameters of a particular device depend on those objects (parameter, application, communications, emergency, and other objects) that reside on the device.

### LTMR Controller EDS Files

EDS files and associated icons that describe the various configurations of the LTMR controller can be downloaded from [www.schneider-electric.com](http://www.schneider-electric.com) website (Products and Services > Automation and Control > Product offers > Motor Control > TeSys T > Downloads > Software/Firmware > EDS&GSD).

EDS files and icons are grouped in a single compressed Zip file that you must unzip to a single directory on your hard disk drive.

### Selection Criteria for TeSys T LTMR Controller Variants

There are four EDS files corresponding to the four possible configurations of the TeSys T Motor Management Controller system:

Choose...	When You Want to Use...
SE TeSys T MMC L EIP	A TeSys T Motor Management Controller system without an expansion module, configurable via the HMI port. This variant enables you to preserve your local configuration.
SE TeSys T MMC L EV40 EIP	A TeSys T Motor Management Controller system with expansion module, configurable via the HMI port. This variant enables you to preserve your local configuration.
SE TeSys T MMC R EIP	A TeSys T Motor Management Controller system without expansion module configurable via the network.
SE TeSys T MMC R EV40 EIP	A TeSys T Motor Management Controller system with expansion module configurable via the network.

In **local** configuration mode, the parameter Config via Network Port Enable must be disabled. This mode preserves the local configuration made using the LTMCU or SoMove with the TeSys T DTM through the HMI port and prevents PLC configuration via the network.

In **remote** configuration mode the parameter Config via Network Port Enable must be enabled. This enables the PLC to remotely configure the LR controller.

**NOTE:** The parameters overwritten by the PLC will be lost. Remote mode is useful when replacing faulty devices.

The Config via Network Port Enable parameter is set by default.

## Object Dictionary

### Overview

The EtherNet/IP protocol is used for object modeling. Object modeling organizes related data and procedures into one entity: the object.

An object is a collection of related services and attributes. Services are procedures an object performs. Attributes are characteristics of objects represented by values, which can vary. Typically, attributes provide status information or govern the operation of an object. The value associated with an attribute may or may not affect the behavior of an object. An object's behavior is an indication of how the object responds to particular events.

Objects within a class are called object instances. An object instance is the actual representation of a particular object within a class. Each instance of a class has the same set of attributes, but has its own set of attribute values, which makes each instance in the class unique. The Object Dictionary describes the attribute values of each object in the device profile.

### LTMR Object Dictionary

The general breakdown of the LTMR Ethernet brick object dictionary is the same for all EtherNet/IP devices:

Class Code	Object	Description
0x01	Identity Object	Identifiers, such as device type, vendor ID, and serial number.
0x02	Message Router Object	Provides a message connection point.
0x04	Assembly Object	Provides collection of other object's attributes (frequently used for I/O messaging).
0x06	Connection Manager Object	Provides for and manages the run-time exchange of messages.
0x64 - 0x96	Communication Variables	Provides the details of the communication variables.
0xF5	TCP/IP Object	Provides description of an opened explicit connection and associated communicator.
0xF6	Ethernet link Object	Manages the functionality of the physical attachment to the Ethernet network.
0x29	Control Supervisor Object	Manages controller functions, operational states, and control.
0x2C	Overload Object	Implements overload behavior.
0xC5	Periodically Kept Acyclic Words (PKW) Object	Enables cyclic I/O messaging for manufacturer-specific registers.
0xC6	EtherNet/IP Monitoring Object	Used to select monitoring data available on Assembly 110.
0x350	EtherNet/IP Interface Diagnostic Object	Provides an overall diagnostic of the EIP communication of the EIP Interface of a device.
0x352	I/O Connection Diagnostic Object	Provides the detailed diagnostic of each configured CIP I/O connection viewed from a scanner, and of each opened CIP I/O connection viewed from an adapter.
0x353	Explicit Connection Diagnostic Object	Provides a description of an opened Explicit Connection and associated communication.
0x354	Explicit Connection Diagnostic List Object	Provides a snapshot of the list of instantiated "Explicit Connection Diagnostic" objects.

These objects are described in detail in the following pages.

## Identity Object

### Description

This object, present in all EtherNet/IP products, provides identification of, and general information about, the device.

### Class Code

The class code is 0x01 as defined by CIP.

### Class Attributes

Attribute ID	Name	Access	Description
0x01	Revision	R	The Identity objects implementation revision. Returns 0x01.
0x02	Max Instance	R	The largest instance number. Returns 0x01.
0x03	Number of Instances	R	The number of object instances. Returns 0x01.
0x04	Optional Instance Attribute List	R	Not supported
0x06	Max Class Attribute	R	The largest class attributes value. Returns 0x07.
0x07	Max Instance Attribute	R	The largest instance attributes value. Returns 0x07.

### Class Services

Service Code	Name	Description
0x01	Get Attribute All	Returns the value of all class attributes.
0x0E	Get Attribute Single	Returns the value of the specified attribute.

### Instance Codes

Only one instance is implemented.

### Instance Attributes

Attribute ID	Name	Access	Description
0x01	Vendor ID	R	Vendor ID (243: Schneider Electric)
0x02	Device Type	R	Motor starter profile (22)
0x03	Device Code	R	TeSys T EtherNet/IP code: <ul style="list-style-type: none"> <li>● 48: LTMR in Remote configuration mode</li> <li>● 49: LTMR and LTMEV40 in Remote configuration mode</li> <li>● 304: LTMR in Local configuration mode</li> <li>● 305: LTMR and LTMEV40 in Local configuration mode</li> </ul>
0x04	Identity Revision	R	Product version. product communication version
0x05	Identity Status	R	Current status of the device
0x06	Device Serial Number	R	Based on device entity and MAC: <ul style="list-style-type: none"> <li>● 0x20: Byte 0 (Entity ID for TeSys T)</li> <li>● Bytes 1-3: Last 3 bytes of MAC address</li> </ul>
0x07	Product Name	R	Commercial reference

**Instance Services**

<b>Service Code</b>	<b>Name</b>	<b>Description</b>
0x01	Get Attribute All	Returns the value of all instance attributes with the access type of R.
0x05	Reset	Emulates device reset (only 0-1 are supported).
0x0E	Get Attribute Single	Returns the value of the specified identity attribute with the access type of R.

## Message Router Object

### Description

The Message Router Object provides a messaging connection point through which a Client may address a service to any object class or instance in the physical device.

### Class Code

The Class code is 0x02 as defined by CIP.

### Class Attributes

Attribute ID	Name	Access	Description
0x01	Revision	R	The Message Router Object implementation revision. Returns 0x01.
0x02	Max Instance	R	The largest instance number. Returns 0x01.
0x03	Number of Instances	R	The number of object instances. Returns 0x01.
0x04	Optional Attribute List	R	The number and list of the optional attributes. The first word contains the number of attributes to follow and every word that follows contains another attribute code. You can include the Current Packets per Second and Total Traffic attributes from the EtherNet/IP Statistics section in this list. For more details, see the instance attributes ( <a href="#">see page 65</a> ).
0x05	Optional Service List	R	The number and list of any implemented optional services. Only the Multiple Service request (0x0A) is supported for now.
0x06	Max Class Attribute	R	The largest Class Attribute value. Returns 0x07.
0x07	Max Instance Attribute	R	The largest Instance Attribute value. Returns 0x77.

### Class Services

Service Code	Name	Description
0x01	Get Attribute All	Returns the value of all class attributes.
0x0E	Get Attribute Single	Returns the value of the specified attribute.

### Instance Codes

Only one instance is implemented.

### Instance Attributes

Attribute ID	Name	Access	Description
0x01	Implemented Object List	R	Implemented Object list. The first two bytes contain the number of implemented objects. In the following list of objects, every two bytes represent another implemented class number: <ul style="list-style-type: none"><li>● Identity</li><li>● Message Router</li><li>● Assembly</li><li>● Connection Manager</li><li>● QoS</li><li>● TCP/IP</li><li>● Ethernet Link</li><li>● Control Supervisor</li><li>● Overload</li><li>● PKW</li><li>● KMC</li></ul>
0x02	Max Connection Number Supported	R	Maximum number of concurrent CIP (Class 1 or Class 3) connections supported. Returns 32.
0x64	Total incoming Class 1 packets received during the last second	R	Total number of incoming packets received for all implicit (Class 1) connections during the last second.

Attribute ID	Name	Access	Description
0x65	Total outgoing Class 1 packets sent during the last second	R	Total number of outgoing packets sent for all implicit (Class 1) connections during the last second.
0x66	Total incoming Class 3 packets received during the last second	R	Total number of incoming packets for all explicit (Class 3) connections during the last second.
0x67	Total outgoing Class 3 packets sent during the last second	R	Total number of Class 3 packets sent for all explicit connections.
0x68	Total incoming unconnected packets received during the last second	R	Total number of incoming unconnected packets received during the last second.
0x69	Total outgoing unconnected packets sent during the last second	R	Total number of unconnected responses sent during the last second.
0x6A	Total incoming EtherNet/IP packets received during the last second	R	Total unconnected, Class 1, or Class 3 packets received during the last second.
0x6B	Total outgoing EtherNet/IP packets sent during the last second	R	Total unconnected, Class 1, or Class 3 packets sent during the last second.
0x6C	Total incoming Class 1 packets received	R	Total number of incoming packets received for all implicit (Class 1) connections.
0x6D	Total outgoing Class 1 packets sent	R	Total number of outgoing packets sent for all implicit (Class 1) connections.
0x6E	Total incoming Class 3 packets received	R	Total number of incoming packets for all explicit (Class 3) connections. This number includes the packets that would return with a detected error (listed in the next two rows).
0x6F	Total incoming Class 3 packets Invalid Parameter Value	R	Total number of incoming Class 3 packets that targeted not supported service/class-instance/attribute/member.
0x70	Total incoming Class 3 packets invalid format	R	Total number of incoming Class 3 packets that had an invalid format.
0x71	Total outgoing Class 3 packets sent	R	Total number of packets sent for all explicit (Class 3) connections.
0x72	Total incoming unconnected packets received	R	Total number of incoming unconnected packets. This number includes the packets that returns with a detected error (listed in the next two rows).
0x73	Total incoming unconnected packets Invalid Parameter Value	R	Total number of incoming unconnected packets that targeted not supported service/class-instance/attribute/member.
0x74	Total incoming unconnected packets Invalid Format	R	Total number of incoming unconnected packets that had an invalid format.
0x75	Total outgoing unconnected packets sent	R	Total number of all unconnected packets sent.
0x76	Total incoming EtherNet/IP packets	R	Total unconnected, Class 1 or Class 3 packets received.
0x77	Total outgoing EtherNet/IP packets	R	Total unconnected, Class 1 or Class 3 packets sent.

### Instance Services

Service Code	Name	Description
0x01	Get Attribute All	Returns the value of all instance attributes.
0x0A	Multiple Service	Provides an option to execute the Multiple Service request.
0x0E	Get Attribute Single	Returns the value of the specified instance attribute.

## Assembly Object

### Description

The Assembly Object binds attribute of multiple objects, which enables each object's data to be sent or received over a single connection. Assembly objects can be used to bind input data or output data. The terms "input" and "output" are defined from the network's point of view. An input sends (produces) data on the network, and an output receives (consumes) data from the network.

Only static assemblies are supported.

### Class Code

The class code is 0x04 as defined by CIP.

### Class Attributes

Attribute ID	Name	Access	Description
0x01	Revision	R	The revision of this CIP Object. Returns 0x02.
0x02	Max Instance	R	The maximum numeric value of the instance number. Returns 116.
0x03	Number of Instances	R	The number of supported assembly instances. Returns 21.
0x04	Optional Attribute List	R	The number and list of the optional attributes. The first word contains the number of attributes to follow and every word that follows contains another attribute code. One optional attribute is supported ((ASSEMBLY_INSTANCE_SIZE (4)).
0x06	Max Class Attribute	R	The numeric value of the highest class attributes (7).
0x07	Max Instance Attribute	R	The numeric value of the highest instance attributes (4).

### Class Services

Service Code	Name	Description
0x0E	Get Attribute Single	Returns the value of the specified attribute.

### Instance Codes

Only one instance of the class, 0x04 is supported

### Instance Attributes

Attribute ID	Name	Access	Description
0x01	Number of members	R	Number of members in this instance returned in a word value. Not supported.
0x02	Assembly_Member_List	R/W	Array of Structures where each structure represents one member and consists of data size, path size, and path of that member. Not supported.
	Assembly_Member_Data_Size		A word containing the member data size in bits.
	Assembly_Member_Path_Size		A word containing the byte size of the EPATH to follow. 0 for the unused space between the members.
	Assembly_Member_Path		EPATH representing the member. For example, "20 04 24 65 30 03 28 01" for the member 1 of the instance 101.
0x03	Assembly_Instance_Data	R/W	Instance data returned as an array of bytes. Access is Read Only for the input data assemblies and Read/Write for the output data assemblies.
0x04	Instance Data Size	R	A word representing the instance data size in bytes.

**NOTE:**

- Setting Member List (attribute 2) is not supported for static assembly as the static assembly members are created at the startup depending on the personality/host assembly map and cannot be changed at runtime.
- Setting Instance Data (attribute 3) is not supported for producing assembly instance (input assembly).

**Instance Services**

Service Code	Name	Description
0x0E	Get Attribute Single	Returns the value of the specified attribute.
0x10	Set Attribute Single	Modifies an assembly object instance attribute value.

**Output Assembly Data****Instance 2: Basic Overload**

Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Reserved	Reserved	Reserved	Reserved	Reserved	FaultReset	Reserved	Reserved

**Instance 3: Basic Motor Starter**

Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Reserved	Reserved	Reserved	Reserved	Reserved	FaultReset	Reserved	Run 1

**Instance 4: Extended Contactor**

Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Reserved	Reserved	Reserved	Reserved	Reserved	Reserved	Run 2	Run 1

**Instance 5: Extended Motor Starter**

Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Reserved	Reserved	Reserved	Reserved	Reserved	Reserved	Run 2	Run 1

**NOTE:** FaultReset, Run1, and Run2 are commands in the Control register 1.

**Instance 100: LTMR Control Registers**

This assembly contains several control registers commonly used with an LTMR device.

Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5
path: 6C : 01 : 05 (Register 704)			path: 6C : 01 : 04 (Register 703)		
LSB (least significant bit)			MSB (most significant bit)	LSB	MSB

**Instance 101: PKW Request Object**

This assembly is vendor-specific. It is used to implement the request object of PKW protocol.

Byte 7	Byte 6	Byte 5	Byte 4	Byte 3	Byte 2	Byte 1	Byte 0
See PKW ( <a href="#">see page 83</a> ) for details.							

**Instance 102: PKW Request and Extended Motor Starter**

This assembly is vendor-specific.

Bytes 0 to 7	Byte 8	Byte 9
See Instance 101 above.	Reserved (value=0)	See Instance 5 above.

**Instance 103: PKW Request and LTMR Control Registers**

This assembly is vendor-specific.

Bytes 0 to 7	Byte 8 to 13
See Instance 101 above.	See Instance 100 above.

**Instance 105: E\_TeSys T FastAccess Output**

This assembly is vendor-specific. All registers are in little endian.

Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5
path: 8C : 01 : 07 (Register 2506)		path: 8C : 01 : 08 (Register 2507)		path: 8C : 01 : 09 (Register 2508)	

**Instance 106: EIOS\_TeSys T Output**

This assembly is vendor-specific. All registers are in little endian.

Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5
path: 6C : 01 : 01 (Register 700)		path: 6C : 01 : 02 Reserved (value = 0)		path: 6C : 01 : 03 Reserved (value = 0)	

Byte 6	Byte 7	Byte 8	Byte 9
path: 6C : 01 : 04 Reserved (value = 0)		path: 6C : 01 : 05 (Register 704)	

**Input Assembly Data****Instance 50: Basic Overload**

Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Reserved	Faulted/Trip						

**Instance 51: Extended Overload**

Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Reserved	Reserved	Reserved	Reserved	Reserved	FaultReset	Warning	Faulted/Trip

**Instance 52: Basic Motor Starter**

Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Reserved	Reserved	Reserved	Reserved	Reserved	Running1	Reserved	Faulted/Trip

**Instance 53: Extended Motor Starter 1**

Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Reserved	Reserved	CntrlfromNet	Ready	Reserved	Running1	Warning	Faulted/Trip

**Instance 54: Extended Motor Starter 2**

Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Reserved	Reserved	CntrlfromNet	Ready	Running2	Running1	Warning	Faulted/Trip

**NOTE:** The instances contain data processed from the System status register 1 and the Control register 1:

- CntrlfromNet = NOT In remote (status bit)
- Ready = System ready (status bit)
- Running2 = Motor running (status bit) AND Motor run reverse command (control bit)
- Running1 = Motor running (status bit) AND Motor run forward command (control bit)
- Warning = System warning (status bit)
- Fault/Trip = System fault (status bit) OR System tripped (status bit)

**Instance 110: LTMR Monitoring Registers (with dynamic configuration)**

This assembly contains several monitorings registers commonly used with an LTMR device. You can choose registers by setting 1...3 attributes of TeSys T Monitoring Control Object. See TeSys T Monitoring and Control Object ([see page 86](#)) for more information.

Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7
Register pointed using path: C6 : 01 : 05	Register pointed using path: C6: 01 : 06	Register pointed using path: C6 : 01 : 07	Register pointed using path: C6 : 01 : 08				
LSB	MSB	LSB	MSB	LSB	MSB	LSB	MSB

**Instance 111: PKW Response Object**

This assembly is vendor-specific. It is used to implement the response object of PKW protocol.

Byte 7	Byte 6	Byte 5	Byte 4	Byte 3	Byte 2	Byte 1	Byte 0
See PKW ( <a href="#">see page 83</a> ) for details.							

**Instance 112: PKW Request and Extended Motor Starter**

This assembly is vendor-specific.

Bytes 0 to 7	Byte 8	Byte 9
See Instance 111 above.	Reserved (value=0)	See Instance 54 above.

**Instance 113: PKW Request and LTMR Monitoring Registers**

This assembly is vendor-specific.

Bytes 0 to 7	Byte 8 to 15
See Instance 111 above.	See Instance 110 above.

**Instance 115: E\_TeSys T FastAccess Input**

This assembly is vendor-specific. All registers are in little endian.

Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5
path: 8C : 01 : 01 (Register 2500)		path: 8C : 01 : 02 (Register 2501)		path: 8C : 01 : 03 (Register 2502)	

Byte 6	Byte 7	Byte 8	Byte 9	Byte 10	Byte 11
path: 8C : 01 : 04 (Register 2503)		path: 8C : 01 : 05 (Register 2504)		path: 8C : 01 : 06 (Register 2505)	

**Instance 116: EIOS\_TeSys T Input**

This assembly is vendor specific. All registers are in little endian.

Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7
path: 68 : 01 : 02 (Register 451)		path: 68 : 01 : 03 (Register 452)		path: 68 : 01 : 04 (Register 453)		path: 68 : 01 : 05 (Register 454)	

Byte 8	Byte 9	Byte 10	Byte 11	Byte 12	Byte 13	Byte 14	Byte 15
path: 68 : 01 : 06 (Register 455)		path: 68 : 01 : 07 (Register 456)		path: 68 : 01 : 08 (Register 457)		path: 68 : 01 : 09 (Register 458)	

Byte 16	Byte 17	Byte 18	Byte 19	Byte 20	Byte 21	Byte 22	Byte 23
path: 68 : 01 : 0A (Register 459)		path: 68 : 01 : 0B (Register 460)		path: 68 : 01 : 0C (Register 461)		path: 68 : 01 : 0D (Register 462)	

Byte 24	Byte 25	Byte 26	Byte 27	Byte 28	Byte 29	Byte 30	Byte 31
path: 68 : 01 : 0E (Register 463)		path: 68 : 01 : 0F (Register 464)		path: 68 : 01 : 10 (Register 465)		path: 68 : 01 : 11 (Register 466)	

Byte 32	Byte 33	Byte 34	Byte 35	Byte 36	Byte 37	Byte 38	Byte 39
path: 68 : 01 : 12 (Register 467)		path: 68 : 01 : 13 (Register 468)		path: 68 : 01 : 14 (Register 469)		path: 68 : 01 : 15 (Register 470)	

Byte 40	Byte 41	Byte 42	Byte 43	Byte 44	Byte 45	Byte 46	Byte 47
path: 68 : 01 : 16 (Register 471)		path: 68 : 01 : 17 (Register 472)		path: 68 : 01 : 18 (Register 473)		path: 68 : 01 : 19 (Register 474)	

<b>Byte 48</b>	<b>Byte 49</b>	<b>Byte 50</b>	<b>Byte 51</b>	<b>Byte 52</b>	<b>Byte 53</b>	<b>Byte 54</b>	<b>Byte 55</b>
path: 68 : 01 : 1A (Register 475)		path: 68 : 01 : 1B (Register 476)		path: 68 : 01 : 1C (Register 477)		path: 68 : 01 : 1D (Register 478)	

<b>Byte 56</b>	<b>Byte 57</b>	<b>Byte 58</b>	<b>Byte 59</b>	<b>Byte 60</b>	<b>Byte 61</b>	<b>Byte 62</b>	<b>Byte 63</b>
path: 68 : 01 : 1E (Register 479)		path: 68 : 01 : 1F (Register 480)		path: 68 : 01 : 20 (Register 481)		path: 68 : 01 : 21 (Register 482)	

<b>Byte 64</b>	<b>Byte 65</b>	<b>Byte 66</b>	<b>Byte 67</b>	<b>Byte 68</b>	<b>Byte 69</b>	<b>Byte 70</b>	<b>Byte 71</b>
path: 68 : 01 : 22 (Register 483)		path: 68 : 01 : 23 (Register 484)		path: 68 : 01 : 24 (Register 485)		path: 68 : 01 : 25 (Register 486)	

<b>Byte 72</b>	<b>Byte 73</b>	<b>Byte 74</b>	<b>Byte 75</b>	<b>Byte 76</b>	<b>Byte 77</b>	<b>Byte 78</b>	<b>Byte 79</b>
path: 68 : 01 : 26 (Register 487)		path: 68 : 01 : 27 (Register 488)		path: 68 : 01 : 28 (Register 489)		path: 68 : 01 : 29 (Register 490)	

<b>Byte 80</b>	<b>Byte 81</b>	<b>Byte 82</b>	<b>Byte 83</b>	<b>Byte 84</b>	<b>Byte 85</b>	<b>Byte 86</b>	<b>Byte 87</b>
path: 68 : 01 : 2A (Register 491)		path: 68 : 01 : 2B (Register 492)		path: 68 : 01 : 2C (Register 493)		path: 68 : 01 : 2D (Register 494)	

<b>Byte 88</b>	<b>Byte 89</b>	<b>Byte 90</b>	<b>Byte 91</b>	<b>Byte 92</b>	<b>Byte 93</b>	<b>Byte 94</b>	<b>Byte 95</b>
path: 68 : 01 : 2E (Register 495)		path: 68 : 01 : 2F (Register 496)		path: 68 : 01 : 30 (Register 497)		path: 68 : 01 : 31 (Register 498)	

<b>Byte 96</b>	<b>Byte 97</b>	<b>Byte 98</b>	<b>Byte 99</b>	<b>Byte 100</b>	<b>Byte 101</b>	<b>Byte 102</b>	<b>Byte 103</b>
path: 68 : 01 : 32 (Register 499)		path: 68 : 01 : 33 (Register 500)		path: 68 : 01 : 34 (Register 501)		path: 68 : 01 : 35 (Register 502)	

<b>Byte 104</b>	<b>Byte 105</b>	<b>Byte 106</b>	<b>Byte 107</b>	<b>Byte 108</b>	<b>Byte 109</b>	<b>Byte 110</b>	<b>Byte 111</b>
path: 68 : 01 : 36 (Register 503)		path: 68 : 01 : 37 (Register 504)		path: 68 : 01 : 38 (Register 505)		path: 68 : 01 : 39 (Register 506)	

<b>Byte 112</b>	<b>Byte 113</b>	<b>Byte 114</b>	<b>Byte 115</b>	<b>Byte 116</b>	<b>Byte 117</b>	<b>Byte 118</b>	<b>Byte 119</b>
path: 68 : 01 : 3A (Register 507)		path: 68 : 01 : 3B (Register 508)		path: 68 : 01 : 3C (Register 509)		path: 68 : 01 : 3D (Register 510)	

<b>Byte 120</b>	<b>Byte 121</b>	<b>Byte 122</b>	<b>Byte 123</b>	<b>Byte 124</b>	<b>Byte 125</b>	<b>Byte 126</b>	<b>Byte 127</b>
path: 68 : 01 : 3E (Register 511)		path: 68 : 01 : 3F (Register 512)		path: 68 : 01 : 40 (Register 513)		path: 68 : 01 : 41 (Register 514)	

## Connection Manager Object

### Description

The Connection Object provides for and manages the run-time exchange of messages.

### Class Code

The Class code is 0x06 as defined by CIP.

### Class Attributes

Attribute ID	Name	Access	Description
0x01	Revision	R	The connection manager implementation revision. Returns 0x01.
0x02	Max Instance	R	The largest instance number. Returns 0x01.
0x03	Number of Instances	R	The number of object instances. Returns 0x01.
0x04	Optional Attribute List	R	The number and list of the optional attributes. The first word contains the number of attributes to follow and every word that follows contains another attribute code. Following optional attributes are included in this list: <ul style="list-style-type: none"> <li>• Total number of incoming connection open requests.</li> <li>• The number of incoming connection open requests rejected because of the unexpected format of the Forward Open.</li> <li>• The number of incoming connection open requests rejected because of the insufficient resources.</li> <li>• The number of incoming connection open requests rejected because of the parameter value sent with the Forward Open.</li> <li>• The number of Forward Close requests received.</li> <li>• The number of Forward Close requests with invalid format.</li> <li>• The number of Forward Close requests that could not be matched to an active connection.</li> <li>• The number of connections that has timed out because the other side stopped producing or there was a network interruption.</li> </ul>
0x06	Max Class Attribute	R	The largest class attributes value. Returns 0x07.
0x07	Max Instance Attribute	R	The largest instance attributes value. Returns 0x08.

### Class Services

Service Code	Name	Description
0x01	Get Attribute All	Returns the value of all class attributes.
0x0E	Get Attribute Single	Returns the value of the specified attribute.

### Instance Codes

Only one instance is implemented.

### Instance Attributes

Attribute ID	Name	Access	Description
0x01	Incoming Forward Open requests count	R/W	Total number of incoming connection open requests.
0x02	Forward Open Format Failure count	R/W	The number of Forward Open requests rejected because of the unexpected format of the Forward Open request.
0x03	Forward Open Resource Failure count	R/W	The number of Forward Open requests rejected because of insufficient resources.
0x04	Forward Open Parameter Value count	R/W	The number of Forward Open requests rejected because of the parameter value sent with Forward Open.
0x05	Incoming Forward Close requests count	R/W	Total number of incoming connection close requests.

Attribute ID	Name	Access	Description
0x06	Forward Close Format Failure count	R/W	The number of Forward Close requests that has invalid format.
0x07	Forward Close Matching Failure count	R/W	The number of Forward Close requests that could not be matched to an active connection.
0x08	Timed out Connections count	R/W	The number of connections that has timed out because the other side stopped producing or there was a network interruption.

### Instance Services

Service Code	Name	Description
0x01	Get Attribute All	Returns the value of all instance attributes.
0x02	Set Attribute All	Sets the values of all instance attributes.
0x0E	Get Attribute Single	Returns the value of the specified instance attribute.
0x10	Set Attribute Single	Sets the value of the specified instance attribute.
0x4E	Forward Close	Closes an existing connection.
0x52	Unconnected Send	Used to send a multi-hop not connected request.
0x54	Forward Open	Opens a new connection.
0x5A	Get Connection Server	Returns the owner information for the specified connection.
0x5B	Large Forward Open	Opens a new connection with maximum size buffer.

## TCP/IP Object

### Description

This object provides description of an opened explicit connection and associated communicator.

### Class Code

The Class code is 0xF5 as defined by CIP.

### Class Attributes

Attribute ID	Name	Access	Description
0x01	Revision	R	The TCP/IP objects implementation revision. Returns 0x03.
0x02	Max Instance	R	Indicate that there is only one host IP address. Returns 0x01.
0x03	Number of Instances	R	The number of object instances. Returns 0x01.
0x04	Optional Instance Attribute List	R	The first two bytes contain the number of optional instance attributes. Each byte pair that follows represents the number of a different optional instance attribute. Not supported.
0x06	Max Class Attribute	R	The largest class attribute value. Returns 0x07.
0x07	Max Instance Attribute	R	The largest instance attribute value. Returns 0x06.

### Class Services

Service Code	Name	Description
0x01	Get Attribute All	Returns the value of all class attributes
0x0E	Get Attribute Single	Returns the value of the specified attribute.

### Instance Codes

Only one instance is implemented.

### Instance Attributes

Attribute ID	Name	Access	Description
0x01	Configuration Status	R	Indicates whether you configured TCP/IP object and its parameters or not.
0x02	Configuration Capability	R	Indicates whether TCP/IP object with all parameters can be configured using DHCP or BOOTP, and whether it can resolve the host names using the DNS server. Returns 0x00000025. BootP client DHCP client Hardware configurable
0x03	Configuration Control	R	Indicates the configuration of device on startup, that is, the first attempt initiated. This returns the following values: <ul style="list-style-type: none"> <li>● 0: To use stored IP address.</li> <li>● 1: To attempt the BootP first.</li> <li>● 2: To use the DHCP attempt first.</li> </ul>
0x04	Physical Link	R	Returns electronic path to the physical link object, which is the Ethernet Link class. The first word contains the size of the EPATH in words. The path that follows specifies instance 1 of the Ethernet Link object (0x20 0xF6 0x24 0x01).

Attribute ID	Name	Access	Description
0x05	Configuration Parameters	R	<p>TCP/IP parameters including the following:</p> <ul style="list-style-type: none"> <li>● DWORD containing the device IP address.</li> <li>● DWORD containing the subnet mask.</li> <li>● DWORD containing the gateway address.</li> <li>● DWORD containing the name server IP address.</li> <li>● DWORD containing the second name server IP address.</li> <li>● WORD containing number of ASCII characters in the domain name.</li> <li>● ASCII string which contains the domain name.</li> </ul>
0x06	Host Name	R	<p>The first word contains the number of ASCII bytes in the device host name. The ASCII host name string follows.</p> <p>Returns the product name as the identity object.</p>

### Instance Services

Service Code	Name	Description
0x01	Get Attribute All	Returns the value of all instance attributes
0x0E	Get Attribute Single	Returns the value of the specified instance attribute.

## Ethernet Link Object

### Description

This object provides the characteristics for each Ethernet links of the product.

### Class Code

The Class code is 0xF6 as defined by CIP.

### Class Attributes

Attribute ID	Name	Access	Description
0x01	Revision	R	The Ethernet Link object implementation revision. Returns 0x03.
0x02	Max Instance	R	Returns 0x02 to represent two Ethernet port instances.
0x03	Number of Instances	R	The number of object instances. Returns 0x02 to represent two Ethernet port instances.
0x04	Optional Instance Attribute List	R	The first two bytes contain the number of optional instance attributes. Each byte pair that follows represents the number of a different optional instance attribute. Returns 0x07, 0x08, and 0x0A as 3 optional attributes.
0x06	Max Class Attribute	R	The largest class attribute value. Returns 0x07.
0x07	Max Instance Attribute	R	The largest instance attribute value. Returns 0x0A.

### Class Services

Service Code	Name	Description
0x01	Get Attribute All	Returns the value of all class attributes
0x0E	Get Attribute Single	Returns the value of the specified attribute.

### Instance Codes

Two instances are implemented for the Ethernet Link object. Each instance represents one of the two Ethernet ports.

### Instance Attributes

Attribute ID	Name	Access	Description
0x01	Interface Speed	R	Interface speed in Mbps (10 or 100 Mbps).
0x02	Interface Flags	R	Returns a word, where the bits are set depending on: <ul style="list-style-type: none"> <li>● Link state (active/inactive).</li> <li>● Negotiation state.</li> <li>● Link faults.</li> <li>● Full/half duplex connection type.</li> </ul> Duplex mode is reflected in bit 1.
0x03	MAC Address	R	Returns 6 bytes with the device MAC address. <ul style="list-style-type: none"> <li>● Port 1: Identical to device MAC address.</li> <li>● Port 2: Device MAC + 1.</li> </ul>
0x07	Interface Type	R	Indicates the type of interface, for example, twisted pair, fiber, internal. Returns 0x02 to indicate twisted fiber.
0x08	Interface State	R	Indicates the current state of the interface, for example, operational (0x01), disabled (0x02).
0x0A	Interface Label	R	Readable identification. <ul style="list-style-type: none"> <li>● Port 1: "Port 1"</li> <li>● Port 2: "Port 2"</li> </ul>

**Instance Services**

Service Code	Name	Description
0x01	Get Attribute All	Returns the value of all instance attributes.
0xE	Get Attribute Single	Returns the value of the specified instance attribute.

## Control Supervisor Object

### Description

This object models all the management functions for devices within the Hierarchy of Motor Control Devices.

### Class Code

The Class code is 0x29 as defined by CIP.

### Class Attributes

Attribute ID	Name	Access	Description
0x01	Revision	R	The Ethernet Link object implementation revision. Returns 0x01.
0x02	Max Instance	R	Returns 0x01 to represent a single instance.
0x03	Number of Instances	R	Returns 0x01 to represent a single instance.
0x06	Max Class Attribute	R	The largest class attribute value. Returns 0x07.
0x07	Max Instance Attribute	R	The largest instance attribute value. Returns 0x11.

### Class Services

Service Code	Name	Description
0x0E	Get Attribute Single	Returns the value of the specified attribute.

### Instance Codes

Only one instance is supported.

### Instance Attributes

Attribute ID	Name	Access	Description
0x03	Run 1	Get/Set	Motor run forward command
0x04	Run 2	Get/Set	Motor run reverse command
0x06	State	Get	0 = Vendor specific 1 = Startup 2 = Not ready 3 = Ready 4 = Enabled 5 = Stopping 6 = Fault stop 7 = Faulted
0x07	Running 1	Get	Motor running and Motor run forward command
0x08	Running 2	Get	Motor running and Motor run reverse command
0x09	Ready	Get	System ready
0x0A	Faulted	Get	System fault
0x0B	Warning	Get	System warning


Attribute ID	Name	Access	Description
0x0C	Fault Reset	Get/Set	Fault reset command
0x0D	Fault Code	Get	Fault code
0x0E	Warning Code	Get	Warning code
0x0F	Control from Network	Get	Control local
0x10	Fault Mode	Get	Action on loss of EtherNet/IP: 0 = Fault + Stop (Network port fallback setting NPTS = 2) 1 = Ignore (NPTS = 0) 2 = Manufacturer specific Signal following fallbacks: • Frozen (NPTS = 1) • Unchanged (NPTS = 3) • Force FW (NPTS = 4) • Force RV (NPTS = 5)

### Instance Service

Service Code	Name	Description
0x05	Reset	Resets the drive to the start-up state. <b>NOTE:</b> This service is not identical to Reset of the Identity object.
0x0E	Get Attribute Single	Returns the value of the specified instance attribute.
0x10	Set Attribute Single	Sets the value of the specified instance attribute.

### Control Supervisor State Event

The following diagram shows the control supervisor state event matrix:



The following table describes the run/stop event matrix:

Event	State (N/A = No Action)							
	Non-exist	Startup	Not_Ready	Ready	Enabled	Stopping	Fault-Stop	Faulted
Switch OFF	N/A	Transition to Non-exist	Transition to Non-exist	Transition to Non-exist	Transition to Non-exist	Transition to Non-exist	Transition to Non-exist	Transition to Non-exist
Switch ON	Transition to Startup	N/A	N/A	N/A	N/A	N/A	N/A	N/A
Initialization Complete	N/A	Transition to Not_Ready	N/A	N/A	N/A	N/A	N/A	N/A
Main Power ON	N/A	N/A	Transition to Ready	N/A	N/A	N/A	N/A	N/A
Run	N/A	N/A	N/A	Transition to Enable	N/A	Transition to Enable	N/A	N/A
Stop	N/A	N/A	N/A	N/A	Transition to Stopping	N/A	N/A	N/A
Stop Complete	N/A	N/A	N/A	N/A	N/A	Transition to Ready	N/A	N/A
Reset	N/A	N/A	Transition to Startup	Transition to Startup	Transition to Startup	Transition to Startup	Transition to Startup	Transition to Startup
Main Power OFF	N/A	N/A	N/A	Transition to Not Ready	Transition to Faulted	Transition to Faulted	Transition to Faulted	N/A
Fault Detected	N/A	Transition to Faulted	Transition to Faulted	Transition to Faulted	Transition to Fault_Stop	Transition to Fault_Stop	N/A	N/A
Fault_Stop Complete	N/A	N/A	N/A	N/A	N/A	N/A	Transition to Faulted	
Fault Reset	N/A	N/A	N/A	N/A	N/A	N/A	N/A	Transition to Not_Ready

Attribute 5 (NetCtrl) is used to request that Run Stop events be controlled from the network. You may inhibit these events, however, if you do not wish to allow Run Stop control from the network under certain circumstances, or if your application does not permit it. Only when attribute 15 (CtrlFromNet) is set to 1 by the device in response to a NetCtrl request, is Run Stop control actually enabled from the network.

If attribute 15 (CtrlFromNet) is 1, then the events Run and Stop are triggered by a combination of the Run1 and Run2 attributes, as shown in the following table. Note that Run1 and Run2 have different contexts for different device types.

The following table shows the Run1 and Run2 contexts for the devices within the motor control hierarchy:

Run	Drives and Servos
Run1	RunFwd
Run2	RunRev

If Control From Network is 0, Run and Stop events must be controlled using local input(s) provided by the vendor.

Run1	Run2	Trigger Event	Run Type
0	0	Stop	N/A
0 -> 1	0	Run	Run1
0	0 -> 1	Run	Run2
0 -> 1	0 -> 1	No action	N/A
1	1	No action	N/A
1 -> 0	1	Run	Run2
1	1 -> 0	Run	Run1

**NOTE:** Local stop and run signals could override or be interlocked with the run/stop control through Ethernet/IP.

## Overload Object

### Description

This object models all the functions specific to an AC motor overload protection device.

### Class Code

The Class code is 0x2C as defined by CIP.

### Class Attributes

Attribute ID	Name	Access	Description
0x01	Revision	R	The EtherNet link objects implementation revision. Returns 0x01.
0x02	Max Instance	R	Returns 0x01 to represent a single instance.
0x03	Number of Instances	R	Returns 0x01 to represent a single instance.
0x06	Max Class Attribute	R	The largest class attribute value. Returns 0x07.
0x07	Max Instance Attribute	R	The largest instance attribute value. Returns 0xB2.

### Class Service

Service Code	Name	Description
0x0E	Get Attribute Single	Returns the value of the specified attribute.

### Instance Codes

Only one instance is supported.

### Instance Attributes

Attribute ID	Name	Access	Description
0x01	Attribute count	R	Returns the supported attribute count (46).
0x02	Attribute list	R	Returns the list of supported instance attributes.
0x03	TripFLCSet	R/W	% of FLA max
0x04	TripClass	R/W	Trip Class Setting (0...200 s)
0x05	AvgCurrent	R	0.1 A
0x06	%PhImbal	R	% Phase imbalance
0x07	%Thermal	R	% Thermal capacity
0x08	IL1 Current	R	0.1 A
0x09	IL2 Current	R	0.1 A
0x0A	IL3 Current	R	0.1 A
0x0B	Ground Current	R	0.1 A
0x65	IL1 Current	R	0.1 A
0x66	IL2 Current	R	0.1 A
0x67	IL3 Current	R	0.1 A
0x68	Ground Current	R	0.1 A
0x69	IL1 Current Ratio	R	% of FLC
0x6A	IL2 Current Ratio	R	% of FLC
0x6B	IL3 Current Ratio	R	% of FLC
0x6C	IAV Average Current Ratio	R	% of FLC
0x6D	Thermal Capacity Level	R	% TripLevel
0x6E	Ground Current	R	0.1 A
0x6F	Current phase imbalance	R	% Imbalance
0x70	Time to trip	R	Seconds

Attribute ID	Name	Access	Description
0x71	Time to Reset	R	Seconds
0x7F	Single/Three Ph	R/W	0 = Single phase 1 = Three phases
0x80	TripFLCSet	R/W	% of FLA max
0x81	Trip Class	R/W	Seconds
0x84	Thermal Warn Level	R/W	% Trip Level
0x85	PL Inhibit Time	R/W	0.1 seconds
0x86	PL Trip Delay	R/W	0.1 seconds
0x88	GF Trip Delay	R/W	0.1...25.0 seconds
0x89	GF Trip Level	R/W	20...500% FLC
0x8A	GF Warn Level	R/W	20...500% FLC
0x8B	Stall Enabled Time	R/W	1...200 seconds
0x8C	Stall Trip Level	R/W	100...800 % FLC
0x8E	Jam Trip Delay	R/W	1...30 seconds
0x8F	Jam Trip Level	R/W	100...800 % FLC
0x90	Jam Warn Level	R/W	100...800 % FLC
0x92	UL Trip Delay	R/W	1...200 seconds
0x93	UL Trip Level	R/W	30...100 % FLC
0x94	UL Warn Level	R/W	30...100 % FLC
0x95	CI Inhibit Time	R/W	0.1 seconds
0x96	CI Trip Delay	R/W	0.1 seconds
0x97	CI Trip Level	R/W	0...70 % Imbalance
0x98	CI Warn Level	R/W	0...70 % Imbalance
0xB2	CT Ratio	R	-

**NOTE:** In the table above:

- PL = Current phase loss
- GF = Ground fault
- Stall = Long start
- UL = Underload
- CI = Current phase imbalance

**Instance Service**

Service Code	Name	Description
0x0E	Get Attribute Single	Returns the value of the specified instance attribute.
0x10	Set Attribute Single	Sets the value of the specified instance attribute.

## Periodically Kept Acyclic Words (PKW) Objects


### Overview

The LTMR controller supports PKW (Periodically Kept in acyclic Words). The PKW feature consists of:

- four input words mapped in input assembly objects 111, 112, and 113
- four output words mapped in output assembly objects 101, 102, and 103

These four words tables enable a EtherNet/IP scanner to read or write any register using I/O messaging.

As shown in the table below, the PKW area is located at the beginning of the corresponding assembly objects 112, 113, 102, and 103.



### PKW OUT Data

PKW OUT data requests from the EtherNet/IP scanner to the LTMR are mapped in assembly objects 101, 102, and 103.

To access registers, select one of the following function codes:

- R\_REG\_16 (0x25) to read 1 register
- R\_REG\_32 (0x26) to read 2 registers
- W\_REG\_16 (0x2A) to write 1 register
- W\_REG\_32 (0x2B) to write 2 registers

Word 1	Word 2			Word 3	Word 4
	MSB		LSB		
Register address	Toggle bit (bit 15)	Function bits (bits 8 - 14)	Not used (bits 0 - 7)	Data to write	
Register number	0 / 1	R_REG_16Code 0x25	0x00	-	-
		R_REG_32Code 0x26		-	-
		W_REG_16Code 0x2A		Data to write in register	-
		W_REG_32Code 0x2B		Data to write in register 1	Data to write in register 2

Any change in the function code triggers the handling of the request (unless Function code [bit 8 to bit 14] = 0x00).

**NOTE:** The highest bit of function code (bit 15) is a toggle bit. It is changed for each consecutive request. This mechanism enables the request initiator to detect that a response is ready by polling bit 15 of the function code in word 2. When this bit in the OUT data becomes equal to the response emitted toggle bit in the IN data (when starting the request), then the response is ready.

## PKW IN Data

PKW IN data response from the LTMR to the EtherNet/IP scanner are mapped in assembly objects 111, 112, and 113.

The LTMR echoes the same register address and function code or, eventually, an error code.

Word 1	Word 2			Word 3	Word 4
	MSB		LSB		
Register address	Toggle bit (bit 15)	Function bits (bits 8 - 14)	Not used (bits 0 - 7)	Data to write	
Same register number as in the request	Same as in the request	ErrorCode 0x4E	0x00	Error code	
		R_REG_16Code 0x25		-	-
		R_REG_32Code 0x26		Data read in register	-
		W_REG_16Code 0x2A		Data read in register 1	Data read in register 2
		W_REG_32Code 0x2B		-	-

If the initiator tries to write a TeSys T object or register to an unauthorized value, or tries to access an inaccessible register, an error code is returned (Function code = toggle bit + 0x4E). The exact error code can be found in words 3 and 4. The request is not accepted and the object/register remains at the old value.

To retrigger exactly the same command, you need to:

1. reset the Function code to 0x00,
2. wait for the response frame with the function code equal to 0x00,
3. reset it to its previous value.

This is useful for a limited master like an HMI.

Another way of retriggering exactly the same command is to invert the toggle bit in the function code byte.

The response is valid when the toggle bit of the response is equal to the toggle bit written in the answer (this is a more efficient method, but it requires higher programming capabilities).

## PKW Error Codes

Case of a write error:

Error Code	Error Name	Explanation
1	FPG_ERR_REQ_STACK_FULL	External request: sends back an error frame
3	FPG_ERR_REGISTER_NOT_FOUND	Register not managed (or the request needs super user access rights)
4	FPG_ERR_ANSWER_DELAYED	External request: answer postponed
7	FPG_ERR_NOT_ALL_REGISTER_FOUND	One or both registers cannot be found
8	FPG_ERR_READ_ONLY	Register not authorized to be written
10	FPG_ERR_VAL_1WORD_TOOHIGH	Written value not in the range of the register (word value is too high)
11	FPG_ERR_VAL_1WORD_TOOLOW	Written value not in the range of the register (word value is too low)
12	FPG_ERR_VAL_2BYTES_INF_TOOHIGH	Written value not in the range of the register (MSB value is too high)
13	FPG_ERR_VAL_2BYTES_INF_TOOLOW	Written value not in the range of the register (MSB value is too low)
16	FPG_ERR_VAL_INVALID	Written value not a valid value
20	FPG_ERR_BAD_ANSWER	External request: sends back an error frame

Case of a read error:

Error Code	Error Name	Explanation
1	FGP_ERR_REQ_STACK_FULL	External request: sends back an error frame
3	FGP_ERR_REGISTER_NOT_FOUND	Register not managed (or the request needs super user access rights)
4	FGP_ERR_ANSWER_DELAYED	External request: answer postponed
7	FGP_ERR_NOT_ALL_REGISTER_FOUND	One or both registers cannot be found

### Class Code

The class code is 0xC5 as defined by CIP.

### Class Attributes

Attribute ID	Name	Access	Description
0x01	Revision	R	The EtherNet link object implementation revision. Returns 0x01.
0x02	Max instance	R	Returns 0x01 to represent a single instance.
0x03	Number of instances	R	The number of object instances. Returns 0x01.
0x06	Max class attribute	R	The largest class attribute value. Returns 0x07.
0x07	Max instance attribute	R	The largest instance attribute value. Returns 0x02.

### Class Services

Service Code	Name	Description
0x01	Get attribute all	Returns the value of all class attributes.
0x0E	Get attribute single	Returns the value of the specified attribute.

### Instance Codes

Only one instance is supported.

### Instance Attributes

Attribute ID	Name	Access	Description
0x01	Request object	R/W	Array of eight bytes to represent the PKW request.
0x02	Response object	R	Array of eight bytes to represent the PKW response.

### Instance Services

Service Code	Name	Description
0x0E	Get attribute single	Returns the value of the specified instance attribute.
0x10	Set attribute all	Modifies the instance attribute value with the access type of R/W.

## TeSys T Monitoring Control Object

### Description

This object allows selection of four different LTMR internal data to monitor.

### Class Code

The Class Code is 0xC6.

### Class Attributes

Attribute ID	Name	Access	Description
0x01	Revision	R	The EtherNet Link object implementation revision. Returns 0x02.
0x02	Max Instance	R	Returns 0x01 to represent a single instance.
0x03	Number of Instances	R	The number of object instances. Returns 0x01.
0x06	Max Class Attribute	R	The largest class attribute value. Returns 0x07.
0x07	Max Instance Attribute	R	The largest instance attribute value. Returns 0x04.

### Class Services

Service Code	Name	Description
0x01	Get Attribute All	Returns the value of all class attributes.
0x0E	Get Attribute Single	Returns the value of the specified attribute.

### Instance Codes

Only one instance is supported.

### Instance Attributes

Attribute ID	Name	Access	Description
0x01	TeSys T Monitoring Word 0	R/W	UINT type to represent the TeSys T Monitoring Word 0. At power up, it is defaulted to 455.
0x02	TeSys T Monitoring Word 1	R/W	UINT type to represent the TeSys T Monitoring Word 1. At power up, it is defaulted to 456.
0x03	TeSys T Monitoring Word 2	R/W	UINT type to represent the TeSys T Monitoring Word 2. At power up, it is defaulted to 457.
0x04	TeSys T Monitoring Word 3	R/W	UINT type to represent the TeSys T Monitoring Word 3. At power up, it is defaulted to 458.

### Instance Services

Service Code	Name	Description
0x10	Set Attribute All	Modifies the instance attribute value with the access type of R/W.
0x0E	Get Attribute Single	Returns the value of the specified instance attribute.

## EtherNet/IP Interface Diagnostic Object

### Description

This object enables you to select the data that will be exchanged on the network through I/O messaging. A single instance (instance 1) of the EtherNet/IP Interface Object is supported.

### Class Code

The Class Code is 0x350 as defined by CIP.

### Class Attributes

Attribute ID	Name	Access	Description
0x01	Revision	R	The EtherNet/IP Interface Diagnostic object implementation revision. Returns 0x01.
0x02	Max Instance	R	Returns 0x01 to indicate that there is only one instance.
0x03	Number of Instances	R	The number of object instances. Returns 0x01.
0x04	Optional Instance Attribute List	R	Returns 0 to indicate no optional attributes.
0x05	Optional Services List	R	Returns 0 to indicate no optional services.
0x06	Max Class Attribute	R	The largest class attribute value. Returns 0x07.
0x07	Max Instance Attribute	R	The largest instance attribute value. Returns 0x07.

### Class Services

Service Code	Name	Description
0x01	Get Attribute All	Returns the value of all class attributes.
0x0E	Get Attribute Single	Returns the value of the specified attribute.

### Instance Codes

Only one instance is implemented for the EtherNet/IP Interface Diagnostic object.

### Instance Attributes

The following instance attributes are supported:

Attribute ID	Name	Access	Description
0x01	Protocols supported	Get	Protocol(s) supported. Returns a 16 bit value with bits 0 and 1 set to indicate that EtherNet/IP and Modbus TCP/IP protocols are supported.
0x02	Connection diagnostics	Get	Returns all the connection diagnostics which includes the following information: <ul style="list-style-type: none"> <li>• Max CIP I/O Connections opened (UINT): Maximum number of CIP I/O Connections opened.</li> <li>• Current CIP I/O Connections (UINT): Number of CIP I/O Connections currently opened.</li> <li>• Max CIP Explicit Connections opened (UINT): Maximum number of CIP Explicit Connections opened.</li> <li>• Current CIP Explicit Connections (UINT): Number of CIP Explicit Connections currently opened.</li> <li>• CIP Connections Opening Errors (UINT): Incremented at each attempt to open a CIP connection that fails.</li> <li>• CIP Connections Timeout Errors (UINT): Incremented when a CIP connection is timed out.</li> <li>• Max EtherNet IP TCP Connections opened (UINT): Maximum number of TCP connections opened and used for EtherNet IP communication.</li> <li>• Current EtherNet IP TCP Connections (UINT): Number of TCP connections currently opened and used for EtherNet IP communication.</li> </ul>

Attribute ID	Name	Access	Description
0x03	I/O Messaging Diagnostics	Get/Clear	Returns all the I/O messaging diagnostics which includes the following information: <ul style="list-style-type: none"><li>● I/O Production Counter (UDINT): Incremented each time a Class 0/1 CIP message is sent.</li><li>● I/O Consumption Counter (UDINT): Incremented each time a Class 0/1 CIP message is received.</li><li>● I/O Production Send Errors Counter (UINT): Incremented each time a Class 0/1 message is not sent.</li><li>● I/O Consumption Receive Errors Counter (UINT): Incremented each time consumption is received with an error.</li></ul>
0x04	Explicit Messaging Diagnostics	Get/Clear	Returns all the explicit messaging diagnostics which includes the following information: <ul style="list-style-type: none"><li>● Class3 Message Send Counter (UDINT): Incremented each time a Class 3 CIP Message is sent.</li><li>● Class3 Message Receive Counter (UDINT): Incremented each time a Class 3 CIP Message is received.</li><li>● UCMM Message Send Counter (UDINT): Incremented each time an UCMM Message is sent.</li><li>● UCMM Message Receive Counter (UDINT): Incremented each time an UCMM Message is received.</li></ul>
0x05	Communication Capacity	Get	Returns the communication capacity data which includes the following information: <ul style="list-style-type: none"><li>● Max CIP Connections (UINT): Max supported CIP Connections.</li><li>● Max TCP Connections (UINT): Max supported TCP Connections.</li><li>● Max Urgent priority rate (UINT): Max CIP transport class 0/1 Urgent priority messages packet(s).</li><li>● Max Scheduled priority rate (UINT): Max CIP transport class 0/1 Scheduled priority messages Packet(s).</li><li>● Max High priority rate (UINT): Max CIP transport class 0/1 High priority messages Packet(s).</li><li>● Max Low priority rate (UINT): Max CIP transport class 0/1 Low priority messages Packet(s).</li><li>● Max Explicit Messaging rate (UINT): Max CIP transport class 2/3 or other EIP messages Packet(s).</li></ul>
0x06	Bandwidth Diagnostics	Get	Returns the bandwidth diagnostics which includes the following information: <ul style="list-style-type: none"><li>● Current sending Urgent priority rate (UINT): CIP transport class 0/1 Urgent priority messages Packet(s) sent.</li><li>● Current reception Urgent priority rate (UINT): CIP transport class 0/1 Urgent priority messages Packet(s) received.</li><li>● Current sending Scheduled priority rate (UINT): CIP transport class 0/1 Scheduled priority messages Packet(s) sent.</li><li>● Current reception Scheduled priority rate (UINT): CIP transport class 0/1 Scheduled priority messages Packet(s) received.</li><li>● Current sending High priority rate (UINT): CIP transport class 0/1 High priority messages Packet(s) sent.</li><li>● Current sending Low priority rate (UINT): CIP transport class 0/1 Low priority messages Packet(s) sent.</li><li>● Current reception low priority rate (UINT): CIP transport class 0/1 Low priority messages Packet(s) received.</li><li>● Current sending Explicit rate (UINT): CIP transport class 2/3 or other EIP messages Packet(s) sent.</li><li>● Current reception Explicit rate (UINT): CIP transport class 2/3 or other EIP messages Packet(s) received.</li></ul>
0x07	Modbus Diagnostic	Get	Returns the modbus diagnostics which includes the following information: <ul style="list-style-type: none"><li>● Max Modbus TCP Connections opened (UINT): Maximum number of TCP connections opened and used for Modbus communication.</li><li>● Current Modbus TCP Connections (UINT): Number of TCP connections currently opened and used for Modbus communication.</li><li>● Modbus TCP Message Send Counter (UDINT): Incremented each time a Modbus TCP/IP Message is sent.</li><li>● Modbus TCP Message Receive Counter (UDINT): Incremented each time a Modbus TCP/IP Message is received.</li></ul>

## Instance Services

Service Code	Name	Description
0x01	Get Attribute All	Returns the value of all instance attributes.

Service Code	Name	Description
0x0E	Get Attribute Single	Returns the value of the specified instance attribute.
0x4C	Get and Clear Single	Returns the value of the specified instance attribute and clears the same.

## I/O Connection Diagnostic Object

### Description

This object provides the detailed diagnostic of each configured CIP I/O connection viewed from a Scanner and of each opened CIP I/O connection viewed from an adapter.

### Class Code

The Class code is 0x352 as defined by CIP.

### Class Attributes

Attribute ID	Name	Access	Description
0x01	Revision	Get	The I/O Connection Diagnostic object implementation revision. Returns 0x01.
0x02	Max Instance	Get	Returns the maximum instance number created that varies from 0 to N (N = maximum number of CIP I/O connections = 32).
0x03	Number of Instances	Get	Returns the number of instances created that varies from 0 to N (N = maximum number of CIP I/O connections = 32).
0x04	Optional Instance Attribute List	Get	Returns 0 to indicate no optional attributes.
0x05	Optional Services List	Get	Returns 0 to indicate no optional services.
0x06	Max Class Attribute	Get	The largest class attribute value. Returns 0x07.
0x07	Max Instance Attribute	Get	The largest instance attribute value. Returns 0x02.

### Class Services

Service Code	Name	Description
0x01	Get Attribute All	Returns the value of all class attributes.
0x0E	Get Attribute Single	Returns the value of the specified attribute.

### Instance Codes

The number of instances created varies from 0...N, where N is the maximum number of CIP I/O connections.

### Instance Attributes

The following instance attributes are supported:

Attribute ID	Name	Access	Description
0x01	I/O Communication Diagnostics	Get/Clear	Returns the I/O communication diagnostics data which contains the following information: <ul style="list-style-type: none"> <li>• I/O Production Counter(UDINT): Incremented at each production.</li> <li>• I/O Consumption Counter (UDINT): Incremented at each consumption.</li> <li>• I/O Production Send Errors Counter (UINT): Incremented each time a production is not sent.</li> <li>• I/O Consumption Receive Errors Counter (UINT): Incremented each time consumption is received with an error.</li> <li>• CIP Connection Timeout Errors (UINT): Incremented when a connection is timed out.</li> <li>• CIP Connection Opening Errors (UINT): Incremented at each attempt to open a connection that fails.</li> <li>• CIP Connection State (UINT): State of the CIP I/O connection.</li> <li>• CIP Last Error General Status (UINT): “General Status” of the last error detected on the connection.</li> <li>• CIP Last Error Extended Status (UINT): “Extended Status” of the last error detected on the connection.</li> <li>• Input Com Status (UINT): Communication status of the inputs.</li> <li>• Output Com status (UINT): Communication status of the outputs.</li> </ul>

Attribute ID	Name	Access	Description
0x02	Connection Diagnostics	Get	<p>Returns all the connection diagnostics which includes the following information:</p> <ul style="list-style-type: none"> <li>● Production Connection ID (UDINT): Connection ID for production.</li> <li>● Consumption Connection ID (UDINT): Connection ID for consumption.</li> <li>● Production RPI (UDINT): RPI for production.</li> <li>● Production API (UDINT): API for production.</li> <li>● Consumption RPI (UDINT): RPI for consumption.</li> <li>● Consumption API (UDINT): API for consumption.</li> <li>● Production Connection Parameters (UDINT): Connection parameters for production.</li> <li>● Consumption Connection Parameters (UINT): Connection parameters for consumption.</li> <li>● Local IP (UDINT).</li> <li>● Local UDP Port (UINT).</li> <li>● Remote IP (UDINT).</li> <li>● Remote UDP Port (UINT).</li> <li>● Production Multicast IP (UDINT): Multicast IP used for production.</li> <li>● Consumption Multicast IP (UDINT): Multicast IP used for consumption.</li> <li>● Protocols supported (UINT): Protocol(s) supported on the connection.</li> </ul>

### Instance Services

Service Code	Name	Description
0x01	Get Attribute All	Returns the value of all instance attributes.
0x0E	Get Attribute Single	Returns the value of the specified instance attribute.
0x4C	Get and Clear Single	Returns the value of the specified instance attribute and clears the same.

## Explicit Connection Diagnostic Object

### Description

This object provides a description of an opened Explicit Connection and associated communication.

### Class Code

The Class Code is 0x353 as defined by CIP.

### Class Attributes

Attribute ID	Name	Access	Description
0x01	Revision	Get	The Explicit Connection Diagnostic object implementation revision. Returns 0x01.
0x02	Max Instance	Get	Returns the maximum instance number created that varies from 0 to N (N = maximum number of CIP explicit connections = 32).
0x03	Number of Instances	Get	Returns the number of instances created that varies from 0 to N (N = maximum number of CIP explicit connections = 32).
0x04	Optional Instance Attribute List	Get	Returns 0 to indicate no optional attributes.
0x05	Optional Services List	Get	Returns 0 to indicate no optional services.
0x06	Max Class Attribute	Get	The largest class attribute value. Returns 0x07.
0x07	Max Instance Attribute	Get	The largest instance attribute value. Returns 0x08.

### Class Services

Service Code	Name	Description
0x01	Get Attribute All	Returns the value of all class attributes.
0x0E	Get Attribute Single	Returns the value of the specified attribute.

### Instance Codes

The number of instances created varies from 0...N, where N is the maximum number of CIP explicit connections which is 32 at present.

### Instance Attributes

The following instance attributes are supported:

Attribute ID	Name	Access	Description
0x01	Originator Connection ID	Get	O -> T Connection ID
0x02	Originator IP	Get	–
0x03	Originator TCP Port	Get	–
0x04	Target Connection ID	Get	T -> O Connection ID
0x05	Target IP	Get	–
0x06	Target TCP Port	Get	–
0x07	Message Send Counter	Get	Incremented each time a Class 3 CIP message is sent on the connection.
0x08	Message Receive Counter	Get	Incremented each time a Class 3 CIP message is received on the connection.

### Instance Services

Service Code	Name	Description
0x01	Get Attribute All	Returns the value of all instance attributes.

## Explicit Connection Diagnostic List Object

### Description

This object provides a snapshot of the list of instantiated Explicit Connection Diagnostic objects.

### Class Code

The Class code is 0x354 as defined by CIP.

### Class Attributes

Attribute ID	Name	Access	Description
0x01	Revision	Get	The Explicit Connection Diagnostic List object implementation revision. Returns 0x01.
0x02	Max Instance	Get	Returns the maximum instance number created that varies from 0 to N (N = maximum number of concurrent list access supported = 2).
0x03	Number of Instances	Get	Returns the number of instances created that varies from 0 to N (N = maximum number of concurrent list access supported = 2).
0x04	Optional Instance Attribute List	Get	Returns 0 to indicate no optional attributes.
0x05	Optional Services List	Get	Returns 0 to indicate no optional services.
0x06	Max Class Attribute	Get	The largest class attribute value. Returns 0x07.
0x07	Max Instance Attribute	Get	The largest instance attribute value. Returns 0x02.

### Class Services

Service Code	Name	Description
0x01	Get Attribute All	Returns the value of all class attributes.
0x0E	Get Attribute Single	Returns the value of the specified attribute.

### Instance Codes

The number of instances created varies from 0...N, where N is the maximum number of concurrent list access supported, which are 2.

### Instance Attributes

The following instance attributes are supported:

Attribute ID	Name	Access	Description
0x01	Number of Connections	Get	Total number of opened Explicit connections.
0x02	Explicit Messaging Connections Diagnostic List	Get	<p>Array of structures that represents the contents of instantiated "Explicit Connection Diagnostic" objects.</p> <p>Each of these objects has the following information:</p> <ul style="list-style-type: none"> <li>• Originator Connection ID (UDINT): O -&gt; T Connection ID.</li> <li>• Originator IP (UDINT).</li> <li>• Originator TCP Port (UINT).</li> <li>• Target Connection ID (UDINT): T -&gt; O Connection ID.</li> <li>• Target IP (UDINT).</li> <li>• Target TCP Port (UINT).</li> <li>• Message Send Counter (UDINT): Incremented each time a Class 3 CIP message is sent on the connection.</li> <li>• Message Receive Counter (UDINT): Incremented each time a Class 3 CIP message is received on the connection.</li> </ul>

**Instance Services**

Service Code	Name	Description
0x08	Create	This service creates an instance of the “Explicit Connections Diagnostic List” object.
0x09	Delete	This service deletes an instance of the “Explicit Connections Diagnostic List” object.
0x33	Explicit Connections Diagnostic Read	This service reads the explicit connections diagnostics data from the list.

## Section 3.4

### Communication Variables

#### Overview

This section describes the communication variables for EtherNet/IP and for Modbus/TCP communication protocols.

#### WARNING

##### LOSS OF CONTROL

- The designer of any control scheme must consider the potential failure modes of control paths and, for certain critical functions, provide a means to achieve a safe state during and after a path failure. Examples of critical control functions are emergency stop and overtravel stop.
- Separate or redundant control paths must be provided for critical control functions.
- System control paths may include communication links. Consideration must be given to the implications of anticipated transmission delays or failures of the link.<sup>(1)</sup>
- Each implementation of an LTMR controller must be individually and thoroughly tested for proper operation before being placed into service.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

(1) For additional information, refer to NEMA ICS 1.1 (latest edition), "Safety Guidelines for the Application, Installation, and Maintenance of Solid State Control".

#### WARNING

##### UNEXPECTED RESTART OF THE MOTOR

Check that the PLC application software:

- Considers the change from local to remote control,
- Manages appropriately the motor control commands during those changes.

When switching to the Network control channels, depending on the communication protocol configuration, the LTMR controller can take into account the latest known state of the motor control commands issued from the PLC and restart automatically the motor.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

#### What Is in This Section?

This section contains the following topics:

Topic	Page
Communication Parameter Clear Commands	96
Simplified Control and Monitoring	98
Organization of Communication Variables	100
Data Formats	101
Data Types	102
Identification Variables	108
Statistics Variables	109
Monitoring Variables	116
Configuration Variables	125
Command Variables	134
User Map Variables	135
Custom Logic Variables	137
Mirroring Variables	138

## Communication Parameter Clear Commands

### Clear Commands Overview

You can clear communication parameters as follows:


- Using the LTMR rotary switches to clear its IP addressing settings
- Using the following parameter-based commands:
  - Clear all command
  - Clear network port settings command

You can clear other parameters using the following parameter-based commands:

- Clear statistics command
- Clear thermal capacity level command
- Clear controller setting command

### Clear IP Using the Rotary Switch

To clear IP addressing settings, set the Ones, or right, rotary switch on the LTMR controller to **Clear IP** (see below):



This clears the following Ethernet parameters:

- IP Address
- Subnet Mask
- Gateway

The position of the Tens, or left, switch does not affect the Clear IP function.

After the IP addressing parameters are cleared, power must be cycled to the LTMR controller for it to obtain new IP addressing parameters ([see page 32](#)).

### Clear All Command

If you want to change the configuration of the LTMR controller, you may want to clear all existing parameters in order to set new parameters for the controller.

To clear all parameters, set to 1 the bit 0 of:

- Modbus/TCP register address 705
- Or EtherNet/IP object address 6C: 01: 06

This forces the controller to enter configuration mode. A power-cycle is performed to restart correctly in this mode. This enables the controller to pick up the new values for the cleared parameters.

When you clear all parameters, static characteristics are also lost. Only the following parameters are not cleared after a Clear All Command:

- Motor LO1 Closings Count
- Motor LO2 Closings Count
- Controller Internal Temperature Max

### Clear Statistics Command

To clear statistics parameters, set to 1 the bit 1 of:

- Modbus/TCP register address 705
- Or EtherNet/IP object address 6C: 01: 06

Statistics parameters are cleared without the LTMR controller being forced into configuration mode. Static characteristics are preserved.

The following parameters are not cleared after a Clear Statistics Command:

- Motor LO1 Closings Count
- Motor LO2 Closings Count
- Controller Internal Temperature Max

### Clear Thermal Capacity Level Command

To clear thermal memory parameters, set to 1 the bit 2 of:

- Modbus/TCP register address 705
- Or EtherNet/IP object address 6C: 01: 06

This action clears the following parameters:

- Thermal Capacity Level
- Rapid Cycle Lockout Timeout

Thermal memory parameters are cleared without the LTMR controller being forced into configuration mode. Static characteristics are preserved.

**NOTE:** This bit is writable at any time, even when the motor is running.

### Clear Controller Settings Command

The Clear Controller Settings Command restores the LTMR controller protection factory setting (timeouts and thresholds).

To clear controller settings parameters, set: to 1 the bit 3 of:

- Modbus/TCP register address 705
- Or EtherNet/IP object address 6C: 01: 06

The following settings are *not* cleared by this command:

- Controller characteristics
- Connections (CT, temperature sensor, and I/O settings)
- Operating mode

Controller setting parameters are cleared without the controller being forced into configuration mode. Static characteristics are preserved.

### Clear Network Port Settings Command

The Clear Network Port Settings command restores the network port factory settings (address, and so on).

To clear controller settings parameters, set to 1 the bit 4 of:

- Modbus/TCP register address 705
- Or EtherNet/IP object address 6C: 01: 06

Controller setting parameters are cleared without the controller being forced into configuration mode. Static characteristics are preserved. Only the network communication becomes ineffective.

After the IP addressing parameters are cleared, power must be cycled to the LTMR controller for it to obtain new IP addressing parameters (*see page 32*).


## Simplified Control and Monitoring

### Overview

In this section there are two simplified examples of the main registers which control and monitor a Motor Management Controller, one with Modbus/TCP communication protocol and one with EtherNet/IP communication protocol.


### Modbus/TCP Registers for Simplified Operation

The illustration below provides basic setup information, using the following registers: configuration, control and monitoring (system status, measurements, faults, and warnings, acknowledgement).



## Ethernet/IP Registers for Simplified Operation

The illustration below provides basic setup information, using the following registers: configuration, control and monitoring (system status, measurements, faults, warnings, and, acknowledgement).



## Organization of Communication Variables

### Introduction

Communication variables are listed in tables. They belong to groups (identification, statistics, monitoring,...). They are associated with an LTMR controller, which may or may not have an LTME expansion module attached.

### Communication Variable Groups

Communication variables are grouped according to the following criteria:

Variable Groups	Modbus/TCP (Register Addresses)	EtherNet/IP (Object Addresses)
Identification variables	00-99	64 : 01 : 32 to 64 : 01 : 61
Statistics variables	100-449	65 : 01 : 01 to 67 : 01 : 83
Monitoring variables	450-539	68 : 01 : 01 to 68 : 01 : 4A
Configuration variables	540-699	69 : 01 : 01 to 6B : 01 : 32
Command variables	700-713	6C : 01 : 01 to 6C : 01 : 0A
User map variables	800--999	6D : 01 : 01 to 6E : 01 : 64
Custom logic variables	1250-1399	71 : 01 : 33 to 71 : 01 : C8
Extended monitoring variables for communication	2000-2099	82 : 01 : 01 to 82 : 01 : 27
Mirroring variables	2500-2599	8C : 01 : 01 to 8C : 01 : 15
Extended configuration variables for communication	3000-3120	96 : 01 : 01 to 96 : 01 : 77

### Table Structure

Communication variables are listed in 5-column tables:

Column 1 Modbus/TCP Register address (in decimal)	Column 2 EtherNet/IP Object address (class : instance : attribute)	Column 3 Variable type: integer, word, word[n], DT_type (see Identification Variables ( <a href="#">see page 108</a> ))	Column 4 Variable name and access via Read only or Read/Write requests	Column 5 Note: code for additional information

### Note

The Note column gives a code for additional information.

Variables without a code are available for all hardware configurations, and without functional restrictions.

The code can be:

- numerical (1-9), for specific hardware combinations
- alphabetical (A-Z), for specific system behaviors

If the Note is...	Then the Variable is...
1	available for the LTMR + LTMEV40 combination
2	always available but with a value equal to 0 if no LTMEV40 is connected
3-9	Not used

If the Note is...	Then...
A	the variable can be written only when the motor is OFF
B	the variable can be written only in configuration mode
C	the variable can be written only with no fault
D-Z	the variable is available for future exceptions

### Unused Addresses

Unused addresses fall into three categories:

- **Not significant**, in Read only tables, means that you should ignore the value read, whether equal to 0 or not.
- **Reserved**, in Read/Write tables, means that you must write 0 in these variables.
- **Forbidden**, means that read or write requests are rejected, that these addresses are not accessible at all.

## Data Formats

### Overview

The data format of a communication variable can be integer, Word, or Word[n], as described below. For more information about a variable size and format, see Data Types ([see page 102](#)).

### Integer (Int, UInt, DInt, IDInt)

Integers fall into the following categories:

- **Int**: signed integer using one register (16 bits)
- **UInt**: unsigned integer using one register (16 bits)
- **DInt**: signed double integer using two registers (32 bits)
- **UDInt**: unsigned double integer using two registers (32 bits)

For all integer-type variables, the variable name is completed with its unit or format, if necessary.

#### Example:

Register 474 or object 68 : 01: 19, **UInt**, Frequency (x 0.01 Hz).

### Word

**Word**: Set of 16 bits, where each bit or group of bits represents command, monitoring or configuration data.

#### Example:

Register 455 or object 68 : 01 : 06, Word, System Status Register 1.

bit 0	System ready
bit 1	System on
bit 2	System fault
bit 3	System warning
bit 4	System tripped
bit 5	Fault reset authorized
bit 6	(Not significant)
bit 7	Motor running
bits 8-13	Motor average current ratio
bit 14	In remote
bit 15	Motor starting (in progress)

### Word[n]

**Word[n]**: Data encoded on contiguous registers.

#### Examples:

Registers 64-69 or objects 64 : 01 : 41 to 64 : 01 : 46, **Word[6]**, Controller Commercial Reference (see DT\_CommercialReference ([see page 102](#))).

Registers 655-658 or objects 6B : 01 : 06 to 6B : 01 : 09, **Word[4]**, Date and Time setting (see DT\_DateTime ([see page 103](#))).

## Data Types

### Overview

Data types are specific variable formats which are used to complement the description of internal formats (for instance, in case of a structure or of an enumeration). The generic format of data types is DT\_xxx.

### List of Data Types

Here is the list of the most commonly used data types:

- DT\_ACInputSetting
- DT\_CommercialReference
- DT\_DateTime
- DT\_ExtBaudRate
- DT\_ExtParity
- DT\_FaultCode
- DT\_FirmwareVersion
- DT\_Language5
- DT\_OutputFallbackStrategy
- DT\_PhaseNumber
- DT\_ResetMode
- DT\_WarningCode

These data types are described below.

### DT\_ACInputSetting

**DT\_ACInputSetting** format is an **enumeration** that improves AC input detection:

Value	Description
0	None (factory setting)
1	< 170 V 50 Hz
2	< 170 V 60 Hz
3	> 170 V 50 Hz
4	> 170 V 60 Hz

### DT\_CommercialReference

**DT\_CommercialReference** format is **Word[6]** and indicates a Commercial Reference:

Word	MSB	LSB
1	character 1	Character 2
2	character 3	Character 4
3	character 5	Character 6
4	character 7	Character 8
5	character 9	Character 10
6	character 11	Character 12

#### Example:

Registers 64-69 or objects 64 : 01 : 41 to 64 : 01 : 46, **Word[6]**, Controller Commercial Reference.

If Controller Commercial Reference = LTMR:

Modbus/TCP (Register Addresses)	EtherNet/IP (Object Addresses)	MSB	LSB
64	64 : 01 : 41	L	T
65	64 : 01 : 42	M	(space)
66	64 : 01 : 43	R	
67	64 : 01 : 44		
68	64 : 01 : 45		
69	64 : 01 : 46		

**DT\_DateTime**

**DT\_DateTime** format is **Word[4]** and indicates Date and Time:

Word	Bits 12-15	Bits 8-11	Bits 4-7	Bits 0-3
1	S	S	0	0
2	H	H	m	m
3	M	M	D	D
4	Y	Y	Y	Y

Where:

- S = second  
The format is two BCD digits.  
The value range is [00-59] in BCD.
- 0 = unused
- H = hour  
The format is two BCD digits.  
The value range is [00-23] in BCD.
- m = minute  
The format is two BCD digits.  
The value range is [00-59] in BCD.
- M = month  
The format is two BCD digits.  
The value range is [01-12] in BCD.
- D = day  
The format is two BCD digits.  
The value range is (in BCD):  
[01-31] for months 01, 03, 05, 07, 08, 10, and 12  
[01-30] for months 04, 06, 09, and 11  
[01-29] for month 02 in a leap year  
[01-28] for month 02 in a non-leap year.
- Y = year  
The format is four Binary Coded Decimal (BCD) digits.  
The value range is [2006-2099] in BCD.

Data entry format and value range are:

Data Entry Format	DT#YYYY-MM-DD-HH:mm:ss	
Minimum value	DT#2006-01-01:00:00:00	January 1, 2006
Maximum value	DT#2099-12-31-23:59:59	December 31, 2099

Note: If you give values outside the limits, the system will return an error.

**Example:**

Registers 655-658 or objects 6B : 01 : 06 to 6B : 01 : 09, **Word[4]**, Date and Time setting.

If date is September 4, 2008 at 7 a.m., 50 minutes and 32 seconds:

Modbus/TCP (Register Addresses)	EtherNet/IP (Object Addresses)	15 12	11 8	7 4	3 0
655	6B : 01 : 06	3	2	0	0
656	6B : 01 : 07	0	7	5	0
657	6B : 01 : 08	0	9	0	4
658	6B : 01 : 09	2	0	0	8

With data entry format: DT#2008-09-04-07:50:32.

**DT\_ExtBaudRate**

**DT\_ExtbaudRate** depends on the bus used:

**DT\_ModbusExtBaudRate** format is an **enumeration** of possible baud rates with Modbus network:

Value	Description
1200	1200 Baud
2400	2400 Baud
4800	4800 Baud
9600	9600 Baud
19200	19,200 Baud
65535	Autodetection (factory setting)

**DT\_ProfibusExtBaudRate** format is an **enumeration** of possible baud rates with PROFIBUS DP network:

Value	Description
65535	Autobaud (factory setting)

**DT\_DeviceNetExtBaudRate** format is an **enumeration** of possible baud rates with DeviceNet network:

Value	Description
0	125 kBaud
1	250 kBaud
2	500 kBaud
3	Autobaud (factory setting)

**DT\_CANopenExtBaudRate** format is an **enumeration** of possible baud rates with CANopen network:

Value	Description
0	10 kBaud
1	20 kBaud
2	50 kBaud
3	125 kBaud
4	250 kBaud (factory setting)
5	500 kBaud
6	800 kBaud
7	1000 kBaud
8	Autobaud
9	Factory setting

**DT\_ExtParity**

**DT\_ExtParity** depends on the bus used:

**DT\_ModbusExtParity** format is an **enumeration** of possible parities with Modbus network:

Value	Description
0	None
1	Even
2	Odd

**DT\_FaultCode**

**DT\_FaultCode** format is an **enumeration** of fault codes:

Fault Code	Description
0	No error
3	Ground current
4	Thermal overload
5	Long start

Fault Code	Description
6	Jam
7	Current phase imbalance
8	Undercurrent
10	Test
11	HMI port error
12	HMI port communication loss
13	Network port internal error
16	External fault
18	On-Off diagnostic
19	Wiring diagnostic
20	Overcurrent
21	Current phase loss
22	Current phase reversal
23	Motor temp sensor
24	Voltage phase imbalance
25	Voltage phase loss
26	Voltage phase reversal
27	Undervoltage
28	Oversupply
29	Underpower
30	Overpower
31	Under power factor
32	Over power factor
33	LTME configuration
34	Temperature sensor short-circuit
35	Temperature sensor open-circuit
36	CT reversal
37	Out of boundary CT ratio
46	Start check
47	Run checkback
48	Stop check
49	Stop checkback
51	Controller internal temperature error
55	Controller internal error (Stack overflow)
56	Controller internal error (RAM error)
57	Controller internal error (RAM checksum error)
58	Controller internal error (Hardware watchdog fault)
60	L2 current detected in single-phase mode
64	Non volatile memory error
65	Expansion module communication error
66	Stuck reset button
67	Logic function error
100-104	Network port internal error
109	Network port comm error
111	Faulty device replacement fault
555	Network port configuration error

**DT\_FirmwareVersion**

**DT\_FirmwareVersion** format is an **XY000 array** that describes a firmware revision:

- X = major revision
- Y = minor revision.

**Example:**

Register 76 or object 64 : 01 : 4D, **UInt**, Controller firmware version.

**DT\_Language5**

**DT\_Language5** format is an **enumeration** used for language display:

Language Code	Description
1	English (factory setting)
2	Français
4	Español
8	Deutsch
16	Italiano

**Example:**

Register 650 or object 6B : 01 : 01, **Word**, HMI language.

**DT\_OutputFallbackStrategy**

**DT\_OutputFallbackStrategy** format is an **enumeration** of motor output states when loosing communication.

Value	Description	Motor Modes
0	Hold LO1 LO2	For all modes
1	Run	For two-step mode only
2	LO1, LO2 OFF	For all modes
3	LO1, LO2 ON	Only for overload, independent and custom operating modes
4	LO1 ON	For all modes except two steps
5	LO2 ON	For all modes except two steps

**DT\_PhaseNumber**

**DT\_PhaseNumber** format is an **enumeration**, with only one bit activated:

Value	Description
1	One phase
2	Three phases

**DT\_ResetMode**

**DT\_ResetMode** format is an **enumeration** of possible modes for thermal fault reset:

Value	Description
1	Manual or HMI
2	Remote by network
4	Automatic

**DT\_WarningCode**

**DT\_WarningCode** format is an **enumeration** of warning codes:

Warning Code	Description
0	No warning
3	Ground current
4	Thermal overload
5	Long start
6	Jam

<b>Warning Code</b>	<b>Description</b>
7	Current phase imbalance
8	Undercurrent
10	HMI port
11	LTMR internal temperature
18	Diagnostic
19	Wiring
20	Overcurrent
21	Current phase loss
23	Motor temp sensor
24	Voltage phase imbalance
25	Voltage phase loss
27	Undervoltage
28	Ovvoltage
29	Underpower
30	Overpower
31	Under power factor
32	Over power factor
33	LTME configuration
46	Start check
47	Run checkback
48	Stop check
49	Stop checkback
109	Network port comm loss
555	Network port configuration

## Identification Variables

### Identification Variables

**Identification variables** are described in the following table:

Modbus/TCP (Register Addresses)	EtherNet/IP (Object Addresses)	Variable Type	Read-only Variables	Note (see page 10 0)
0-34	64 : 01 : 01 - 64 : 01 : 23		(Not significant)	
35-40	64 : 01 : 24 - 64 : 01 : 29	Word[6]	Expansion commercial reference (See DT_CommercialReference (see page 102))	1
41-45	64 : 01 : 2A - 64 : 01 : 2E	Word[5]	Expansion serial number	1
46	64 : 01 : 2F	UInt	Expansion ID code	1
47	64 : 01 : 30	UInt	Expansion firmware version (See DT_FirmwareVersion (see page 106))	1
48	64 : 01 : 31	UInt	Expansion compatibility code	1
49-60	64 : 01 : 32 - 64 : 01 : 3D		(Not significant)	
61	64 : 01 : 3E	UInt	Network port ID code	
62	64 : 01 : 3F	UInt	Network port firmware version (See DT_FirmwareVersion (see page 106))	
63	64 : 01 : 40	UInt	Network port compatibility code	
64-69	64 : 01 : 41 - 64 : 01 : 46	Word[6]	Controller commercial reference (See DT_CommercialReference (see page 102))	
70-74	64 : 01 : 47 - 64 : 01 : 4B	Word[5]	Controller serial number	
75	64 : 01 : 4C	UInt	Controller ID code	
76	64 : 01 : 4D	UInt	Controller firmware version (See DT_FirmwareVersion (see page 106))	
77	64 : 01 : 4E	UInt	Controller compatibility code	
78	64 : 01 : 4F	UInt	Current scale ratio (0.1 %)	
79	64 : 01 : 50	UInt	Current sensor max	
80	64 : 01 : 51		(Not significant)	
81	64 : 01 : 52	UInt	Current range max (x 0.1 A)	
82-94	64 : 01 : 53 - 64 : 01 : 5F		(Not significant)	
95	64 : 01 : 60	UInt	Load CT ratio (x 0.1 A)	
96	64 : 01 : 61	UInt	Full load current max (maximum FLC range, $FLC = Full\ Load\ Current$ ) (x 0.1 A)	
97-99	64 : 01 : 62 - 64 : 01 : 64		(Forbidden)	

## Statistics Variables

### Statistics Overview

**Statistics variables** are grouped according to the following criteria. Trip statistics are contained into a main table and an extension table.

Statistics Variable Groups	Modbus/TCP (Register Addresses)	EtherNet/IP (Object Addresses)
Global statistics	100-121	65 : 01 : 01 - 65 : 01 : 16
LTM monitoring statistics	122-149	65 : 01 : 17 - 65 : 01 : 32
Last trip statistics and extension	150-179 300-309	66 : 01 : 01 - 66 : 01 : 1E 67 : 01 : 01 - 67 : 01 : 0A
Trip n-1 statistics and extension	180-209 330-339	66 : 01 : 1F - 66 : 01 : 3C 67 : 01 : 1F - 67 : 01 : 28
Trip n-2 statistics and extension	210-239 360-369	66 : 01 : 3D - 66 : 01 : 5A 67 : 01 : 3D - 67 : 01 : 46
Trip n-3 statistics and extension	240-269 390-399	66 : 01 : 5B - 66 : 01 : 78 67 : 01 : 5B - 67 : 01 : 64
Trip n-4 statistics and extension	270-299 420-429	66 : 01 : 79 - 66 : 01 : 96 67 : 01 : 79 - 67 : 01 : 82

### Global Statistics

The global statistics are described in the following table:

Modbus/TCP (Register Addresses)	EtherNet/IP (Object Addresses)	Variable Type	Read-only Variables	Note (see page 100)
100-101	65 : 01 : 01 - 65 : 01 : 02		(Not significant)	
102	65 : 01 : 03	UInt	Ground current faults count	
103	65 : 01 : 04	UInt	Thermal overload faults count	
104	65 : 01 : 05	UInt	Long start faults count	
105	65 : 01 : 06	UInt	Jam faults count	
106	65 : 01 : 07	UInt	Current phase imbalance faults count	
107	65 : 01 : 08	UInt	Undercurrent faults count	
109	65 : 01 : 0A	UInt	HMI port faults count	
110	65 : 01 : 0B	UInt	Controller internal faults count	
111	65 : 01 : 0C	UInt	Internal port faults count	
112	65 : 01 : 0D	UInt	(Not significant)	
113	65 : 01 : 0E	UInt	Network port config faults count	
114	65 : 01 : 0F	UInt	Network port faults count	
115	65 : 01 : 10	UInt	Auto-resets count	
116	65 : 01 : 11	UInt	Thermal overload warnings count	
117-118	65 : 01 : 12 - 65 :: 01 : 13	UDInt	Motor starts count	
119-120	65 : 01 : 14 - 65 :: 01 : 15	UDInt	Operating time (s)	
121	65 : 01 : 16	Int	Controller internal temperature max (°C)	

### LTM Monitoring Statistics

The LTM monitoring statistics are described below:

Modbus/TCP (Register Addresses)	EtherNet/IP (Object Addresses)	Variable Type	Read-only Variables	Note (see page 100)
122	65 : 01 : 17	UInt	Faults count	
123	65 : 01 : 18	UInt	Warnings count	
124-125	65 : 01 : 19 - 65 : 01 : 1A	UDInt	Motor LO1 closings count	
126-127	65 : 01 : 1B - 65 : 01 : 1C	UDInt	Motor LO2 closings count	

Modbus/TCP (Register Addresses)	EtherNet/IP (Object Addresses)	Variable Type	Read-only Variables	Note (see page 100 )
128	65 : 01 : 1D	UInt	Diagnostic faults count	
129	65 : 01 : 1E	UInt	(Reserved)	
130	65 : 01 : 1F	UInt	Overcurrent faults count	
131	65 : 01 : 20	UInt	Current phase loss faults count	
132	65 : 01 : 21	UInt	Motor temperature sensor faults count	
133	65 : 01 : 22	UInt	Voltage phase imbalance faults count	1
134	65 : 01 : 23	UInt	Voltage phase loss faults count	1
135	65 : 01 : 24	UInt	Wiring faults count	1
136	65 : 01 : 25	UInt	Undervoltage faults count	1
137	65 : 01 : 26	UInt	Oversupply faults count	1
138	65 : 01 : 27	UInt	Underpower faults count	1
139	65 : 01 : 28	UInt	Overpower faults count	1
140	65 : 01 : 29	UInt	Under power factor faults count	1
141	65 : 01 : 2A	UInt	Over power factor faults count	1
142	65 : 01 : 2B	UInt	Load shedding count	1
143-144	65 : 01 : 2C - 65 : 01 : 2D	UDInt	Active power consumption (kWh)	1
145-146	65 : 01 : 2E - 65 : 01 : 2F	UDInt	Reactive power consumption (kVArh)	1
147	65 : 01 : 30	UInt	Auto restart immediate count	
148	65 : 01 : 31	UInt	Auto restart delayed count	
149	65 : 01 : 32	UInt	Auto restart manual count	

**Last Fault (n-0) Statistics**

The last fault statistics are completed by variables at register addresses 300 to 310.

Modbus/TCP (Register Addresses)	EtherNet/IP (Object Addresses)	Variable Type	Read-only Variables	Note (see page 100 )
150	66 : 01 : 01	UInt	Fault code n-0	
151	66 : 01 : 02	UInt	Motor full load current ratio n-0 (% FLC max)	
152	66 : 01 : 03	UInt	Thermal capacity level n-0 (% trip level)	
153	66 : 01 : 04	UInt	Average current ratio n-0 (% FLC)	
154	66 : 01 : 05	UInt	L1 current ratio n-0 (% FLC)	
155	66 : 01 : 06	UInt	L2 current ratio n-0 (% FLC)	
156	66 : 01 : 07	UInt	L3 current ratio n-0 (% FLC)	
157	66 : 01 : 08	UInt	Ground current ratio n-0 (x 0.1 % FLC min)	
158	66 : 01 : 09	UInt	Full load current max n-0 (x 0.1 A)	
159	66 : 01 : 0A	UInt	Current phase imbalance n-0 (%)	
160	66 : 01 : 0B	UInt	Frequency n-0 (x 0.1 Hz)	
161	66 : 01 : 0C	UInt	Motor temperature sensor n-0 (x 0.1 °C)	
162-165	66 : 01 : OD - 66 : 01 : 10	Word[4]	Date and time n-0 (See DT_DateTime (see page 103))	
166	66 : 01 : 11	UInt	Average voltage n-0 (V)	1
167	66 : 01 : 12	UInt	L3-L1 voltage n-0 (V)	1

Modbus/TCP (Register Addresses)	EtherNet/IP (Object Addresses)	Variable Type	Read-only Variables	Note (see page 100 )
168	66 : 01 : 13	UInt	L1-L2 voltage n-0 (V)	1
169	66 : 01 : 14	UInt	L2-L3 voltage n-0 (V)	1
170	66 : 01 : 15	UInt	Voltage phase imbalance n-0 (%)	1
171	66 : 01 : 16	UInt	Active power n-0 (x 0.1 kW)	1
172	66 : 01 : 17	UInt	Power factor n-0 (x 0.01)	1
173-179	66 : 01 : 18 - 66 : 01 : 1E		(Not significant)	

## N-1 Fault Statistics

The n-1 fault statistics are completed by variables at register addresses 330 to 340.

Modbus/TCP (Register Addresses)	EtherNet/IP (Object Addresses)	Variable Type	Read-only Variables	Note (see page 100 )
180	66 : 01 : 1F	UInt	Fault code n-1	
181	66 : 01 : 20	UInt	Motor full load current ratio n-1 (% FLC max)	
182	66 : 01 : 21	UInt	Thermal capacity level n-1 (% trip level)	
183	66 : 01 : 22	UInt	Average current ratio n-1 (% FLC)	
184	66 : 01 : 23	UInt	L1 current ratio n-1 (% FLC)	
185	66 : 01 : 24	UInt	L2 current ratio n-1 (% FLC)	
186	66 : 01 : 25	UInt	L3 current ratio n-1 (% FLC)	
187	66 : 01 : 26	UInt	Ground current ratio n-1 (x 0.1 % FLC min)	
188	66 : 01 : 27	UInt	Full load current max n-1 (x 0.1 A)	
189	66 : 01 : 28	UInt	Current phase imbalance n-1 (%)	
190	66 : 01 : 29	UInt	Frequency n-1 (x 0.1 Hz)	
191	66 : 01 : 2A	UInt	Motor temperature sensor n-1 (x 0.1 Ω)	
192-195	66 : 01 : 2B - 66 : 01 : 2E	Word[4]	Date and time n-1 (See DT_DateTime (see page 103))	
196	66 : 01 : 2F	UInt	Average voltage n-1 (V)	1
197	66 : 01 : 30	UInt	L3-L1 voltage n-1 (V)	1
198	66 : 01 : 31	UInt	L1-L2 voltage n-1 (V)	1
199	66 : 01 : 32	UInt	L2-L3 voltage n-1 (V)	1
200	66 : 01 : 33	UInt	Voltage phase imbalance n-1 (%)	1
201	66 : 01 : 34	UInt	Active power n-1 (x 0.1 kW)	1
202	66 : 01 : 35	UInt	Power factor n-1 (x 0.01)	1
203-209	66 : 01 : 36 - 66 : 01 : 3C	UInt	(Not significant)	

## N-2 Fault Statistics

The n-2 fault statistics are completed by variables at register addresses 360 to 370.

Modbus/TCP (Register Addresses)	EtherNet/IP (Object Addresses)	Variable Type	Read-only Variables	Note (see page 100 )
210	66 : 01 : 3D	UInt	Fault code n-2	
211	66 : 01 : 3E	UInt	Motor full load current ratio n-2 (% FLC max)	
212	66 : 01 : 3F	UInt	Thermal capacity level n-2 (% trip level)	
213	66 : 01 : 40	UInt	Average current ratio n-2 (% FLC)	
214	66 : 01 : 41	UInt	L1 current ratio n-2 (% FLC)	
215	66 : 01 : 42	UInt	L2 current ratio n-2 (% FLC)	
216	66 : 01 : 43	UInt	L3 current ratio n-2 (% FLC)	
217	66 : 01 : 44	UInt	Ground current ratio n-2 (x 0.1 % FLC min)	

Modbus/TCP (Register Addresses)	EtherNet/IP (Object Addresses)	Variable Type	Read-only Variables	Note ( <a href="#">see page 100</a> )
218	66 : 01 : 45	UInt	Full load current max n-2 (x 0.1 A)	
219	66 : 01 : 46	UInt	Current phase imbalance n-2 (%)	
220	66 : 01 : 47	UInt	Frequency n-2 (x 0.1 Hz)	
221	66 : 01 : 48	UInt	Motor temperature sensor n-2 (x 0.1 Ω)	
222-225	66 : 01 : 49 - 66 : 01 : 4C	Word[4]	Date and time n-2 (See DT_DateTime ( <a href="#">see page 103</a> ))	
226	66 : 01 : 4D	UInt	Average voltage n-2 (V)	1
227	66 : 01 : 4E	UInt	L3-L1 voltage n-2 (V)	1
228	66 : 01 : 4F	UInt	L1-L2 voltage n-2 (V)	1
229	66 : 01 : 50	UInt	L2-L3 voltage n-2 (V)	1
230	66 : 01 : 51	UInt	Voltage phase imbalance n-2 (%)	1
231	66 : 01 : 52	UInt	Active power n-2 (x 0.1 kW)	1
232	66 : 01 : 53	UInt	Power factor n-2 (x 0.01)	1
233-239	66 : 01 : 54 - 66 : 01 : 5A		( <i>Not significant</i> )	

### N-3 Fault Statistics

The n-3 fault statistics are completed by variables at register addresses 390 to 400.

Modbus/TCP (Register Addresses)	EtherNet/IP (Object Addresses)	Variable Type	Read-only Variables	Note ( <a href="#">see page 100</a> )
240	66 : 01 : 5B	UInt	Fault code n-3	
241	66 : 01 : 5C	UInt	Motor full load current ratio n-3 (% FLC max)	
242	66 : 01 : 5D	UInt	Thermal capacity level n-3 (% trip level)	
243	66 : 01 : 5E	UInt	Average current ratio n-3 (% FLC)	
244	66 : 01 : 5F	UInt	L1 current ratio n-3 (% FLC)	
245	66 : 01 : 60	UInt	L2 current ratio n-3 (% FLC)	
246	66 : 01 : 61	UInt	L3 current ratio n-3 (% FLC)	
247	66 : 01 : 62	UInt	Ground current ratio n-3 (x 0.1 % FLC min)	
248	66 : 01 : 63	UInt	Full load current max n-3 (0.1 A)	
249	66 : 01 : 64	UInt	Current phase imbalance n-3 (%)	
250	66 : 01 : 65	UInt	Frequency n-3 (x 0.1 Hz)	
251	66 : 01 : 66	UInt	Motor temperature sensor n-3 (x 0.1 Ω)	
252-255	66 : 01 : 67 - 66 : 01 : 6A	Word[4]	Date and time n-3 (See DT_DateTime ( <a href="#">see page 103</a> ))	
256	66 : 01 : 6B	UInt	Average voltage n-3 (V)	1
257	66 : 01 : 6C	UInt	L3-L1 voltage n-3 (V)	1
258	66 : 01 : 6D	UInt	L1-L2 voltage n-3 (V)	1
259	66 : 01 : 6E	UInt	L2-L3 voltage n-3 (V)	1
260	66 : 01 : 6F	UInt	Voltage phase imbalance n-3 (%)	1
261	66 : 01 : 70	UInt	Active power n-3 (x 0.1 kW)	1
262	66 : 01 : 71	UInt	Power factor n-3 (x 0.01)	1
263-269	66 : 01 : 72 - 66 : 01 : 78		( <i>Not significant</i> )	

#### N-4 Fault Statistics

The n-4 fault statistics are completed by variables at register addresses 420 to 430.

Modbus/TCP (Register Addresses)	EtherNet/IP (Object Addresses)	Variable Type	Read-only Variables	Note (see page 100)
270	66 : 01 : 79	UInt	Fault code n-4	
271	66 : 01 : 7A	UInt	Motor full load current ratio n-4 (% FLC max)	
272	66 : 01 : 7B	UInt	Thermal capacity level n-4 (% trip level)	
273	66 : 01 : 7C	UInt	Average current ratio n-4 (% FLC)	
274	66 : 01 : 7D	UInt	L1 current ratio n-4 (% FLC)	
275	66 : 01 : 7E	UInt	L2 current ratio n-4 (% FLC)	
276	66 : 01 : 7F	UInt	L3 current ratio n-4 (% FLC)	
277	66 : 01 : 80	UInt	Ground current ratio n-4 (x 0.1 % FLC min)	
278	66 : 01 : 81	UInt	Full load current max n-4 (x 0.1 A)	
279	66 : 01 : 82	UInt	Current phase imbalance n-4 (%)	
280	66 : 01 : 83	UInt	Frequency n-4 (x 0.1 Hz)	
281	66 : 01 : 84	UInt	Motor temperature sensor n-4 (x 0.1 Ω)	
282-285	66 : 01 : 85 - 66 : 01 : 88	Word[4]	Date and time n-4 (See DT_DateTime (see page 103))	
286	66 : 01 : 89	UInt	Average voltage n-4 (V)	1
287	66 : 01 : 8A	UInt	L3-L1 voltage n-4 (V)	1
288	66 : 01 : 8B	UInt	L1-L2 voltage n-4 (V)	1
289	66 : 01 : 8C	UInt	L2-L3 voltage n-4 (V)	1
290	66 : 01 : 8D	UInt	Voltage phase imbalance n-4 (%)	1
291	66 : 01 : 8E	UInt	Active power n-4 (x 0.1 kW)	1
292	66 : 01 : 8F	UInt	Power factor n-4 (x 0.01)	1
293-299	66 : 01 : 90 - 66 : 01 : 96		(Not significant)	

#### Last Fault (n-0) Statistics Extension

The last fault main statistics are listed at register addresses 150 to 179.

Modbus/TCP (Register Addresses)	EtherNet/IP (Object Addresses)	Variable Type	Read-only Variables	Note (see page 100)
300-301	67 : 01 : 01 - 67 : 01 : 02	UDInt	Average current n-0 (x 0.01 A)	
302-303	67 : 01 : 03 - 67 : 01 : 04	UDInt	L1 current n-0 (x 0.01 A)	
304-305	67 : 01 : 05 - 67 : 01 : 06	UDInt	L2 current n-0 (x 0.01 A)	
306-307	67 : 01 : 07 - 67 : 01 : 08	UDInt	L3 current n-0 (x 0.01 A)	
308-309	67 : 01 : 09 - 67 : 01 : 0A	UDInt	Ground current n-0 (mA)	
310	67 : 01 : 0B	UInt	Motor temperature sensor degree n-0 (°C)	

## N-1 Fault Statistics Extension

The n-1 fault main statistics are listed at register addresses 180 to 209.

Modbus/TCP (Register Addresses)	EtherNet/IP (Object Addresses)	Variable Type	Read-only Variables	Note (see page 100)
330-331	67 : 01 : 1F - 67 : 01 : 20	UDInt	Average current n-1 (x 0.01 A)	
332-333	67 : 01 : 21 - 67 : 01 : 22	UDInt	L1 current n-1 (x 0.01 A)	
334-335	67 : 01 : 23 - 67 : 01 : 24	UDInt	L2 current n-1 (x 0.01 A)	
336-337	67 : 01 : 25 - 67 : 01 : 26	UDInt	L3 current n-1 (x 0.01 A)	
338-339	67 : 01 : 27 - 67 : 01 : 28	UDInt	Ground current n-1 (mA)	
340	67 : 01 : 29	UInt	Motor temperature sensor degree n-1 (°C)	

## N-2 Fault Statistics Extension

The n-2 fault main statistics are listed at register addresses 210 to 239.

Modbus/TCP (Register Addresses)	EtherNet/IP (Object Addresses)	Variable Type	Read-only Variables	Note (see page 100)
360-361	67 : 01 : 3D - 67 : 01 : 3E	UDInt	Average current n-2 (x 0.01 A)	
362-363	67 : 01 : 3F - 67 : 01 : 40	UDInt	L1 current n-2 (x 0.01 A)	
364-365	67 : 01 : 41 - 67 : 01 : 42	UDInt	L2 current n-2 (x 0.01 A)	
366-367	67 : 01 : 43 - 67 : 01 : 44	UDInt	L3 current n-2 (x 0.01 A)	
368-369	67 : 01 : 45 - 67 : 01 : 46	UDInt	Ground current n-2 (mA)	
370	67 : 01 : 47	UInt	Motor temperature sensor degree n-2 (°C)	

## N-3 Fault Statistics Extension

The n-3 fault main statistics are listed at register addresses 240 to 269.

Modbus/TCP (Register Addresses)	EtherNet/IP (Object Addresses)	Variable Type	Read-only Variables	Note (see page 100 )
390-391	67 : 01 : 5B - 67 : 01 : 5C	UDInt	Average current n-3 (x 0.01 A)	
392-393	67 : 01 : 5D - 67 : 01 : 5E	UDInt	L1 current n-3 (x 0.01 A)	
394-395	67 : 01 : 5F - 67 : 01 : 60	UDInt	L2 current n-3 (x 0.01 A)	
396-397	67 : 01 : 61 - 67 : 01 : 62	UDInt	L3 current n-3 (x 0.01 A)	
398-399	67 : 01 : 63 - 67 : 01 : 64	UDInt	Ground current n-3 (mA)	
400	67 : 01 : 65	UInt	Motor temperature sensor degree n-3 (°C)	

#### N-4 Fault Statistics Extension

The n-4 fault main statistics are listed at register addresses 270 to 299.

Modbus/TCP (Register Addresses)	EtherNet/IP (Object Addresses)	Variable Type	Read-only Variables	Note (see page 100 )
420-421	67 : 01 : 79 - 67 : 01 : 7A	UDInt	Average current n-4 (x 0.01 A)	
422-423	67 : 01 : 7B - 67 : 01 : 7C	UDInt	L1 current n-4 (x 0.01 A)	
424-425	67 : 01 : 7D - 67 : 01 : 7E	UDInt	L2 current n-4 (x 0.01 A)	
426-427	67 : 01 : 7F - 67 : 01 : 80	UDInt	L3 current n-4 (x 0.01 A)	
428-429	67 : 01 : 81 - 67 : 01 : 82	UDInt	Ground current n-4 (mA)	
430	67 : 01 : 83	UInt	Motor temperature sensor degree n-4 (°C)	

## Monitoring Variables

### Monitoring Overview

Monitoring variables are grouped according to the following criteria:

Monitoring Variable groups	Modbus/TCP (Register Addresses)	EtherNet/IP (Object Addresses)
Monitoring of faults	450-454	68 : 01 : 01 to 68 : 01 : 05
Monitoring of status	455-459	68 : 01 : 06 to 68 : 01 : 0A
Monitoring of warnings	460-464	68 : 01 : 0B to 68 : 01 : 0F
Monitoring of measurements	465-539	68 : 01 : 10 to 68 : 01 : 5A
Extended monitoring for communication	2000-2099	82 : 01 : 01 to 82 : 01 : 64

### Monitoring of Faults

Variables for monitoring of faults are described in the following table:

Modbus/TCP (Register Addresses)	EtherNet/IP (Object Addresses)	Variable Type	Read-only Variables	Note (see page 100)
450	68 : 01 : 01	UInt	Minimum wait time (s)	
451	68 : 01 : 02	UInt	Fault code (code of the last fault, or of the fault that takes priority) (See DT_FaultCode (see page 104).)	
452	68 : 01 : 03	Word	Fault register 1 <i>bits 0-1 (Reserved)</i> bit 2 Ground current fault bit 3 Thermal overload fault bit 4 Long start fault bit 5 Jam fault bit 6 Current phase imbalance fault bit 7 Undercurrent fault <i>bit 8 (Reserved)</i> bit 9 Test fault bit 10 HMI port fault bit 11 Controller internal fault bit 12 Internal port fault <i>bit 13 (Not significant)</i> bit 14 Network port config fault bit 15 Network port fault	

Modbus/TCP (Register Addresses)	EtherNet/IP (Object Addresses)	Variable Type	Read-only Variables	Note (see page 10 0)
453	68 : 01 : 04	Word	Fault register 2 bit 0 External system fault bit 1 Diagnostic fault bit 2 Wiring fault bit 3 Overcurrent fault bit 4 Current phase loss fault bit 5 Current phase reversal fault bit 6 Motor temperature sensor fault bit 7 Voltage phase imbalance fault bit 8 Voltage phase loss fault bit 9 Voltage phase reversal fault bit 10 Undervoltage fault bit 11 Overvoltage fault bit 12 Underpower fault bit 13 Overpower fault bit 14 Under power factor fault bit 15 Over power factor fault	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
454	68 : 01 : 05	Word	Fault register 3 bit 0 LTME configuration fault <i>bits 1-15 (Reserved)</i>	

### Monitoring of Status

Variables for monitoring of status are described below:

Modbus/TCP (Register Addresses)	EtherNet/IP (Object Addresses)	Variable Type	Read-only Variables	Note (see page 10 0)
455	68 : 01 : 06	Word	System status register 1 bit 0 System ready bit 1 System on bit 2 System fault bit 3 System warning bit 4 System tripped bit 5 Fault reset authorized bit 6 Controller power bit 7 Motor running (with detection of a current, if greater than 10% FLC) bit 8-13 Motor average current ratio 32 = 100% FLC - 63 = 200% FLC bit 14 In remote bit 15 Motor starting (start in progress) 0 = descending current is less than 150% FLC 1 = ascending current is greater than 10% FLC	

Modbus/TCP (Register Addresses)	EtherNet/IP (Object Addresses)	Variable Type	Read-only Variables	Note (see page 10 0)
456	68 : 01 : 07	Word	System status register 2 bit 0 Auto-reset active <i>bit 1 (Not significant)</i> bit 2 Fault power cycle requested bit 3 Motor restart time undefined bit 4 Rapid cycle lockout bit 5 Load shedding bit 6 Motor speed 0 = FLC1 setting is used 1 = FLC2 setting is used bit 7 HMI port comm loss bit 8 Network port comm loss bit 9 Motor transition lockout <i>bits 10-15 (Not significant)</i>	1
457	68 : 01 : 08	Word	Logic inputs status bit 0 Logic input 1 bit 1 Logic input 2 bit 2 Logic input 3 bit 3 Logic input 4 bit 4 Logic input 5 bit 5 Logic input 6 bit 6 Logic input 7 bit 7 Logic input 8 bit 8 Logic input 9 bit 9 Logic input 10 bit 10 Logic input 11 bit 11 Logic input 12 bit 12 Logic input 13 bit 13 Logic input 14 bit 14 Logic input 15 bit 15 Logic input 16	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
458	68 : 01 : 09	Word	Logic outputs status bit 0 Logic output 1 bit 1 Logic output 2 bit 2 Logic output 3 bit 3 Logic output 4 bit 4 Logic output 5 bit 5 Logic output 6 bit 6 Logic output 7 bit 7 Logic output 8 <i>bits 8-15 (Reserved)</i>	1 1 1 1 1

Modbus/TCP (Register Addresses)	EtherNet/IP (Object Addresses)	Variable Type	Read-only Variables	Note (see page 10 0)
459	68 : 01 : 0A	Word	I/O status bit 0 Input 1 bit 1 Input 2 bit 2 Input 3 bit 3 Input 4 bit 4 Input 5 bit 5 Input 6 bit 6 Input 7 bit 7 Input 8 bit 8 Input 9 bit 9 Input 10 bit 10 Input 11 bit 11 Input 12 bit 12 Output 1 (13-14) bit 13 Output 2 (23-24) bit 14 Output 3 (33-34) bit 15 Output 4 (95-96, 97-98)	

### Monitoring of Warnings

Variables for monitoring of warnings are described in the following table:

Modbus/TCP (Register Addresses)	EtherNet/IP (Object Addresses)	Variable Type	Read-only Variables	Note (see page 10 0)
460	68 : 01 : 0B	UInt	Warning code (See DT_WarningCode (see page 106).)	
461	68 : 01 : 0C	Word	Warning register 1 <i>bits 0-1 (Not significant)</i> bit 2 Ground current warning bit 3 Thermal overload warning <i>bit 4 (Not significant)</i> bit 5 Jam warning bit 6 Current phase imbalance warning bit 7 Undercurrent warning <i>bits 8-9 (Not significant)</i> bit 10 HMI port warning bit 11 Controller internal temperature warning <i>bits 12-14 (Not significant)</i> bit 15 Network port warning	

Modbus/TCP (Register Addresses)	EtherNet/IP (Object Addresses)	Variable Type	Read-only Variables	Note (see page 10 0)
462	68 : 01 : 0D	Word	Warning register 2 <i>bit 0 (Not significant)</i> bit 1 Diagnostic warning <i>bit 2 (Reserved)</i> bit 3 Overcurrent warning bit 4 Current phase loss warning bit 5 Current phase reversal warning bit 6 Motor temperature sensor warning bit 7 Voltage phase imbalance warning bit 8 Voltage phase loss warning <i>bit 9 (Not significant)</i> bit 10 Undervoltage warning bit 11 Overvoltage warning bit 12 Underpower warning bit 13 Overpower warning bit 14 Under power factor warning bit 15 Over power factor warning	1 1
463	68 : 01 : 0E	Word	Warning register 3 bit 0 LTME configuration warning <i>bits 1-15 (Reserved)</i>	
464	68 : 01 : 0F	UInt	Motor temperature sensor degree (°C)	

### Monitoring of Measurements

Variables for monitoring of measurements are described below:

Modbus/TCP (Register Addresses)	EtherNet/IP (Object Addresses)	Variable Type	Read-only Variables	Note (see page 10 0)
465	68 : 01 : 10	UInt	Thermal capacity level (% trip level)	
466	68 : 01 : 11	UInt	Average current ratio (% FLC)	
467	68 : 01 : 12	UInt	L1 current ratio (% FLC)	
468	68 : 01 : 13	UInt	L2 current ratio (% FLC)	
469	68 : 01 : 14	UInt	L3 current ratio (% FLC)	
470	68 : 01 : 15	UInt	Ground current ratio (x 0.1 % FLC min)	
471	68 : 01 : 16	UInt	Current phase imbalance (%)	
472	68 : 01 : 17	Int	Controller internal temperature (°C)	
473	68 : 01 : 18	UInt	Controller config checksum	
474	68 : 01 : 19	UInt	Frequency (x 0.01 Hz)	2
475	68 : 01 : 1A	UInt	Motor temperature sensor (x 0.1 Ω)	
476	68 : 01 : 1B	UInt	Average voltage (V)	1
477	68 : 01 : 1C	UInt	L3-L1 voltage (V)	1
478	68 : 01 : 1D	UInt	L1-L2 voltage (V)	1
479	68 : 01 : 1E	UInt	L2-L3 voltage (V)	1
480	68 : 01 : 1F	UInt	Voltage phase imbalance (%)	1
481	68 : 01 : 20	UInt	Power factor (x 0.01)	1
482	68 : 01 : 21	UInt	Active power (x 0.1 kW)	1
483	68 : 01 : 22	UInt	Reactive power (x 0.1 kVAR)	1

Modbus/TCP (Register Addresses)	EtherNet/IP (Object Addresses)	Variable Type	Read-only Variables	Note (see page 100)
484	68 : 01 : 23	Word	Auto restart status register bit 0 Voltage dip occurred bit 1 Voltage dip detection bit 2 Auto restart immediate condition bit 3 Auto restart delayed condition bit 4 Auto restart manual condition <i>bits 5-15 (Not significant)</i>	
485	68 : 01 : 24	Word	Controller last power OFF duration	
486-489	68 : 01 : 25 - 68 : 01 : 28		<i>(Not significant)</i>	
490	68 : 01 : 29	Word	Network port monitoring bit 0 Network port communicating bit 1 Network port connected bit 2 Network port self-testing bit 3 Network port self-detecting bit 4 Network port bad config <i>bits 5-15 (Not significant)</i>	
491	68 : 01 : 2A	UInt	Network port baud rate (See DT_ExtBaudRate (see page 104).)	
492	68 : 01 : 2B		<i>(Not significant)</i>	
493	68 : 01 : 2C	UInt	Network port parity (See DT_ExtParity (see page 104).)	
494-499	68 : 01 : 2D - 68 : 01 : 32		<i>(Not significant)</i>	
500-501	68 : 01 : 33 - 68 : 01 : 34	UDInt	Average current (x 0.01 A)	
502-503	68 : 01 : 35 - 68 : 01 : 36	UDInt	L1 current (x 0.01 A)	
504-505	68 : 01 : 37 - 68 : 01 : 38	UDInt	L2 current (x 0.01 A)	
506-507	68 : 01 : 39 - 68 : 01 : 3A	UDInt	L3 current (x 0.01 A)	
508-509	68 : 01 : 3B - 68 : 01 : 3C	UDInt	Ground current (mA)	
510	68 : 01 : 3D	UInt	Controller port ID	
511	68 : 01 : 3E	UInt	Time to trip (x 1 s)	
512	68 : 01 : 3F	UInt	Motor last start current ratio (% FLC)	
513	68 : 01 : 40	UInt	Motor last start duration (s)	
514	68 : 01 : 41	UInt	Motor starts per hour count	
515	68 : 01 : 42	Word	Phase imbalances register bit 0 L1 current highest imbalance bit 1 L2 current highest imbalance bit 2 L3 current highest imbalance bit 3 L1-L2 voltage highest imbalance bit 4 L2-L3 voltage highest imbalance bit 5 L3-L1 voltage highest imbalance <i>bits 6-15 (Not significant)</i>	1 1 1
516-523	68 : 01 : 43 - 68 : 01 : 5A		<i>(Reserved)</i>	
524-539	68 : 01 : 4B - 68 : 01 : 5A		<i>(Forbidden)</i>	

## Extended Monitoring for Communication

Variables for extended monitoring for communication are described in the following table:

Modbus/TCP (Register Addresses)	EtherNet/IP (Object Addresses)	Variable Type	Read-only Variables	Note (see page 10 0)
2000-2001	82 : 01 : 01 - 82 : 01 : 02	Word[2]	Ethernet Basic HW Diag Validity Register 2000: bit 0: Ethernet services available (1=Yes) bit 1: Ethernet global status available (1=Yes) bits 2-14: ( <i>Reserved</i> ) bit 15: Ethernet field extended 1 available (1=Yes) Register 2001: bit 0: Ethernet IP assignment mode available (1=Yes) bit 1: Ethernet device name available (1=Yes) bit 2: Ethernet MB messages received counter available (1=Yes) bit 3: Ethernet MB messages sent counter available (1=Yes) bit 4: Ethernet MB error messages sent counter available (1=Yes) bit 5: Ethernet opened servers counter available (1=Yes)	
			bit 6: Ethernet opened clients counter available (1=Yes) bit 7: Ethernet transmitted correct frames counter available (1=Yes) bit 8: Ethernet received correct frames counter available (1=Yes) bit 9: Ethernet frame format available (1=Yes) bit 10: Ethernet MAC address available (1=Yes) bit 11: Ethernet gateway available (1=Yes) bit 12: Ethernet subnet mask available (1=Yes) bit 13: Ethernet IP address available (1=Yes) bit 14: Ethernet services status available (1=Yes) bit 15: Ethernet field extended 2 available (1=Yes)	
2002	82 : 01 : 03	Word	Ethernet global status bits 0-1: Ethernet global status 1= at least 1 enabled service is operating with an unresolved error 2 = all enabled services are operating without error bits 2-15: ( <i>Reserved</i> )	
2003	82 : 01 : 04	Word	Ethernet services validity bit 0: Ethernet port 502 messaging available (1=Yes) bits 1-15: ( <i>Reserved</i> )	
2004	82 : 01 : 05	Word	Ethernet services status bits 0-2: Ethernet port 502 messaging 1 = idle 2 = operational bits 3-15: ( <i>Reserved</i> )	
2005-2006	82 : 01 : 06 - 82 : 01 : 07	UDInt	Ethernet IP address Register 2005: bits 0-7: first byte bits 8-15: second byte Register 2006: bits 0-7: third byte bits 8-15: fourth byte	

Modbus/TCP (Register Addresses)	EtherNet/IP (Object Addresses)	Variable Type	Read-only Variables	Note (see page 10 0)
2007-2008	82 : 01 : 08 - 82 : 01 : 09	UDInt	Ethernet subnet mask  Register 2007:  bits 0-7: first byte  bits 8-15: second byte  Register 2008:  bits 0-7: third byte  bits 8-15: fourth byte	
2009-2010	82 : 01 : 0A - 82 : 01 : 0B	UDInt	Ethernet gateway address  Register 2009:  bits 0-7: first byte  bits 8-15: second byte  Register 2010:  bits 0-7: third byte  bits 8-15: fourth byte	
2011-2013	82 : 01 : 0C - 82 : 01 : 0E	Word[3]	Ethernet MAC Address  Register 2011:  bits 0-7: first hex byte  bits 8-15: second hex byte  Register 2012:  bits 0-7: third hex byte  bits 8-15: fourth hex byte  Register 2013:  bits 0-7: fifth hex byte  bits 8-15: sixth hex byte	
2014-2016	82 : 01 : 0F- 82 : 01 : 11	Word[3]	Ethernet II framing registers  Register 2014:  bit 0: Ethernet II framing supported (1=Yes) bit 1: Ethernet II framing receiver supported (1=Yes) bit 2: Ethernet II framing sender supported (1=Yes) bit 3: Ethernet auto-detection supported (1=Yes) bits 4-15: ( <i>Reserved</i> )  Register 2015:  bit 0: Ethernet II framing configured (1=Yes) bit 1: Ethernet II framing receiver configured (1=Yes) bit 2: Ethernet II framing sender configured (1=Yes) bit 3: Ethernet auto-detection configured (1=Yes) bits 4-15: ( <i>Reserved</i> )  Register 2016:  bit 0: Ethernet II framing operational (1=Yes) bit 1: Ethernet II framing receiver operational (1=Yes) bit 2: Ethernet II framing sender operational (1=Yes) bit 3: Ethernet auto-detection operational (1=Yes) bits 4-15: ( <i>Reserved</i> )	
2017-2018	82 : 01 : 12 - 82 : 01 : 13	UDInt	Ethernet received correct frames counter	
2019-2020	82 : 01 : 14 - 82 : 01 : 15	UDInt	Ethernet transmitted correct frames counter	
2021	82 : 01 : 16	UInt	Ethernet opened clients counter	
2022	82 : 01 : 17	UInt	Ethernet opened servers counter	

Modbus/TCP (Register Addresses)	EtherNet/IP (Object Addresses)	Variable Type	Read-only Variables	Note (see page 10 0)
2023-2024	82 : 01 : 18	UDInt	Ethernet MB error messages sent counter	
2025-2026	82 : 01 : 1A - 82 : 01 : 1B	UDInt	Ethernet MB messages sent counter	
2027-2028	82 : 01 : 1C - 82 : 01 : 1D	UDInt	Ethernet MB messages received counter	
2029-2036	82 : 01 : 1E - 82 : 01 : 25	Word[8]	Ethernet device name	
2037	82 : 01 : 26	Word	Ethernet IP assignment capability bit 0: Ethernet IP served by name available (1 = Yes) bit 1: Ethernet IP served by MAC BootP available (1 = Yes) bit 2: Ethernet IP served by MAC DHCP available (1 = Yes) bit 3: Ethernet IP served by stored assignment available (1 = Yes) bits 4-15: <i>(Reserved)</i>	
2038	82 : 01 : 27	Word	Ethernet IP assignment operational bit 0: Ethernet IP served by name available (1 = Yes) bit 1: Ethernet IP served by MAC BootP available (1 = Yes) bit 2: Ethernet IP served by MAC DHCP available (1 = Yes) bit 3: Ethernet IP served by stored assignment available (1 = Yes) bits 4-15: <i>(Reserved)</i>	
2039-2099	82 : 01 : 28 - 82 : 01 : 64		<i>(Reserved)</i>	

## Configuration Variables

### Configuration Overview

Configuration variables are grouped according to the following criteria

Configuration Variable groups	Modbus/TCP (Register Addresses)	EtherNet/IP (Object Addresses)
Configuration	540-649	69 : 01 : 01 to 6A : 01 : 32
Setting	650-699	6B : 01 : 01 to 6B : 01 : 32
Extended settings for communication	3000-3120	96 : 01 : 01 to 96 : 01 : 79

### Configuration Variables

The configuration variables are described in the following table:

Modbus/TCP (Register Addresses)	EtherNet/IP (Object Addresses)	Variable Type	Read/Write Variables	Note (see page 100)
540	69 : 01 : 01	UInt	Motor operating mode 2 = 2-wire overload 3 = 3-wire overload 4 = 2-wire independent 5 = 3-wire independent 6 = 2-wire reverser 7 = 3-wire reverser 8 = 2-wire 2-step 9 = 3-wire 2-step 10 = 2-wire 2-speed 11 = 3-wire 2-speed 256-511 = Custom logic program (0-255)	B
541	69 : 01 : 02	UInt	Motor transition timeout (s)	
542-544	69 : 01 : 03 - 69 : 01 : 05		(Reserved)	
545	69 : 01 : 06	Word	Controller AC inputs setting register bits 0-3 Controller AC logic inputs configuration (See DT_ACInputSetting (see page 102)) bits 4-15 (Reserved)	
546	69 : 01 : 07	UInt	Thermal overload setting bits 0-2 Motor temperature sensor type: 0 = None 1 = PTC binary 2 = PT100 3 = PTC analog 4 = NTC analog bits 3-4 Thermal overload mode: 0 = Definite 2 = Inverse thermal bits 5-15 (Reserved)	B
547	69 : 01 : 08	UInt	Thermal overload fault definite timeout (s)	
548	69 : 01 : 09		(Reserved)	
549	69 : 01 : 0A	UInt	Motor temperature sensor fault threshold (x 0.1 Ω)	
550	69 : 01 : 0B	UInt	Motor temperature sensor warning threshold (x 0.1 Ω)	
551	69 : 01 : 0C	UInt	Motor temperature sensor fault threshold degree (°C)	
552	69 : 01 : 0D	UInt	Motor temperature sensor warning threshold degree (°C)	
553	69 : 01 : 0E	UInt	Rapid cycle lockout timeout (s)	
554	69 : 01 : 0F		(Reserved)	
555	69 : 01 : 10	UInt	Current phase loss timeout (x 0.1 s)	
556	69 : 01 : 11	UInt	Overcurrent fault timeout (s)	
557	69 : 01 : 12	UInt	Overcurrent fault threshold (% FLC)	
558	69 : 01 : 13	UInt	Overcurrent warning threshold (% FLC)	

Modbus/TCP (Register Addresses)	EtherNet/IP (Object Addresses)	Variable Type	Read/Write Variables	Note (see page 10 0)
559	69 : 01 : 14	Word	Ground current fault configuration	B
			bit 0 Ground current mode	
			bits 1-15 ( <i>Reserved</i> )	
560	69 : 01 : 15	UInt	Ground CT primary	
561	69 : 01 : 16	UInt	Ground CT secondary	
562	69 : 01 : 17	UInt	External ground current fault timeout (x 0.01 s)	
563	69 : 01 : 18	UInt	External ground current fault threshold (x 0.01 A)	
564	69 : 01 : 19	UInt	External ground current warning threshold (x 0.01 A)	
565	69 : 01 : 1A	UInt	Motor nominal voltage (V)	1
566	69 : 01 : 1B	UInt	Voltage phase imbalance fault timeout starting (x 0.1 s)	1
567	69 : 01 : 1C	UInt	Voltage phase imbalance fault timeout running (x 0.1 s)	1
568	69 : 01 : 1D	UInt	Voltage phase imbalance fault threshold (% imb)	1
569	69 : 01 : 1E	UInt	Voltage phase imbalance warning threshold (% imb)	1
570	69 : 01 : 1F	UInt	Oversupply fault timeout (x 0.1 s)	1
571	69 : 01 : 20	UInt	Oversupply fault threshold (% Vnom)	1
572	69 : 01 : 21	UInt	Oversupply warning threshold (% Vnom)	1
573	69 : 01 : 22	UInt	Undersupply fault timeout (x 0.1 s)	1
574	69 : 01 : 23	UInt	Undersupply fault threshold (% Vnom)	1
575	69 : 01 : 24	UInt	Undersupply warning threshold (% Vnom)	1
576	69 : 01 : 25	UInt	Voltage phase loss fault timeout (x 0.1 s)	1
577	69 : 01 : 26	Word	Voltage dip setting	1
			bit 0 Load shedding enable	
			bit 1 Auto-restart enable	
			bits 2-15 ( <i>Reserved</i> )	
578	69 : 01 : 27	UInt	Load shedding timeout (s)	1
579	69 : 01 : 28	UInt	Voltage dip threshold (% Vnom)	1
580	69 : 01 : 29	UInt	Voltage dip restart timeout (s)	1
581	69 : 01 : 2A	UInt	Voltage dip restart threshold (% Vnom)	1
582	69 : 01 : 2B	UInt	Auto restart immediate timeout (x 0.1 s)	
583	69 : 01 : 2C	UInt	Motor nominal power (x 0.1 kW)	1
584	69 : 01 : 2D	UInt	Overpower fault timeout (s)	1
585	69 : 01 : 2E	UInt	Overpower fault threshold (% Pnom)	1
586	69 : 01 : 2F	UInt	Overpower warning threshold (% Pnom)	1
587	69 : 01 : 30	UInt	Underpower fault timeout (s)	1
588	69 : 01 : 31	UInt	Underpower fault threshold (% Pnom)	1
589	69 : 01 : 32	UInt	Underpower warning threshold (% Pnom)	1
590	69 : 01 : 33	UInt	Under power factor fault timeout (x 0.1 s)	1
591	69 : 01 : 34	UInt	Under power factor fault threshold (x 0.01 PF)	1
592	69 : 01 : 35	UInt	Under power factor warning threshold (x 0.01 PF)	1
593	69 : 01 : 36	UInt	Over power factor fault timeout (x 0.1 s)	1
594	69 : 01 : 37	UInt	Over power factor fault threshold (x 0.01 PF)	1
595	69 : 01 : 38	UInt	Over power factor warning threshold (x 0.01 PF)	1
596	69 : 01 : 39	UInt	Auto restart delayed timeout (s)	
597-599	69 : 01 : 3A - 69 : 01 : 3C		( <i>Reserved</i> )	
600	6A : 01 : 01		( <i>Not significant</i> )	

Modbus/TCP (Register Addresses)	EtherNet/IP (Object Addresses)	Variable Type	Read/Write Variables	Note <i>(see page 100)</i>
601	6A : 01 : 02	Word	General configuration register 1 bit 0 Controller system config required: 0 = exit the configuration menu 1 = go to the configuration menu bits 1-7 <i>(Reserved)</i> Control mode configuration, bits 8-10 (one bit is set to 1): bit 8 Config via HMI keypad enable bit 9 Config via HMI engineering tool enable bit 10 Config via network port enable bit 11 Motor star-delta bit 12 Motor phases sequence: 0 = A B C 1 = A C B bits 13-14 Motor phases (See DT_PhaseNumber <i>(see page 106)</i> ) bit 15 Motor auxiliary fan cooled (factory setting = 0)	A B
602	6A : 01 : 03	Word	General configuration register 2 bits 0-2 Fault reset mode (See DT_ResetMode <i>(see page 106)</i> ) bit 3 HMI port parity setting: 0 = none 1 = even (factory setting) bits 4-8 <i>(Reserved)</i> bit 9 HMI port endian setting bit 10 Network port endian setting bit 11 HMI motor status LED color bits 12-15 <i>(Reserved)</i>	C
603	6A : 01 : 04	UInt	HMI port address setting	
604	6A : 01 : 05	UInt	HMI port baud rate setting (Baud)	
605	6A : 01 : 06		<i>(Reserved)</i>	
606	6A : 01 : 07	UInt	Motor trip class (s)	
607	6A : 01 : 08		<i>(Reserved)</i>	
608	6A : 01 : 09	UInt	Thermal overload fault reset threshold (% trip level)	
609	6A : 01 : 0A	UInt	Thermal overload warning threshold (% trip level)	
610	6A : 01 : 0B	UInt	Internal ground current fault timeout (x 0.1 s)	
611	6A : 01 : 0C	UInt	Internal ground current fault threshold (% FLCmin)	
612	6A : 01 : 0D	UInt	Internal ground current warning threshold (% FLCmin)	
613	6A : 01 : 0E	UInt	Current phase imbalance fault timeout starting (x 0.1 s)	
614	6A : 01 : 0F	UInt	Current phase imbalance fault timeout running (x 0.1 s)	
615	6A : 01 : 10	UInt	Current phase imbalance fault threshold (% imb)	
616	6A : 01 : 11	UInt	Current phase imbalance warning threshold (% imb)	
617	6A : 01 : 12	UInt	Jam fault timeout (s)	
618	6A : 01 : 13	UInt	Jam fault threshold (% FLC)	
619	6A : 01 : 14	UInt	Jam warning threshold (% FLC)	
620	6A : 01 : 15	UInt	Undercurrent fault timeout (s)	
621	6A : 01 : 16	UInt	Undercurrent fault threshold (% FLC)	
622	6A : 01 : 17	UInt	Undercurrent warning threshold (% FLC)	
623	6A : 01 : 18	UInt	Long start fault timeout (s)	
624	6A : 01 : 19	UInt	Long start fault threshold (% FLC)	
625	6A : 01 : 1A		<i>(Reserved)</i>	

Modbus/TCP (Register Addresses)	EtherNet/IP (Object Addresses)	Variable Type	Read/Write Variables	Note (see page 10 0)
626	6A : 01 : 1B	UInt	HMI display contrast setting	
			bits 0-7 HMI display contrast setting	
			HMI display brightness setting	
627	6A : 01 : 1C	UInt	Contactor rating (0.1 A)	
628	6A : 01 : 1D	UInt	Load CT primary	B
629	6A : 01 : 1E	UInt	Load CT secondary	B
630	6A : 01 : 1F	UInt	Load CT multiple passes (passes)	B
631	6A : 01 : 20	Word	Fault enable register 1	
			bits 0-1 ( <i>Reserved</i> )	
			bit 2 Ground current fault enable	
			bit 3 Thermal overload fault enable	
			bit 4 Long start fault enable	
			bit 5 Jam fault enable	
			bit 6 Current phase imbalance fault enable	
			bit 7 Undercurrent fault enable	
			bit 8 ( <i>Reserved</i> )	
			bit 9 Self test enable 0 = disable 1 = enable (factory setting)	
			bit 10 HMI port fault enable	
			bits 11-14 ( <i>Reserved</i> )	
			bit 15 Network port fault enable	
632	6A : 01 : 21	Word	Warning enable register 1	
			bit 0 ( <i>Not significant</i> )	
			bit 1 ( <i>Reserved</i> )	
			bit 2 Ground current warning enable	
			bit 3 Thermal overload warning enable	
			bit 4 ( <i>Reserved</i> )	
			bit 5 Jam warning enable	
			bit 6 Current phase imbalance warning enable	
			bit 7 Undercurrent warning enable	
			bits 8-9 ( <i>Reserved</i> )	
			bit 10 HMI port warning enable	
			bit 11 Controller internal temperature warning enable	
			bits 12-14 ( <i>Reserved</i> )	
			bit 15 Network port warning enable	

Modbus/TCP (Register Addresses)	EtherNet/IP (Object Addresses)	Variable Type	Read/Write Variables	Note (see page 100)
633	6A : 01 : 22	Word	Fault enable register 2 bit 0 ( <i>Reserved</i> ) bit 1 Diagnostic fault enable bit 2 Wiring fault enable bit 3 Overcurrent fault enable bit 4 Current phase loss fault enable bit 5 Current phase reversal fault enable bit 6 Motor temperature sensor fault enable bit 7 Voltage phase imbalance fault enable bit 8 Voltage phase loss fault enable bit 9 Voltage phase reversal fault enable bit 10 Undervoltage fault enable bit 11 Overvoltage fault enable bit 12 Underpower fault enable bit 13 Overpower fault enable bit 14 Under power factor fault enable bit 15 Over power factor fault enable	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
634	6A : 01 : 23	Word	Warning enable register 2 bit 0 ( <i>Reserved</i> ) bit 1 Diagnostic warning enable bit 2 ( <i>Reserved</i> ) bit 3 Overcurrent warning enable bit 4 Current phase loss warning enable bit 5 ( <i>Reserved</i> ) bit 6 Motor temperature sensor warning enable bit 7 Voltage phase imbalance warning enable bit 8 Voltage phase loss warning enable bit 9 ( <i>Reserved</i> ) bit 10 Undervoltage warning enable bit 11 Overvoltage warning enable bit 12 Underpower warning enable bit 13 Overpower warning enable bit 14 Under power factor warning enable bit 15 Over power factor warning enable	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
635-636	6A : 01 : 24 - 6A : 01 : 25		( <i>Reserved</i> )	
637	6A : 01 : 26	UInt	Auto-reset attempts group 1 setting	
638	6A : 01 : 27	UInt	Auto-reset group 1 timeout	
639	6A : 01 : 28	UInt	Auto-reset attempts group 2 setting	
640	6A : 01 : 29	UInt	Auto-reset group 2 timeout	
641	6A : 01 : 2A	UInt	Auto-reset attempts group 3 setting	
642	6A : 01 : 2B	UInt	Auto-reset group 3 timeout	
643	6A : 01 : 2C	UInt	Motor step 1 to 2 timeout	
644	6A : 01 : 2D	UInt	Motor step 1 to 2 threshold	
645	6A : 01 : 2E	UInt	HMI port fallback setting (See DT_OutputFallbackStrategy (see page 106))	
646-649	6A : 01 : 2F - 6A : 01 : 32		( <i>Reserved</i> )	

## Setting Variables

The setting variables are described in the following table:

Modbus/TCP (Register Addresses)	EtherNet/IP (Object Addresses)	Variable Type	Read/Write Variables	Note (see page 10 0)
650	6B : 01 : 01	Word	HMI language setting register:	
			bit 0-4 HMI language setting (See DT_Language5 (see page 106))	
			bits 5-15 ( <i>Not significant</i> )	
651	6B : 01 : 02	Word	HMI display items register 1	
			bit 0 HMI display average current enable	
			bit 1 HMI display thermal capacity level enable	
			bit 2 HMI display L1 current enable	
			bit 3 HMI display L2 current enable	
			bit 4 HMI display L3 current enable	
			bit 5 HMI display ground current enable	
			bit 6 HMI display motor status enable	
			bit 7 HMI display current phase imbalance enable	
			bit 8 HMI display operating time enable	
			bit 9 HMI display I/O status enable	
			bit 10 HMI display reactive power enable	
			bit 11 HMI display frequency enable	
			bit 12 HMI display starts per hour enable	
			bit 13 HMI display control mode enable	
652	6B : 01 : 03	UInt	bit 14 HMI display start statistics enable	
			bit 15 HMI motor temperature sensor enable	
653	6B : 01 : 04	UInt	Motor full load current ratio, FLC1 (% FLCmax)	
654	6B : 01 : 05	Word	HMI display items register 2	
			bit 0 HMI display L1-L2 voltage enable	1
			bit 1 HMI display L2-L3 voltage enable	1
			bit 2 HMI display L3-L1 voltage enable	1
			bit 3 HMI display average voltage enable	1
			bit 4 HMI display active power enable	1
			bit 5 HMI display power consumption enable	1
			bit 6 HMI display power factor enable	1
			bit 7 HMI display average current ratio enable	
			bit 8 HMI display L1 current ratio enable	1
			bit 9 HMI display L2 current ratio enable	1
			bit 10 HMI display L3 current ratio enable	1
			bit 11 HMI display thermal capacity remaining enable	
			bit 12 HMI display time to trip enable	
			bit 13 HMI display voltage phase imbalance enable	1
655-658	6B : 01 : 06 - 6B : 01 : 09	Word[4]	bit 14 HMI display date enable	
			bit 15 HMI display time enable	
			Date and time setting (See DT_DateTime (see page 103))	
659	6B : 01 : 0A	Word[4]	HMI display items register 3	
			bit 0 HMI display temperature sensor degree CF	
			bits 1-15 ( <i>Reserved</i> )	
660-681	6B : 01 : 0B - 6B : 01 : 20		( <i>Reserved</i> )	

Modbus/TCP (Register Addresses)	EtherNet/IP (Object Addresses)	Variable Type	Read/Write Variables	Note (see page 10 0)
682	6B : 01 : 21	UInt	Network port fallback setting (See DT_OutputFallbackStrategy (see page 106))	
683	6B : 01 : 22	Word	Control setting register	
			bits 0-1 ( <i>Reserved</i> )	
			bits 2 Control remote local default mode (with LTMCU) 0 = remote 1 = local	
			bit 3 ( <i>Reserved</i> )	
			bit 4 Control remote local buttons enable (with LTMCU) 0 = disable 1 = enable	
			bits 5-6 Control remote channel setting (with LTMCU) 0 = network 1 = terminal strip 2 = HMI	
			bit 7 ( <i>Reserved</i> )	
			bit 8 Control local channel setting 0 = terminal strip 1 = HMI	
			bit 9 Control direct transition 0 = stop required during transition 1 = stop not required during transition	
			bit 10 Control transfer mode 0 = bump 1 = bumpless	
			bit 11 Stop terminal strip disable 0 = enable 1 = disable	
			bit 12 Stop HMI disable 0 = enable 1 = disable	
			bits 13-15 ( <i>Reserved</i> )	
684-694	6B : 01 : 23 - 6B : 01 : 2D		( <i>Reserved</i> )	
695	6B : 01 : 2E	UInt	Network port baud rate setting (Baud) (See DT_ExtBaudRate (see page 104))	
696	6B : 01 : 2F	UInt	Network port address setting	
697-699	6B : 01 : 30 - 6B : 01 : 32		( <i>Not significant</i> )	

### Extended Configuration Variables for Communication

The extended configuration variables are described in the following table:

Modbus/TCP (Register Addresses)	EtherNet/IP (Object Addresses)	Variable Type	Read/Write Variables	Note (see page 10 0)
3000-3001	96 : 01 : 01 - 96 : 01 : 02	UDInt	Ethernet IP address setting	
3002-3003	96 : 01 : 03 - 96 : 01 : 04	UDInt	Ethernet subnet mask setting	
3004-3005	96 : 01 : 05 - 96 : 01 : 06	UDInt	Ethernet gateway address setting	
3006-3009	96 : 01 : 07 - 96 : 01 : 09		( <i>Reserved</i> )	
3010-3011	96 : 01 : 0B - 96 : 01 : 0C	UDInt	Ethernet master IP address setting	

Modbus/TCP (Register Addresses)	EtherNet/IP (Object Addresses)	Variable Type	Read/Write Variables	Note (see page 10 0)
3012-3013	96 : 01 : 0D - 96 : 01 : 0E	UDInt	Ethernet SNMP manager address 1 setting	
3014-3015	96 : 01 : 0F - 96 : 01 : 10	UDInt	Ethernet SNMP manager address 2 setting	
3016-3031	96 : 01 : 11 - 96 : 01 : 20	Word[16]	Ethernet SNMP system name setting	
3032-3047	96 : 01 : 21 - 96 : 01 : 30	Word[16]	Ethernet SNMP system location setting	
3048-3063	96 : 01 : 31 - 96 : 01 : 40	Word[16]	Ethernet SNMP system contact setting	
3064-3071	96 : 01 : 41 - 96 : 01 : 48	Word[8]	Ethernet SNMP community name get setting	
3072-3079	96 : 01 : 49 - 96 : 01 : 50	Word[8]	Ethernet SNMP community name set setting	
3080-3087	96 : 01 : 51 - 96 : 01 : 58	Word[8]	Ethernet SNMP community name trap setting	
3088	96 : 01 : 59		(Reserved)	
3089	96 : 01 : 5A	Word	Ethernet RSTP bridge priority	
3090	96 : 01 : 5B	Word	Ethernet RSTP hello time	
3091	96 : 01 : 5C	Word	Ethernet RSTP max age time	
3092	96 : 01 : 5D	Word	Ethernet RSTP transmit count	
3093	96 : 01 : 5E	Word	Ethernet RSTP forward delay	
3094	96 : 01 : 5F	Word	Ethernet RSTP port count	
3095	96 : 01 : 60	Word	Ethernet RSTP port 1 priority	
3096-3097	96 : 01 : 61 - 96 : 01 : 62	UDInt	Ethernet RSTP port 1 past cost	
3098	96 : 01 : 63	Word	Ethernet RSTP port 1 select	
3099	96 : 01 : 64	Word	Ethernet RSTP port 2 priority	
3100-3101	96 : 01 : 65 - 96 : 01 : 66	UDInt	Ethernet RSTP port 2 path cost	
3102	96 : 01 : 67	Word	Ethernet RSTP port 2 select	
3103	96 : 01 : 68	Word	Ethernet extended configuration control	
3104	96 : 01 : 69	Word	Ethernet broadcast storm protection	
			0: Disable Broadcast Storm Protection (No Limit)	
			1: 64 kbps Bandwidth	
			2: 128 kbps Bandwidth	
			3: 256 kbps Bandwidth	
			4: 512 kbps Bandwidth	
			5: 1000 kbps Bandwidth (Default Value)	
3105	96 : 01 : 6A	Word	Ethernet QoS control	
3106	96 : 01 : 6B	Word	Ethernet QoS CIP class 0/1 urgent	
			bits 0-3 Ethernet QoS CIP class 0/1 urgent queue priority	
			bits 4-7 Ethernet QoS CIP class 0/1 urgent 8021 priority	
			bits 8-11 Ethernet QoS CIP class 0/1 urgent DSCP	
			bits 12-15 (Reserved)	
3107	96 : 01 : 6C	Word	Ethernet QoS CIP class 0/1 scheduled	
			bits 0-3 Ethernet QoS CIP class 0/1 scheduled queue priority	
			bits 4-7 Ethernet QoS CIP class 0/1 scheduled 8021 priority	
			bits 8-11 Ethernet QoS CIP class 0/1 scheduled DSCP	
			bits 12-15 (Reserved)	

Modbus/TCP (Register Addresses)	EtherNet/IP (Object Addresses)	Variable Type	Read/Write Variables	Note (see page 10 0)
3108	96 : 01 : 6D	Word	Ethernet QoS CIP class 0/1 high bits 0-3 Ethernet QoS CIP class 0/1 high queue priority bits 4-7 Ethernet QoS CIP class 0/1 high 8021 priority bits 8-11 Ethernet QoS CIP class 0/1 high DSCP bits 12-15 ( <i>Reserved</i> )	
3109	96 : 01 : 6E	Word	Ethernet QoS CIP class 0/1 low bits 0-3 Ethernet QoS CIP class 0/1 low queue priority bits 4-7 Ethernet QoS CIP class 0/1 low 8021 priority bits 8-11 Ethernet QoS CIP class 0/1 low DSCP bits 12-15 ( <i>Reserved</i> )	
3110	96 : 01 : 6F	Word	Ethernet QoS CIP UCMM class 3 bits 0-3 Ethernet QoS CIP UCMM class 3 queue priority bits 4-7 Ethernet QoS CIP UCMM class 3 8021 priority bits 8-11 Ethernet QoS CIP UCMM class 3 DSCP bits 12-15 ( <i>Reserved</i> )	
3111	96 : 01 : 70	Word	Ethernet QoS PTP general bits 0-3: Ethernet QoS PTP general queue priority bits 4-7: Ethernet QoS PTP general 8021 priority bits 8-11: Ethernet QoS PTP general DSCP bits 12-15 ( <i>Reserved</i> )	
3112	96 : 01 : 71	Word	Ethernet QoS PTP event bits 0-3: Ethernet QoS PTP event queue priority bits 4-7: Ethernet QoS PTP event 8021 priority bits 8-11: Ethernet QoS PTP event DSCP bits 12-15 ( <i>Reserved</i> )	
3113	96 : 01 : 72	Word	Ethernet QoS default outbound priority	
3114	96 : 01 : 73	Word	Ethernet QoS number of ports	
3115	96 : 01 : 74	Word	Ethernet QoS port 1 default inbound priority	
3116	96 : 01 : 75	Word	Ethernet QoS port 2 default inbound priority	
3117	96 : 01 : 76	Word	Ethernet QoS device control	
3118	96 : 01 : 77	UDInt	EthernetIP capabilities control	

## Command Variables

### Command Variables

Command variables are described in the following table:

Modbus/TCP (Register Addresses)	EtherNet/IP (Object Addresses)	Variable Type	Read/Write Variables	Note (see page 10 0)
700	6C : 01 : 01	Word	Register available to remotely write commands that can be processed in a specific Custom Logic	
701-703	6C : 01 : 02 - 6C : 01 : 04		(Reserved)	
704	6C : 01 : 05	Word	Control register 1 bit 0 Motor run forward command <sup>(1)</sup> bit 1 Motor run reverse command <sup>(1)</sup> bit 2 (Reserved) bit 3 Fault reset command bit 4 (Reserved) bit 5 Self test command bit 6 Motor low speed command bits 7-15 (Reserved)	
705	6C : 01 : 06	Word	Control register 2 bit 0 Clear all command Clear all parameters, except: <ul style="list-style-type: none"> <li>● Motor LO1 closings count</li> <li>● Motor LO2 closings count</li> <li>● Controller internal temperature max</li> <li>● Thermal capacity level</li> </ul> bit 1 Clear statistics command bit 2 Clear thermal capacity level command bit 3 Clear controller settings command bit 4 Clear network port settings command bits 5-15 (Reserved)	
706-709	6C : 01 : 07 - 6C : 01 : 0A		(Reserved)	
710-799	6C : 01 : 08 - 6C : 01 : 64		(Forbidden)	

(1) Even in overload mode, bits 0 and 1 of register 704 can be used to remotely control LO1 and LO2.

## User Map Variables

### Overview

User Map variables are designed to optimize the access to several non-contiguous registers in one single request.

You can define several read and write areas.

The user map can be defined via:

- A PC running SoMove with TeSys T DTM
- A PLC via the network port

### User Map Variables

**User Map Variables** are described in the following table:

User Map Variable Groups	Modbus/TCP (Register Addresses)	EtherNet/IP (Object Addresses)
User Map addresses	800-899	6D : 01 : 01 - 6D : 01 : 64
User Map values	900-999	6E : 01 : 01 - 6E : 01 : 64

Modbus/TCP (Register Addresses)	EtherNet/IP (Object Addresses)	Variable Type	Read/Write Variables	Note ( <i>see page 100</i> )
800-898	6D : 01 : 01 - 6D : 01 : 63	Word[99]	User map addresses setting	
899	6D : 01 : 64	Word	(Reserved)	

Modbus/TCP (Register Addresses)	EtherNet/IP (Object Addresses)	Variable Type	Read/Write Variables	Note ( <i>see page 100</i> )
900-998	6E : 01 : 01 - 6E : 01 : 63	Word[99]	User map values	
999	6E : 01 : 64	Word	(Reserved)	

The User Map Address group is used to select a list of addresses to read or write. It can be considered as a configuration area.

The User Map Value group is used to read or write values associated to addresses configured in the User Map Address area:

- Read or write of register 900 allows to read or write the register address defined in register 800
- Read or write of register 901 allows to read or write the register address defined in register 801,-

### Example of Use

The User Map Address configuration below gives an example of user map address configuration to access non-contiguous registers:

Modbus/TCP (Register Addresses)	EtherNet/IP (Object Addresses)	Value Configured	Read/Write Variables
800	6D : 01 : 01	452	Fault register 1
801	6D : 01 : 02	453	Fault register 2
802	6D : 01 : 03	461	Warning register 1
803	6D : 01 : 04	462	Warning register 2
804	6D : 01 : 05	450	Minimum wait time
805	6D : 01 : 06	500	Average current (0.01 A) MSW
806	6D : 01 : 07	501	Average current (0.01 A) LSW
850	6D : 01 : 51	651	HMI display items register 1
851	6D : 01 : 52	654	HMI display items register 2
852	6D : 01 : 53	705	Control register 2

With this configuration, monitoring information is accessible with one single read request through register addresses 900 to 906.

Configuration and command can be written with one single write using register addresses 950 to 952.

## Custom Logic Variables

### Custom Logic Variables

Custom logic variables are described in the following table:

Modbus/TCP (Register Addresses)	EtherNet/IP (Object Addresses)	Variable Type	Read/Write Variables	Note (see page 10 0)
1250	71 : 01 : 33	Word	Custom logic setting register 1	
			<i>bit 0 (Reserved)</i>	
			bit 1 Logic input 3 external ready enable	
			<i>bits 2-15 (Reserved)</i>	
1251-1269	71 : 01 : 34 - 71 : 01 : 46		<i>(Reserved)</i>	
1270	71 : 01 : 47	Word	Custom logic command register 1	
			bit 0 Custom logic external fault command	
			<i>bits 1-15 (Reserved)</i>	
1271-1279	71 : 01 : 48 - 71 : 01 : 50		<i>(Reserved)</i>	

Modbus/TCP (Register Addresses)	EtherNet/IP (Object Addresses)	Variable Type	Read-only Variables	Note (see page 10 0)
1280	71 : 01 : 51	Word	Custom logic monitoring register 1	
			<i>bit 0 (Reserved)</i>	
			bit 1 Custom logic system ready	
			<i>bits 2-15 (Reserved)</i>	
1281-1300	71 : 01 : 52 - 71 : 01 : 65		<i>(Reserved)</i>	

Modbus/TCP (Register addresses)	EtherNet/IP (Object addresses)	Variable type	Read/Write variables	Note (see page 10 0)
1301-1399	71 : 01 : 66 -71 : 01 : C8	Word[99]	General purpose registers for logic functions	

## Mirroring Variables

### Mirroring Variables

**Mirroring variables** are updated to present—in a series of contiguous registers—the values of other high priority status, I/O and control registers, as follows:

Modbus/TCP (Register Addresses)	EtherNet/IP (Object Addresses)	Variable Type	Read-only Variables	Note (see page 100)
2500	8C : 01 : 01	Word	Mirror status register  bit 0 Input table freshness 0 = table has been read within 100 ms 1 = table has not been read within 100 ms  bit 1 Input table validity 0 = table data is invalid 1 = table data is valid  bit 2 Input table changed 0 = table data is unchanged from last read 1 = table data is changed from last read  <i>bits 3-7 (Reserved)</i>  bit 8 Output table freshness 0 = table has been read within 100 ms 1 = table has not been read within 100 ms  bit 9 Output table validity 0 = table data is invalid 1 = table data is valid  bit 10 Output table changed 0 = table data is unchanged from last read 1 = table data is changed from last read  <i>bits 11-15 (Reserved)</i>	
2501	8C : 01 : 02	Word	<i>(Reserved)</i>	
2502	8C : 01 : 03	Word	Mirrors System Status Register 1 (register 455 or object 68 : 01 : 06)  bit 0 mirrors System Ready bit 1 mirrors System On bit 2 mirrors System Fault bit 3 mirrors System Warning bit 4 mirrors System Tripped bit 5 mirrors Fault Reset Authorized bit 6 mirrors Controller Power bit 7 mirrors Motor Running (with detection of a current if greater than 10% FLC) bits 8-13 mirrors Motor Average Current Ratio 32 = 100% FLC - 63 = 200% FLC bit 14 mirrors In remote bit 15 mirrors Motor Starting (start in progress) 0 = descending current is less than 150% FLC 1 = ascending current is greater than 10% FLC	

Modbus/TCP (Register Adresses)	EtherNet/IP (Object Addresses)	Variable Type	Read-only Variables	Note (see page 100)
2503	8C : 01 : 04	Word	Mirrors System Status Register 2 (register 456 or object 68 : 01 : 07) bit 0 mirrors Auto-reset Active bit 1 ( <i>Not significant</i> ) bit 2 mirrors Fault Power Cycle Requested bit 3 mirrors Motor Restart Time Undefined bit 4 mirrors Rapid Cycle Lockout bit 5 mirrors Load Shedding bit 6 mirrors Motor Speed 0 = FLC1 setting is used 1 = FLC2 setting is used bit 7 mirrors HMI Port Comm Loss bit 8 mirrors Network Port Comm Loss bit 9 mirrors Motor Transition Lockout <i>bits 10-15 (Not significant)</i>	1
2504	8C : 01 : 05	Word	Mirrors Logic Inputs Status (register 457 or object 68 : 01 : 08) bit 0 mirrors Logic Input 1 bit 1 mirrors Logic Input 2 bit 2 mirrors Logic Input 3 bit 3 mirrors Logic Input 4 bit 4 mirrors Logic Input 5 bit 5 mirrors Logic Input 6 bit 6 mirrors Logic Input 7 bit 7 mirrors Logic Input 8 bit 8 mirrors Logic Input 9 bit 9 mirrors Logic Input 10 bit 10 mirrors Logic Input 11 bit 11 mirrors Logic Input 12 bit 12 mirrors Logic Input 13 bit 13 mirrors Logic Input 14 bit 14 mirrors Logic Input 15 bit 15 mirrors Logic Input 16	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
2505	8C : 01 : 06	Word	Logic outputs status (register 458 or object 68 : 01 : 09) bit 0 mirrors Logic Output 1 bit 1 mirrors Logic Output 2 bit 2 mirrors Logic Output 3 bit 3 mirrors Logic Output 4 bit 4 mirrors Logic Output 5 bit 5 mirrors Logic Output 6 bit 6 mirrors Logic Output 7 bit 7 mirrors Logic Output 8 <i>bits 8-15 (Reserved)</i>	1 1 1 1

Modbus/TCP (Register Addresses)	EtherNet/IP (Object Addresses)	Variable Type	Read/Write Variables	Note (see page 100)
2506	8C : 01 : 07	Word	Logic Outputs Command Register (register 700 or object 6C : 01 : 01)	
			bit 0 mirrors Logic Output 1 Command	
			bit 1 mirrors Logic Output 2 Command	
			bit 2 mirrors Logic Output 3 Command	
			bit 3 mirrors Logic Output 4 Command	
			bit 4 mirrors Logic Output 5 Command	1
			bit 5 mirrors Logic Output 6 Command	1
			bit 6 mirrors Logic Output 7 Command	1
			bit 7 mirrors Logic Output 8 Command	1
			<i>bits 8-15 (Reserved)</i>	
2507	8C : 01 : 08	Word	Control Register 1 (register 704 or object 6C : 01 : 05)	
			bit 0 mirrors Motor Run Forward Command	
			bit 1 mirrors Motor Run Reverse Command	
			<i>bit 2 (Reserved)</i>	
			bit 3 mirrors Fault Reset Command	
			<i>bit 4 (Reserved)</i>	
			bit 5 mirrors Self Test Command	
			bit 6 mirrors Motor Low Speed Command	
			<i>bits 7-15 (Reserved)</i>	
2508	8C : 01 : 09	Word	Analog Output 1 Command (register 706 or object 6C : 01 : 07)	
2509-2599	8C : 01 : 0A - 8C : 01 : 64	-	<i>(Reserved)</i>	

---

# Chapter 4

## Using the Standard Web Server User Interface

---

### Overview

This chapter describes the functions of the standard Web server pages and how to use the data to operate an LTMR controller with or without an LTME expansion module.

### What Is in This Chapter?

This chapter contains the following topics:

Topic	Page
Description of the Standard Web Server User Interface	142
Home Page	146
Login Page	148
Documentation Page	149
Monitoring Page	150
Product Status Page	151
Metering Page	153
Diagnostics Page	154
Ethernet Basic Page	155
Ethernet Extended Diagnostics Page	156
RSTP Bridge Statistics Page	157
RSTP Port Statistics Page	158
Faults & Warnings Page	159
Fault History Page	160
Maintenance Page	162
Counters Page	163
Setup Page	164
Product Thermal Settings Page	165
Product Current Settings Page	166
Product Voltage Settings Page	167
Product Power Settings Page	168
RSTP Configuration Page	169
Communication Page	170
Password Page	171

## Description of the Standard Web Server User Interface

### Overview

The standard Web server pages provide an LTMR embedded HMI which can be accessed using a standard web browser supported by:

- Microsoft Internet Explorer version 8 or later
- Mozilla Firefox version 13 or later
- Google Chrome version 19 or later

### Java Free Web Pages

The latest versions of web pages are developed on a technology called as Lightweight Web App (LWA). The web pages are independent from Java backbone, works under any environment (XP, Windows 7, Windows 8, and so on), and also on all web browsers (Microsoft Internet Explorer, Mozilla Firefox, and Google Chrome). TeSys T new web pages works on PC without Java installation.


### Functions of the Web Server User Interface

The following table describes all the functions of the Web server pages. Some functions are available according to the configuration (for example functions available only if LTME is connected).

Menu	Information Displayed	Function
HOME	Home page	Identification of the connected product: LTMR controller with/without LTME expansion module
	Language	Display of the pages in the selected language
	Identification	Activation and deactivation of data modification mode
DOCUMENTATION	References	Link to the <a href="http://www.schneider-electric.com">http://www.schneider-electric.com</a> website
MONITORING	Product status	Display of information from input/output status and the internal product status
	Metering	Display of measured data with numerical value and graphical representation
DIAGNOSTICS	Ethernet basic diagnostics	Display of information on the IP parameters, FDR, device name and the protocol
	Ethernet extended diagnostics	Display and reset (password-protected) of communication statistics for each port
	RSTP bridge	Display and reset (password-protected) of statistics
	RSTP port	Display and reset (password-protected) of statistics and status for the ports 1 and 2
	Faults and warnings	Display of fault and warning status and fault count, if any, for each data, and reset (password-protected) of fault count
	Fault history	Display and reset (password-protected) of the thermal, current, voltage, and power fault history
MAINTENANCE	Counters	Display and reset (password-protected) of statistics
SETUP	Thermal settings	Display and modification (password-protected) of editable thermal settings
	Current settings	Display and modification (password-protected) of editable current settings
	Voltage settings	Display and modification (password-protected) of editable voltage settings
	Power settings	Display and modification (password-protected) of editable power settings
	RSTP settings	Display and modification (password-protected) of editable RSTP settings
	Communication	Display and modification (password-protected) of editable communication settings
	Password	Modification of the password used to edit data

## Standard Web Server Structure

The diagram below shows the navigation in the standard Web server pages:




## Access to the Standard Web Server

Step	Action
1	Connect the LTMRModbus/TCP controller to your PC.
2	Open a Web browser.
3	In the address bar, enter the IP address assigned to the LTMR controller. If necessary, refer to the LTMR IP addressing procedure ( <a href="#">see page 32</a> ).
4	If connection is accepted, the Home page displays. You can navigate in the different pages via menus and submenus.
5	If you want to modify parameter values, enter your password by clicking <b>Login</b> on the <b>Home</b> menu. For information about <ul style="list-style-type: none"> <li>• Entering the password, refer to the Login page (<a href="#">see page 148</a>),</li> <li>• Changing the password, refer to the Password page (<a href="#">see page 171</a>).</li> </ul>

## Standard Web Server User Interface

All Web server pages have the same appearance. A window is divided into three areas, as follows:



Legend	Area	Description
1	Menus	Banner displayed on every page, showing links to the menus: <ul style="list-style-type: none"> <li>• Home</li> <li>• Documentation</li> <li>• Monitoring</li> <li>• Diagnostics</li> <li>• Maintenance</li> <li>• Setup</li> </ul>
2	Submenu treeview	Links to the pages related to the selected menu. The treeview <ul style="list-style-type: none"> <li>• Always displays the menu name in which the user is navigating,</li> <li>• Allows the user to expand or collapse functions.</li> </ul>
3	Page body	Information related to the contextual page selected in the menu or submenu.

### Clear Counters Button

A Clear Counters button is displayed in the following pages:

- Ethernet Extended Diagnostics page
- RSTP Bridge Statistics page
- RSTP Port Statistics page
- Fault History page
- Counters page

When clicking this button, in the Ethernet Extended Diagnostics, Fault History, or Counters page (if enabled), you perform a Clear Statistics Command and the LTMR controller's statistics are reset. Thus, the following parameters are reset on the Web server pages:

- All statistics on the Ethernet Extended Diagnostics page
- All fault counters on the Faults & Warnings Diagnostics page
- The 5 fault records on the Fault History page
- The Operating Time and Motor Start Counters on the Counters page

When clicking the Clear Counters button (if enabled) in the RSTP Bridge page, it clears all the RSTP Bridge Statistics.


When clicking the Clear Counters button (if enabled) in the RSTP Port page, it clears all the RSTP Port Statistics data on both ports.

The Clear Counters button is:

- Disabled by default
- Enabled in modification mode (after entering the correct password in the Login page)
- Clear counters button in RSTP port and RSTP Bridge pages are enabled in modification mode only if RSTP is enabled in the device

## Home Page

### Overview



### Access to the Home Page

The Home page is displayed:

- After you connect to the standard Web server,
- When you click Home in the menu headers at any moment during navigation and from any page displayed.

### Home Page Submenu

The Home page submenu contains the following items:

Level 1	Level 2	Function
Languages	English	Switch the page language to English
	French	Switch the page language to French
	Spanish	Switch the page language to Spanish
	Custom	Switch the page language to the Custom language (English by default)
Identification	Login	Display the Login page to enter the password ( <a href="#">see page 148</a> )
	Logout	Deactivate the data modification mode

### Language Selection

From the submenu zone, click one of the following languages to display the page content in this language:

- English
- French
- Spanish
- Custom (English by default)

### Logout

Click **Logout** to disable the modification mode.

## Home Page Body

The Home page displays the following product elements:

- A view of the LTMR controller and LTME expansion module when connected
- LTMR controller data:
  - Vendor name: Schneider Electric
  - Commercial reference
  - Version
- Version of the communication interface
- LTME expansion module data:
  - Commercial reference
  - Version
  - DISCOVER button

**NOTE:** LTME data is blank if no LTME is connected.

## DISCOVER Button

The DISCOVER button is displayed in the following pages:


- Home page
- Documentation page
- Monitoring page
- Diagnostics page
- Maintenance page
- Setup page

When clicking this button, the Network status LED of the LTMR controller blinks 10 times alternatively red and green.

There is no visual modification on the Web page.

## Login Page

### Overview



### Login Page Body

By default, the password protection is always enabled.

The Login page allows you to enter the user name and password required to activate the modification mode:

- The user name is "USER" (uppercase),
- The password is an integer from 0000 to 9999, the default value is 0000.

**NOTE:** The Web pages' password is the same as the LTMCU password.


### Exiting the Modification Mode

To exit the modification mode and deactivate the password

- Click Logout in the Identification submenu of the Home page, or
- Close the Web browser.

## Documentation Page

### Overview



### Access to the Documentation Page


The Documentation page displays when you click Documentation in the menu headers at any moment during navigation and from any page displayed.

### Documentation Page Submenu

The Documentation page submenu allows you to access the References page. You can download LTMR technical publications and other technical information from our website at [www.schneider-electric.com](http://www.schneider-electric.com) using the hyperlink on the References page.

## Monitoring Page

### Overview



### Access to the Monitoring Page

The Monitoring page displays when you click Monitoring in the menu headers at any moment during navigation and from any page displayed.


### Monitoring Page Submenu

The Monitoring page submenu allows you to access the following pages:

- Product Status (*see page 151*)
- Metering (*see page 153*)

## Product Status Page

### Overview



### Product Status Page Body

The page displays

- the state of each I/O related to the dedicated connector pin on the product view (LTMR controller + LTME expansion module),
- general states and values.

The state indicators depend on the following color code:

- Inactive states are in gray.
- Active states are in green, orange, or red depending on the data.

The Product Status page contains the following read-only data:

Data Name	Parameter Name
LI1	Logic Input 1
LI2	Logic Input 2
LI3	Logic Input 3
LI4	Logic Input 4
LI5	Logic Input 5
LI6	Logic Input 6
LI7 <sup>(1)</sup>	Logic Input 7
LI8 <sup>(1)</sup>	Logic Input 8
LI9 <sup>(1)</sup>	Logic Input 9
LI10 <sup>(1)</sup>	Logic Input 10
LO1	Logic Output 1
LO2	Logic Output 2
LO3	Logic Output 3
LO4	Logic Output 4
Wiring Fault	Wiring Fault
System Ready	System Ready
System ON	System ON


(1) If no LTME expansion module is connected, the indicator is not displayed.  
(2) The color in active state depends on the value of the HMI Motor Status LED Color parameter: red if value is 0, green if 1, gray if inactive.

Data Name	Parameter Name
System Fault	System Fault
System Warning	System Warning
Fault Reset Authorized	Fault Reset Authorized
Power Cycle Required	Power Cycle Required
Minimum Wait Time	Minimum Wait Time
Time To Thermal Fault	Time To Trip
Motor Starting	Motor Starting
Motor Running	Motor Running
High Speed	High Speed
Direction 1 <sup>(2)</sup>	Direction 1
Direction 2 <sup>(2)</sup>	Direction 2
Average Current (%FLC)	Average Current
Average Current (A)	Average Current

(1) If no LTME expansion module is connected, the indicator is not displayed.  
(2) The color in active state depends on the value of the HMI Motor Status LED Color parameter: red if value is 0, green if 1, gray if inactive.

## Metering Page

### Overview



### Metering Page Body

The page displays the numerical value and graphical representation next to each data name.


The Metering page contains the following read-only data:

Group Name	Data Name	Parameter Name
Thermal	Thermal Capacity Level	Thermal Capacity Level
	Motor Temperature	<ul style="list-style-type: none"> <li>● Motor Temperature Sensor Degree:           <ul style="list-style-type: none"> <li>○ Motor Temperature Sensor Type is PT100</li> <li>○ Motor temperature displayed in °C or °F according to the value of the HMI Display Temperature Sensor Degree CF parameter</li> </ul> </li> <li>● Motor Temperature Sensor Ohm:           <ul style="list-style-type: none"> <li>○ Motor Temperature Sensor Type is not PT100</li> <li>○ Motor temperature displayed in Ohms</li> </ul> </li> <li>● No Motor Temperature Detected:           <ul style="list-style-type: none"> <li>○ Motor Temperature Data displays not connected</li> <li>○ Graph indicator shows 100%</li> </ul> </li> </ul>
Current	Average Current	Average Current
	Ground Current	Ground Current
	Current Phase Imbalance	Current Phase Imbalance
Voltage	Average Voltage <sup>(1)</sup>	Average Voltage
	Frequency <sup>(1)</sup>	Frequency
	Voltage Phase Imbalance <sup>(1)</sup>	Voltage Phase Imbalance
Power	Active Power <sup>(1)</sup>	Active Power
	Power Factor <sup>(1)</sup>	Power Factor
	Reactive Factor <sup>(1)</sup>	Reactive Power

**(1)** Not displayed if no LTME expansion module is connected.

## Diagnostics Page

### Overview



### Access to the Diagnostics Page

The Diagnostics page displays when you click Diagnostics in the menu headers at any moment during navigation and from any page displayed.


### Diagnostics Page Submenu

The Diagnostics page submenu allows you to access the following pages:

Level 1	Level 2
Ethernet	Basic ( <a href="#">see page 155</a> ) Extended ( <a href="#">see page 156</a> )
RSTP	RSTP Bridge ( <a href="#">see page 157</a> ) RSTP Port ( <a href="#">see page 158</a> )
Product	Faults & Warnings ( <a href="#">see page 159</a> ) Fault History ( <a href="#">see page 160</a> )

## Ethernet Basic Page

### Overview




### Ethernet Basic Page Body

The Ethernet Basic page contains the following read-only data:

Group Name	Data Name	Parameter Name
Address	MAC Address	Ethernet MAC Address
	IP Address	Ethernet IP Address
	Subnet Mask	Ethernet Subnet Mask
	Gateway Address	Ethernet Gateway Address
	Protocol	Ethernet Capabilities Control
Product Identification	Device Name	Ethernet Device Name
Faulty Device Replacement Status	FDR Status	Network Port FDR Status

## Ethernet Extended Diagnostics Page

### Overview



### Ethernet Extended Diagnostics Page Body

In the Port Number list, select the Ethernet port to display the related diagnostics.

The Clear Counters button located at the bottom of the page can be used to reset all statistics including the Ethernet statistics counters ([see page 144](#)).

The Ethernet Extended Diagnostics page contains the following read-only data for each port:

Group Name	Data Name
Transmit Statistics	Frames Transmitted OK
	Collisions
	Excessive Collisions
	Carrier Sense Errors
	Link Speed
	Duplex Mode
	Frames Received OK
Receive Statistics	CRC Errors

## RSTP Bridge Statistics Page

### Overview

The screenshot displays the RSTP Bridge Statistics page within the Schneider Electric TeSys T Motor Management System. The left sidebar includes links for Diagnostics, Ethernet (Basic, Extended), RSTP (RSTP Bridge, RSTP Port), and Product (Fault & Warning, Fault History). The main content area is titled 'RSTP Bridge Statistics' and contains two sections: 'General' and 'Configured vs.learned'. Each section has several input fields for various RSTP parameters. A 'Clear Counters' button is located at the bottom of the page.

### RSTP Bridge Statistics Page Body

The RSTP Bridge Statistic page contains the following data:

Group Name	Data Name
General	Bridge Status Bridge ID Designated Root ID Designated Root Port Rootpath Cost Total Topology Changes
Configured vs. learned	Configured Hello Time Learned Hello Time Configured Forward Delay Learned Forward Delay Configure Max Age Learned Max Age

## RSTP Port Statistics Page

### Overview

The screenshot shows the Schneider Electric TeSys T Motor Management System web interface. The top navigation bar includes links for Home, Documentation, Monitoring, Control, Diagnostics, Maintenance, and Setup. The left sidebar has sections for Diagnostics, Ethernet (Basic, Extended), RSTP (Bridge, Port), and Product (Fault & Warning, Fault History). The main content area is titled 'RSTP Port Statistics' and displays a table for port number 1. The table columns include Port Status, Port State, Role, Priority, Port Path Cost, Designated Port ID, Received RSTs, Transmitted RSTs, Received Configure, Transmitted Configure, Received TCNs, and Transmitted TCNs. A 'Clear Counters' button is located at the bottom of the table.

### RSTP Port Statistics Page Body

In the Port Number list, select the RSTP port number in the field to display the related diagnostics.

The RSTP Port Statistics page contains the following data for each port:

Group Name	Data Name
Port Status	Status
	Role
	Priority
	Port Path Cost
	Designated Port ID
	Received RSTs
	Transmitted RSTs
	Received Configure
	Transmitted Configure
	Received TCNs
	Transmitted TCNs

## Faults & Warnings Page

### Overview

System Fault	Count	System Warning	Count
Thermal Overload	Warnings: [red box], Faults: [red box], FaultCount: [red box]	Over Voltage	Warnings: [red box], Faults: [red box], FaultCount: [red box]
Motor Temperature Sensor	Warnings: [red box], Faults: [red box], FaultCount: [red box]	Under Power	Warnings: [red box], Faults: [red box], FaultCount: [red box]
Ground Current	Warnings: [red box], Faults: [red box], FaultCount: [red box]	Over Power	Warnings: [red box], Faults: [red box], FaultCount: [red box]
Current Phase Imbalance	Warnings: [red box], Faults: [red box], FaultCount: [red box]	Under Power Factor	Warnings: [red box], Faults: [red box], FaultCount: [red box]
Current Phase Loss	Warnings: [red box], Faults: [red box], FaultCount: [red box]	Over Power Factor	Warnings: [red box], Faults: [red box], FaultCount: [red box]
Current Phase Reversal	Warnings: [red box], Faults: [red box], FaultCount: [red box]	Network Port	Warnings: [red box], Faults: [red box], FaultCount: [red box]
Long Start	Warnings: [red box], Faults: [red box], FaultCount: [red box]	Network Port Config	Warnings: [red box], Faults: [red box], FaultCount: [red box]
Jam	Warnings: [red box], Faults: [red box], FaultCount: [red box]	HMI Port	Warnings: [red box], Faults: [red box], FaultCount: [red box]
Under Current	Warnings: [red box], Faults: [red box], FaultCount: [red box]	External Fault	Warnings: [red box], Faults: [red box], FaultCount: [red box]
Over Current	Warnings: [red box], Faults: [red box], FaultCount: [red box]	Motor Diagnostic	Warnings: [red box], Faults: [red box], FaultCount: [red box]
Voltage Phase Imbalance	Warnings: [red box], Faults: [red box], FaultCount: [red box]	Wiring Diagnostic	Warnings: [red box], Faults: [red box], FaultCount: [red box]
Voltage Phase Loss	Warnings: [red box], Faults: [red box], FaultCount: [red box]	Test	Warnings: [red box], Faults: [red box], FaultCount: [red box]
Voltage Phase Reversal	Warnings: [red box], Faults: [red box], FaultCount: [red box]	Internal Controller	Warnings: [red box], Faults: [red box], FaultCount: [red box]
Under Voltage	Warnings: [red box], Faults: [red box], FaultCount: [red box]	Internal Network Brick	Warnings: [red box], Faults: [red box], FaultCount: [red box]
		Internal Link	Warnings: [red box], Faults: [red box], FaultCount: [red box]

Copyright © Schneider Electric. All Rights Reserved.

### Faults & Warnings Page Body

The following items are displayed next to each data name: the warning or fault status and the faults counter value, if any.

The color code of the indicators is as follows:

In Case of...	The Indicator is...
warning	Orange
Fault	Red
Inactive warning or fault	Gray

The Clear Counters button located at the bottom of the page can be used to reset all statistics and fault counters ([see page 144](#)).

The Faults & Warnings page contains read-only data.

## Fault History Page

### Overview

The screenshot displays the Schneider Electric TeSys T Motor Management System's Fault History page. The interface is organized into several sections:

- Header:** Schneider Electric logo and TeSys T Motor Management System title.
- Navigation Bar:** Home, Documentation, Monitoring, Control, Diagnostics, Maintenance, Setup.
- Left Sidebar:** Diagnostics, Internet (Basic, Extended), RSTP (RSTP Bridge, RSTP Port), Product (Fault & Warning, Fault History).
- Fault Selection:** A dropdown menu showing 'Fault Selection' and a value '0'.
- Date-Time and Fault Code:** Input fields for Date-Time and Fault Code.
- Current Section:** Contains parameters: FLCmax, FLC ratio, Average Current, L1 Current, L2 Current, L3 Current, Ground Current, Average Current Ratio, L1 Current ratio, L2 Current ratio, L3 Current ratio, Ground Current ratio, Current Phase Imbalance.
- Thermal Section:** Contains parameters: Thermal Capacity, Motor Temp Sensor.
- Voltage Section:** Contains parameters: Average Voltage, L1-L2 Voltage, L2-L3 Voltage, L3-L1 Voltage, Voltage Phase Imbalance, Frequency.
- Power Section:** Contains parameters: Active Power, Power Factor.
- Buttons:** Clear Counters and Fault History.

### Fault History Page Body

In the Fault History list, select a fault number to display the history of LTMR controller data recorded at the time of the last five detected faults. Fault N0 contains the most recent fault record, and fault N4 contains the oldest retained fault record.

The Clear Counters and Fault History button located at the bottom of the page can be used to reset all statistics including the five fault records ([see page 144](#)).

The Fault History page contains the following read-only parameters for fault N0:


Group Name	Data Name	Parameter Name
Fault Selection	Date-Time	Date and Time N0
	Fault Code	Fault Code N0
Current	FLC max	Full Load Current max
	FLC Ratio	Motor Full Load Current Ratio
	Average Current	Average Current N0
	L1 Current	L1 Current N0
	L2 Current	L2 Current N0
	L3 Current	L3 Current N0
	Ground Current	Ground Current N0
	Average Current Ratio	Average Current ratio N0
	L1 Current Ratio	L1 Current Ratio N0
	L2 Current Ratio	L2 Current Ratio N0
	L3 Current Ratio	L3 Current Ratio N0
	Ground Current Ratio	Ground Current Ratio N0
Thermal	Thermal Capacity	Thermal Capacity Level N0
	Motor Temp Sensor	Motor Temperature Sensor Degree N0

<b>Group Name</b>	<b>Data Name</b>	<b>Parameter Name</b>
Voltage	Average Voltage	Average Voltage N0
	L1-L2 Voltage	L1L2 Voltage N0
	L2-L3 Voltage	L2L3 Voltage N0
	L3-L1 Voltage	L3L1 Voltage N0
	Voltage Phase Imbalance	Voltage Phase Imbalance N0
	Frequency	Frequency N0
Power	Active Power	Active Power N0
	Power Factor	Power Factor N0

Faults N1–N4 fault record information in the same way as Fault N0. See corresponding N1–N4 parameters.

## Maintenance Page

### Overview



### Access to the Maintenance Page


The Maintenance page displays when you click Maintenance in the menu headers at any moment during navigation and from any page displayed.

### Maintenance Page Submenu

The Maintenance page submenu allows you to access the Counters page.

## Counters Page

### Overview



### Counters Page Body


The Clear Counters button located at the bottom of the page can be used to reset the operating time, the motor starts counters, and statistics on other pages ([see page 144](#)). The other parameters displayed on the Counters page are not reset.

The Counters page contains the following read-only data:

Group Name	Data Name	Parameter Name
Control Unit Statistics	MaxTemperature	Controller Internal Temperature Maximum
	LO1 Closing Count	Motor LO1 Closings Count
	LO2 Closing Count	Motor LO2 Closings Count
	Last Power OFF Duration	Controller Last Power OFF Duration
Motor Statistics	Operation Time	Operating Time
	Starts Count	Motor Starts Count
	Starts Per Hour	Motor Starts Per Hour Count
Last Start	Level	Motor Last Start Current Ratio
	Duration	Motor Last Start Duration

## Setup Page

### Overview



### Access to the Setup Page

The Setup page displays when you click Setup in the menu headers at any moment during navigation and from any page displayed.

### Setup Page Submenu

The Setup page submenu allows you to access the following pages:


Level 1	Level 2
Product	Thermal ( <a href="#">see page 165</a> ) Current ( <a href="#">see page 166</a> ) Voltage ( <a href="#">see page 167</a> ) Power ( <a href="#">see page 168</a> ) RSTP Configuration ( <a href="#">see page 169</a> ) Communication ( <a href="#">see page 170</a> )
Security	Password ( <a href="#">see page 171</a> )

### Modifying Values in the Settings Pages

To modify setting values in the six pages of the Product submenu, you must have entered the modification mode ([see page 148](#)), otherwise the parameter values remain grayed.

## Product Thermal Settings Page

### Overview



### Thermal Settings Page Body

In the Protection Choice list, select the name of the desired protection group.

The modification of settings is allowed only after entry of the correct password on the Login page ([see page 148](#)).


Apply button sets the LTMR configuration with the entered data. The data entered must be valid.

Undo button retrieves the current values of the LTMR configuration.

The Thermal Settings page contains the editable data.

## Product Current Settings Page

### Overview



### Current Settings Page Body

In the Protection Choice list, select the name of the desired protection group.

The modification of settings is allowed only after entry of the correct password on the Login page ([see page 148](#)).


Apply button sets the LTMR configuration with the entered data. The data entered must be valid.

Undo button retrieves the current values of the LTMR configuration.

The Current Settings page contains editable data.

## Product Voltage Settings Page

### Overview



### Voltage Settings Page Body

In the Protection Choice list, select the name of the desired protection group.

The modification of settings is allowed only after entry of the correct password on the Login page ([see page 148](#)).


Apply button sets the LTMR configuration with the entered data. The data entered must be valid.

Undo button retrieves the current values of the LTMR configuration.

The Voltage Settings page contains editable data.

## Product Power Settings Page

### Overview



### Power Settings Page Body

In the Protection Choice list, select the name of the desired protection group.

The modification of settings is allowed only after entry of the correct password on the Login page ([see page 148](#)).

Apply button sets the LTMR configuration with the entered data. The data entered must be valid.

Undo button retrieves the current values of the LTMR configuration.

The Power Settings page contains editable data.

## RSTP Configuration Page

### Overview

The screenshot displays the RSTP Configuration page of the TeSys T Motor Management System. The left sidebar includes links for Product (Thermal, Current, Voltage, Power, RSTP, Communication), Security (Password), and Setup. The main content area is titled "RSTP CONFIGURATION". It contains two main sections: "Parameters" and "Port Parameters".

**Parameters**

Status	Disable
Bridge Priority	32768
Hello Time(sec)	2
Max Age Time(sec)	36
Transmit Count	6
Forward Delay(Sec)	20

**Port Parameters**

Port1 Priority	128
Port1 Path Cost	0
Port2 Priority	128
Port2 Path Cost	0

Buttons at the bottom include "Apply", "Undo", and "Reset To Default".

### RSTP Configuration Page Body

Apply button sets the LTMR configuration with the entered data. The data entered must be valid.

Undo button retrieves the current values of the LTMR configuration.

Reset to Default button restores the factory setting values of the LTMR configuration.

## Communication Page

### Overview

The screenshot shows the Schneider Electric TeSys T Motor Management System Communication page. The top navigation bar includes Home, Documentation, Monitoring, Control, Diagnostics, Maintenance, and Setup. The main content area is titled "Communication Parameters" and contains fields for IP address (192.168.16.2), Subnet Mask (255.255.255.0), and Gateway Address (0.0.0.0). On the left, there are two expandable sections: "Product" (Thermal, Current, Voltage, Power, RSTP, Communication) and "Security" (Password). At the bottom right are "Apply" and "Undo" buttons. A copyright notice at the bottom states "Copyright © Schneider Electric. All Rights Reserved."

**NOTE:** This IP address is used only if the product is in stored IP mode ([see page 32](#)). Restart the device in stored IP mode for the parameters in the page to take effect.

### Communication Page Body

Apply button sets the LTMR configuration with the entered data. The data entered must be valid.

Undo button retrieves the current values of the LTMR configuration.

The Communication Settings page contains the following (password-protected) data:

Group Name	Data Name
Communication Parameters	IP Address
	Subnet Mask
	Gateway Address

## Password Page

### Overview

The screenshot shows the Schneider Electric TeSys T Motor Management System web interface. The top navigation bar includes links for Home, Documentation, Monitoring, Control, Diagnostics, Maintenance, and Setup. The main menu on the left has sections for Product (Setup, Thermal, Current, Voltage, Power, RSTP, Communication) and Security (Password). The central content area is titled "PASSWORD CHANGE" and contains a "Password Change" form with fields for Name, Password, New Password, and Confirm New Password. Below the form are "Apply" and "Undo" buttons. At the bottom of the page, a copyright notice reads "Copyright © Schneider Electric. All Rights Reserved."

### Password Page

The Password page allows you to change the password required to modify the editable parameters in some Web pages.

The password must be an integer from 0000 to 9999.

**NOTE:** The Web pages' password is the same as the LTMCU password. If you change the password of the LTMCU, the Web server pages' password is set to this password and vice versa.

### Changing the Password

Follow the procedure below to change the password:

Step	Action
1	In the Password page, enter your current user name (USER).
2	Enter the new password twice (an integer from 0000 to 9999).
3	Confirm or cancel changes.

The password returns to factory setting:

- On a product Return to factory setting, or
- When a new firmware is downloaded in the product.



# Glossary



## A

### active power

Also known as *real power*, active power is the rate of producing, transferring or using electrical energy. It is measured in watts (W) and often expressed in kilowatts (kW) or megawatts (MW).

### analog

Describes inputs (e.g. temperature) or outputs (e.g. motor speed) that can be set to a range of values. Contrast with discrete.

### apparent power

The product of current and voltage, apparent power consists of both active power and reactive power. It is measured in volt-amperes and often expressed in kilovolt-amperes (kVA) or megavolt-amperes (MVA).

## C

### CANopen

An open industry standard protocol used on the internal communication bus. The protocol allows the connection of any standard CANopen device to the island bus.

### CT

*current transformer*.

## D

### definite time

A variety of TCC or TVC where the initial magnitude of the trip time delay remains a constant, and does not vary in response to changes in the value of the measured quantity (e.g. current). Contrast with inverse thermal.

### device

In the broadest terms, any electronic unit that can be added to a network. More specifically, a programmable electronic unit (e.g. PLC, numeric controller or robot) or I/O card.

### DeviceNet

DeviceNet is a low-level, connection-based network protocol that is based on CAN, a serial bus system without a defined application layer. DeviceNet, therefore, defines a layer for the industrial application of CAN.

### DIN

*Deutsches Institut für Normung*. The European organization that organizes the creation and maintenance of dimensional and engineering standards.

### DIN rail


A steel mounting rail, made pursuant to DIN standards (typically 35 mm wide) that allows for easier "snap-on" mounting of IEC electrical devices, including the LTMR controller and the expansion module. Contrast with screw mounting of devices to a control panel by drilling and tapping holes.

### discrete

Describes inputs (e.g. switches) or outputs (e.g. coils) that can be only *On* or *Off*. Contrast with analog.

### DPST

*double-pole/single-throw*. A switch that connects or disconnects 2 circuit conductors in a single branch circuit. A DPST switch has 4 terminals, and is the equivalent of 2 single-pole/single-throw switches controlled by a single mechanism, as depicted below:



## E

### **endian setting (big endian)**

'big endian' means that the high-order byte/word of the number is stored in memory at the lowest address, and the low-order byte/word at the highest address (the big end comes first).

### **endian setting (little endian)**

'little endian' means that the low-order byte/word of the number is stored in memory at the lowest address, and the high-order byte/word at the highest address (the little end comes first).

### **EtherNet/IP**

(Ethernet Industrial Protocol) is an industrial application protocol built on TCP/IP and CIP protocols. It is mainly used on automated networks, it defines network devices as network objects as to allow the communication between industrial control system and their components; (programmable automation controller, programmable logic controller, I/O systems).

## F

### **FLC**

*full load current*. Also known as *rated current*. The current the motor will draw at the rated voltage and rated load. The LTMR controller has 2 FLC settings: FLC1 (Motor Full Load Current Ratio) and FLC2 (Motor High Speed Full Load Current Ratio), each set as a percentage of FLC max.

### **FLC1**

*Motor Full Load Current Ratio*. FLC parameter setting for low or single speed motors.

### **FLC2**

*Motor High Speed Full Load Current Ratio*. FLC parameter setting for high-speed motors.

### **FLCmax**

*Full Load Current Max*. Peak current parameter.

### **FLCmin**

*Minimum Full Load Current*. The smallest amount of motor current the LTMR controller will support. This value is determined by the LTMR controller model.

## H

### **hysteresis**

A value—added to lower limit threshold settings or subtracted from upper limit threshold settings—that retards the response of the LTMR controller before it stops measuring the duration of faults and warnings.

## I

### **inverse thermal**

A variety of TCC where the initial magnitude of the trip time delay is generated by a thermal model of the motor and varies in response to changes in the value of the measured quantity (e.g. current). Contrast with definite time.

## M

### **Modbus**

Modbus is the name of the master-slave/client-server serial communications protocol developed by Modicon (now Schneider Automation, Inc.) in 1979, which has since become a standard network protocol for industrial automation.

## N

### **nominal power**

*Motor Nominal Power*. Parameter for the power a motor will produce at rated voltage and rated current.

### **nominal voltage**

*Motor Nominal Voltage*. Parameter for rated voltage.

**NTC**

*negative temperature coefficient.* Characteristic of a thermistor—a thermally sensitive resistor—whose resistance increases as its temperature falls, and whose resistance decreases as its temperature rises.

**NTC analog**

Type of RTD.

**P****PLC**

*programmable logic controller.*

**power factor**

Also called *cosine phi* (or  $\phi$ ), power factor represents the absolute value of the ratio of active power to apparent power in AC power systems.

**PROFIBUS DP**

An open bus system that uses an electrical network based on a shielded 2-wire line or an optical network based on a fiber-optic cable.

**PT100**

Type of RTD.

**PTC**

*positive temperature coefficient.* Characteristic of a thermistor—a thermally sensitive resistor—whose resistance increases as its temperature rises, and whose resistance decreases as its temperature falls.

**PTC analog**

Type of RTD.

**PTC binary**

Type of RTD.

**R****reset time**

Time between a sudden change in the monitored quantity (e.g. current) and the switching of the output relay.

**rms**

*root mean square.* A method of calculating average AC current and average AC voltage. Because AC current and AC voltage are bi-directional, the arithmetic average of AC current or voltage always equals 0.

**RTD**

*resistance temperature detector.* A thermistor (thermal resistor sensor) used to measure the temperature of the motor. Required by the LTMR controller's Motor Temp Sensor motor protection function.

**T****TCC**

*trip curve characteristic.* The type of delay used to trip the flow of current in response to a fault condition. As implemented in the LTMR controller, all motor protection function trip time delays are definite time, except for the Thermal Overload function, which also offers inverse thermal trip time delays.

**TVC**

*trip voltage characteristic.* The type of delay used to trip the flow of voltage in response to a fault condition. As implemented by the LTMR controller and the expansion module, all TVCs are definite time.



# Index



## A

active power, 120, 153

n-0, 111, 161

n-1, 111

n-2, 112

n-3, 112

n-4, 113

assembly object, 67

auto restart

delayed condition, 121

delayed count, 110

delayed timeout, 126

enable, 126

immediate condition, 121

immediate count, 110

immediate timeout, 126

manual condition, 121

manual count, 110

status register, 121

auto-reset

attempts group 1 setting, 129

attempts group 2 setting, 129

attempts group 3 setting, 129

group 1 timeout, 129

group 2 timeout, 129

group 3 timeout, 129

average current, 152, 153

n-0, 113, 160

n-1, 114

n-2, 114

n-3, 114

n-4, 115

average current ratio, 152

n-0, 110, 160

n-1, 111

n-2, 111

n-3, 112

n-4, 113

average voltage, 153

n-0, 110, 161

n-1, 111

n-2, 112

n-3, 112

n-4, 113

## C

closings count

motor LO1, 163

motor LO2, 163

command

analog output 1, 140

clear all, 96, 134

clear controller settings, 97, 134

clear IP, 96

clear network port settings, 97, 134

clear statistics, 96, 134

clear thermal capacity level, 97, 134

fault reset, 134, 140

FDR data backup, 40

FDR data restore, 40

logic outputs register, 140

motor low speed, 134, 140

motor run forward, 134, 140

motor run reverse, 134, 140

self test, 134, 140

config via

HMI engineering tool enable, 127

HMI keypad enable, 127

network port enable, 127

configuration software

EDS, 61

contactor rating, 128

control

direct transition, 131

register 1, 134, 140

register 2, 134

setting register, 131

transfer mode, 131

control local

channel setting, 131

control mode

configuration, 127

control remote

channel setting, 131

local buttons enable, 131

local default mode, 131

control supervisor object, 78

controller

AC inputs setting register, 125

AC logic inputs configuration, 125

commercial reference, 108

compatibility code, 108

config checksum, 120

firmware version, 108

ID code, 108

internal temperature, 120

internal temperature max, 109

internal temperature maximum, 163

last power off duration, 163

port ID, 121

power, 117, 138

serial number, 108

system config required, 127

## counter

- Ethernet MB error messages sent, 46
- Ethernet MB messages received, 46
- Ethernet MB messages sent, 46
- Ethernet open clients, 46
- Ethernet opened servers, 46
- Ethernet received correct frames, 45
- Ethernet transmitted correct frames, 46

## current

- average, 121, 153
- ground, 121, 153
- L1, 121
- L2, 121
- L3, 121
- range max, 108
- scale ratio, 108
- sensor max, 108

## current highest imbalance

- L1, 121
- L2, 121
- L3, 121

## current phase imbalance, 120, 153

- fault threshold, 127
- fault timeout running, 127
- fault timeout starting, 127
- n-0, 110, 160
- n-1, 111
- n-2, 112
- n-3, 112
- n-4, 113
- warning threshold, 127

## current phase loss

- timeout, 125

## current ratio

- average, 120
- ground, 120
- L1, 120
- L2, 120
- L3, 120

## custom logic

- auxiliary 1 LED, 152
- auxiliary 2 LED, 152

## custom logic command

- external fault, 137
- register 1, 137

## custom logic monitoring

- register 1, 137
- system ready, 137

## custom logic setting

- register 1, 137

## D

## date and time

- n-0, 110, 160
- n-1, 111
- n-2, 112
- n-3, 112
- n-4, 113
- setting, 130

## diagnostics

- Ethernet, 43

## E

## EDS, 61

## electronic data sheet

- basic, 61
- EDS, 61

## Ethernet, 122, 122, 122

- auto-detection configured, 123
- auto-detection operational, 123
- auto-detection supported, 123
- basic HW diag validity, 43, 122
- broadcast storm protection, 132
- capabilities control, 155
- device name, 46, 124, 155
- device name available, 122
- diagnostics, 43
- extended configuration control, 132
- field extended 1 available, 122
- frame format available, 122
- frame status, 45
- gateway, 44
- gateway address, 123, 155
- gateway address setting, 27, 47, 131
- gateway available, 122
- global status, 44, 122, 122
- global status available, 122
- IP address, 44, 122, 155
- IP address setting, 27, 47, 131
- IP assignment capability, 47, 124
- IP assignment mode available, 122
- IP assignment operational, 47, 124
- IP served by MAC BootP available, 124, 124
- IP served by MAC DHCP available, 124, 124
- IP served by name available, 124, 124
- IP served by stored assignment available, 124,

- 124  
 MAC address, 45, 123, 155  
 MAC address available, 122  
 master IP address setting, 31, 131  
 MB error messages sent counter, 46, 124  
 MB error messages sent counter available, 122  
 MB messages received counter, 46, 124  
 MB messages received counter available, 122  
 MB messages sent counter, 46, 124  
 MB messages sent counter available, 122  
 opened clients counter, 46, 123  
 opened clients counter available, 122  
 opened servers counter, 46, 123  
 opened servers counter available, 122  
 port 502 messaging, 122  
 QoS CIP class 0/1 high, 133  
 QoS CIP class 0/1 high 8021 priority, 133  
 QoS CIP class 0/1 high DSCLPy, 133  
 QoS CIP class 0/1 high queue priority, 133  
 QoS CIP class 0/1 low, 133  
 QoS CIP class 0/1 low 8021 priority, 133  
 QoS CIP class 0/1 low DSCLP, 133  
 QoS CIP class 0/1 low queue priority, 133  
 QoS CIP class 0/1 scheduled, 132  
 QoS CIP class 0/1 scheduled 8021 priority, 132  
 QoS CIP class 0/1 scheduled DSCLP, 132  
 QoS CIP class 0/1 scheduled queue priority, 132  
 QoS CIP class 0/1 urgent, 132  
 QoS CIP class 0/1 urgent 8021 priority, 132, 132  
 QoS CIP class 0/1 urgent queue priority, 132  
 QoS CIP UCMM class 3, 133  
 QoS CIP UCMM class 3 8021 priority, 133  
 QoS CIP UCMM class 3 DSCLP, 133  
 QoS CIP UCMM class 3 queue priority, 133  
 QoS control, 132  
 QoS default outbound priority, 133  
 QoS device control, 133  
 QoS number of ports, 133  
 QoS port 1 default inbound priority, 133  
 QoS port 2 default inbound priority, 133  
 QoS PTP event, 133  
 QoS PTP event 8021 priority, 133  
 QoS PTP event DSCLP, 133  
 QoS PTP event queue priority, 133  
 QoS PTP general, 133  
 QoS PTP general 8021 priority, 133  
 QoS PTP general DSCLPy, 133  
 QoS PTP general queue priority, 133  
 received correct frames counter, 45, 123  
 received correct frames counter available, 122  
 RSTP bridge priority, 132  
 RSTP forward delay, 132  
 RSTP hello time, 132  
 RSTP max age time, 132  
 RSTP port 1 path cost, 132  
 RSTP port 1 priority, 132  
 RSTP port 1 select, 132  
 RSTP port 2 path cost, 132  
 RSTP port 2 priority, 132  
 RSTP port 2 select, 132  
 RSTP port count, 132  
 RSTP transmit count, 132  
 services available, 122  
 services status, 44, 122  
 services validity, 44, 122  
 SNMP community name get setting, 132  
 SNMP community name set setting, 49, 132  
 SNMP community name trap setting, 49, 132  
 SNMP community names get setting, 49  
 SNMP manager address 1 setting, 49, 132  
 SNMP manager address 2 setting, 49, 132  
 SNMP system contact setting, 49, 132  
 SNMP system location setting, 49, 132  
 SNMP system name setting, 49, 132  
 subnet mask, 44, 123, 155  
 subnet mask available, 122  
 subnet mask setting, 27, 47, 131  
 transmitted correct frames counter, 46, 123  
 transmitted correct frames counter available, 122  
**Ethernet II**  
 framing configured, 123  
 framing operational, 123  
 framing receiver configured, 123  
 framing receiver operational, 123  
 framing receiver supported, 123  
 framing registers, 123  
 framing sender configured, 123  
 framing sender operational, 123  
 framing sender supported, 123  
 framing supported, 123  
**EtherNet/IP**  
 device profile, 61  
 explicit message, 60  
 I/O message, 60  
**EtherNet/IP interface diagnostic object**, 87  
**EthernetIP**  
 capabilities control, 133  
**expansion**  
 commercial reference, 108  
 compatibility code, 108  
 firmware version, 108  
 ID code, 108  
 serial number, 108  
**external ground current**  
 fault threshold, 126  
 fault timeout, 126  
 warning threshold, 126

**F**

## fault

controller internal, 116  
 current phase imbalance, 116  
 current phase loss, 117  
 current phase reversal, 117  
 diagnostic, 117  
 external system, 117  
 ground current, 116  
 HMI port, 116  
 internal port, 116  
 jam, 116  
 long start, 116  
 LTME configuration, 117  
 motor temperature sensor, 117  
 network port, 116  
 network port config, 116  
 over power factor, 117  
 overcurrent, 117  
 overpower, 117  
 overvoltage, 117  
 register 1, 116  
 register 2, 117  
 register 3, 117  
 test, 116  
 thermal overload, 116  
 under power factor, 117  
 undervoltage, 116  
 underpower, 117  
 undervoltage, 117  
 voltage phase imbalance, 117  
 voltage phase loss, 117  
 voltage phase reversal, 117  
 wiring, 117, 151

## fault code, 116

n-0, 110, 160  
 n-1, 111  
 n-2, 111  
 n-3, 112  
 n-4, 113

## fault enable

current phase imbalance, 128  
 current phase loss, 129  
 current phase reversal, 129  
 diagnostic, 129  
 ground current, 128  
 HMI port, 128  
 jam, 128  
 long start, 128  
 motor temperature sensor, 129  
 network port, 128  
 over power factor, 129  
 overcurrent, 129  
 overpower, 129  
 overvoltage, 129  
 register 1, 128  
 register 2, 129  
 thermal overload, 128  
 under power factor, 129  
 undervoltage, 128  
 underpower, 129  
 undervoltage, 129  
 voltage phase imbalance, 129  
 voltage phase loss, 129  
 voltage phase reversal, 129  
 wiring, 129

## fault power cycle requested, 118, 139, 152

## fault reset

authorized, 117, 138, 152  
 auto-reset active, 118, 139  
 fault reset mode, 127  
 faults count, 109  
 auto-resets, 109  
 controller internal, 109  
 current phase imbalance, 109  
 current phase loss, 110  
 diagnostic, 110  
 ground current, 109  
 HMI port, 109  
 internal port, 109  
 jam, 109  
 long start, 109  
 motor temperature sensor, 110  
 network port, 109  
 network port config, 109  
 over power factor, 110  
 overcurrent, 110  
 overpower, 110  
 overvoltage, 110  
 thermal overload, 109  
 under power factor, 110  
 undervoltage, 109  
 underpower, 110  
 undervoltage, 110  
 voltage phase imbalance, 110  
 voltage phase loss, 110  
 wiring, 110

## faulty device replacement (FDR), 36

## FDR (faulty device replacement), 36

## frequency, 120, 153

n-0, 110, 161  
 n-1, 111  
 n-2, 112  
 n-3, 112  
 n-4, 113

full load current max, 108, 160

- n-0, 110
- n-1, 111
- n-2, 112
- n-3, 112
- n-4, 113

## G

general configuration

- register 1, 127
- register 2, 127

general purpose registers for logic functions, 137

ground CT

- primary, 126
- secondary, 126

ground current, 153

- fault configuration, 126
- mode, 126
- n-0, 113, 160
- n-1, 114
- n-2, 114
- n-3, 114
- n-4, 115

ground current ratio

- n-0, 110, 160
- n-1, 111
- n-2, 111
- n-3, 112
- n-4, 113

## H

high priority registers

- mirroring, 55

HMI

- display brightness setting, 128
- display contrast setting, 128
- language setting, 130
- language setting register, 130

HMI display

- I/O status enable, 130
- L1 current enable, 130
- active power enable, 130
- average current enable, 130
- average current ratio enable, 130
- average voltage enable, 130
- control mode enable, 130
- current phase imbalance enable, 130
- date enable, 130
- frequency enable, 130
- ground current enable, 130
- items register 1, 130
- items register 2, 130
- L1 current ratio enable, 130
- L1-L2 voltage enable, 130
- L2 current enable, 130
- L2 current ratio enable, 130
- L2-L3 voltage enable, 130
- L3 current enable, 130
- L3 current ratio enable, 130
- L3-L1 voltage enable, 130
- motor status enable, 130
- motor temperature sensor enable, 130
- operating time enable, 130
- power consumption enable, 130
- power factor enable, 130
- reactive power enable, 130
- start statistics enable, 130
- starts per hour enable, 130
- thermal capacity level enable, 130
- thermal capacity remaining enable, 130
- time enable, 130
- time to trip enable, 130
- voltage phase imbalance enable, 130

HMI display items register 3, 130

HMI display temperature sensor degree CF, 130

HMI motor status LED color, 127

HMI port

- address setting, 127
- baud rate setting, 127
- comm loss, 118, 139
- endian setting, 127
- fallback setting, 129
- parity setting, 127

## I

I/O scanning

- configuring, 55

I/O status, 119

In remote, 117, 138

internal ground current

- fault threshold, 127
- fault timeout, 127
- warning threshold, 127

IP addressing, 32

## J

jam

- fault threshold, 127
- fault timeout, 127
- warning threshold, 127

- L**
- L1 current
    - n-0, 113, 160
    - n-1, 114
    - n-2, 114
    - n-3, 114
    - n-4, 115
  - L1 current ratio
    - n-0, 110, 160
    - n-1, 111
    - n-2, 111
    - n-3, 112
    - n-4, 113
  - L1-L2 voltage
    - n-0, 111, 161
    - n-1, 111
    - n-2, 112
    - n-3, 112
    - n-4, 113
  - L2 current
    - n-0, 113, 160
    - n-1, 114
    - n-2, 114
    - n-3, 114
    - n-4, 115
  - L2 current ratio
    - n-0, 110, 160
    - n-1, 111
    - n-2, 111
    - n-3, 112
    - n-4, 113
  - L2-L3 voltage
    - n-0, 111, 161
    - n-1, 111
    - n-2, 112
    - n-3, 112
    - n-4, 113
  - L3 current
    - n-0, 113, 160
    - n-1, 114
    - n-2, 114
    - n-3, 114
    - n-4, 115
  - L3 current ratio
    - n-0, 110, 160
    - n-1, 111
    - n-2, 111
    - n-3, 112
    - n-4, 113
  - L3-L1 voltage
    - n-0, 110, 161
    - n-1, 111
    - n-2, 112
    - n-3, 112
    - n-4, 113
  - link
    - ethernet, 30
  - load CT
    - multiple passes, 128
    - primary, 128
    - ratio, 108
    - secondary, 128
  - load shedding, 118, 139
    - enable, 126
    - timeout, 126
  - load shedding count, 110
  - logic input, 151
  - logic input 3
    - external ready enable, 137
  - logic output, 151
  - long start
    - fault threshold, 127
    - fault timeout, 127
- M**
- master IP, 31
  - minimum wait time, 116, 152
  - mirroring
    - input table changed, 138
    - input table freshness, 138
    - input table validity, 138
    - output table changed, 138
    - output table freshness, 138
    - output table validity, 138
    - status register, 138
    - system status register 1, 138
  - mirroring high priority registers, 55
  - Modbus
    - master IP, 31
  - motor
    - auxiliary fan cooled, 127
    - average current ratio, 117, 138
    - full load current ratio, 130
    - high speed full load current ratio, 130
    - last start current, 121, 163
    - last start duration, 121, 163
    - lockout timeout, 125
    - nominal power, 126
    - nominal voltage, 126
    - operating mode, 125
    - phases, 127
    - phases sequence, 127
    - restart time undefined, 118, 139
    - running, 117, 138
    - speed, 118, 139
    - star-delta, 127
    - starting, 117, 138
    - starts per hour count, 121, 163
    - temperature sensor fault threshold, 125
    - temperature sensor type, 125
    - temperature sensor warning threshold, 125
    - transition lockout, 118, 139
    - trip class, 127
  - motor full load current ratio, 160
    - n-0, 110
    - n-1, 111
    - n-2, 111
    - n-3, 112
    - n-4, 113
  - motor high speed, 152
  - motor running, 152
  - motor starting, 152
  - motor starts count, 109, 163
  - motor step 1 to 2
    - threshold, 129
    - timeout, 129
  - motor temperature sensor, 120
    - fault threshold degree, 125
    - warning threshold degree, 125

## **N**

### network port

- address setting, 131
- bad config, 121
- baud rate, 121
- baud rate setting, 131
- comm loss, 118, 139
- comm loss timeout, 29, 30, 31
- communicating, 121
- compatibility code, 108
- connected, 121
- endian setting, 127
- fallback setting, 29, 31, 131
- fault enable, 29
- FDR auto backup enable, 39
- FDR auto backup period setting, 39
- FDR controller interval, 28
- FDR status, 39, 40, 155
- FDR synchro setting, 28
- firmware version, 108
- frame type, 27, 45
- ID code, 108
- monitoring, 121
- parity, 121
- self-detecting, 121
- self-testing, 121
- SNMP trap authentication failure enable, 49
- warning enables, 29

## **O**

### object

- EtherNet/IP interface, 87

### objects

- assembly, 67
- control supervisor, 78
- identity, 63
- message router, 65
- overload, 81

### operating time, 109, 163

### over power factor

- fault threshold, 126
- fault timeout, 126
- warning threshold, 126

### overcurrent

- fault threshold, 125
- fault timeout, 125
- warning threshold, 125

### overload object, 81

## **P**

### overpower

- fault threshold, 126
- fault timeout, 126
- warning threshold, 126

### overvoltage

- fault threshold, 126
- fault timeout, 126
- warning threshold, 126

## **R**

### Periodic Registers Service Objects, 83

#### phase imbalances register, 121

#### PKW, 83

#### Periodic Registers Service Objects, 83

### power consumption

- active, 110
- reactive, 110

### power factor, 120, 153

- n-0, 111, 161
- n-1, 111
- n-2, 112
- n-3, 112
- n-4, 113

## **S**

### self test, 128

### simple network management protocol (SNMP), 48

### SNMP (simple network management protocol), 48

### starts count

- motor LO1, 109
- motor LO2, 109

### stop HMI

- disable, 131

### stop terminal strip

- disable, 131

### system

- fault, 117, 138, 152
- on, 117, 138, 151
- ready, 117, 138, 151
- tripped, 117, 138
- warning, 117, 138, 152

### system status

- logic inputs, 118, 139
- logic outputs, 118, 139
- register 1, 117
- register 2, 118, 139

## **T**

### TeSys T

- motor management system, 9

thermal capacity level, 120, 153

- n-0, 110, 160
- n-1, 111
- n-2, 111
- n-3, 112
- n-4, 113

thermal overload

- fault definite timeout, 125
- fault reset threshold, 127
- mode, 125
- setting, 125
- warning threshold, 127

time to trip, 121, 152

## U

under power factor

- fault threshold, 126
- fault timeout, 126
- warning threshold, 126

undercurrent

- fault threshold, 127
- fault timeout, 127
- warning threshold, 127

underpower

- fault threshold, 126
- fault timeout, 126
- warning threshold, 126

undervoltage

- fault threshold, 126
- fault timeout, 126
- warning threshold, 126

user map addresses setting, 135

user map values, 135

## V

voltage

- average, 120
- L1-L2, 120
- L2-L3, 120
- L3-L1, 120
- phase imbalance, 120

voltage dip

- detection, 121
- occurred, 121
- restart threshold, 126
- restart timeout, 126
- setting, 126
- threshold, 126

voltage highest imbalance

- L1-L2, 121
- L2-L3, 121
- L3-L1, 121

voltage phase imbalance, 153

- fault threshold, 126
- fault timeout running, 126
- fault timeout starting, 126

- n-0, 111, 161

- n-1, 111

- n-2, 112

- n-3, 112

- n-4, 113

- warning threshold, 126

voltage phase loss

- fault timeout, 126

## W

warning

- controller internal temperature, 119
- current phase imbalance, 119
- current phase loss, 120
- current phase reversal, 120
- diagnostic, 120
- ground current, 119
- HMI port, 119
- jam, 119
- LTME configuration, 120
- motor temperature sensor, 120
- network port, 119
- over power factor, 120
- overcurrent, 120
- overpower, 120
- overvoltage, 120
- register 1, 119
- register 2, 120
- register 3, 120
- thermal overload, 119
- under power factor, 120
- undercurrent, 119
- underpower, 120
- undervoltage, 120
- voltage phase imbalance, 120
- voltage phase loss, 120

warning code, 119

warning enable

- controller internal temperature, 128
- current phase balance, 128
- current phase loss, 129
- diagnostic, 129
- ground current, 128
- HMI port, 128
- jam, 128
- motor temperature sensor, 129
- network port, 128
- over power factor, 129
- overcurrent, 129
- overpower, 129
- overvoltage, 129
- register 1, 128
- register 2, 129
- thermal overload, 128
- under power factor, 129
- undercurrent, 128
- underpower, 129
- undervoltage, 129
- voltage phase imbalance, 129
- voltage phase loss, 129

warnings count, 109

- thermal overload, 109

wiring

- fault, 151









DOCA0129EN-00

**Schneider Electric Industries SAS**  
35, rue Joseph Monier  
CS30323  
F - 92506 Rueil Malmaison Cedex

[www.schneider-electric.com](http://www.schneider-electric.com)

*As standards, specifications and designs change from time to time, please ask for confirmation of the information given in this publication.*

07/2017