

- Page 77, in Table 32: Suggested Components for Standard Duty Applications.
Under Control fuses (FU4/FU5), replace 0.25 A with **0.5 A UL Class CC, 600 V time delay fuses**.
- Page 78, in Table 33: Additional Suggested Components for Standard Duty Applications.
New IC1, IC2, and SC component selections apply. See Table 1.

Table 1: Corrections to Table 33

| ATS48 Controller Model | IC1 ^{1, 2, 3} Isolation Contactor | IC2 ^{1, 2, 3} | | SC ^{1, 2, 3} Shorting Contactor (AC1) |
|------------------------------|--|-------------------------------------|-------------------------|---|
| | | Reversing Contactor ⁶ | Mechanical Interlock | |
| D17Y | LC1D12G7 | LC1D12G7 | ⁹ | LC1D12G7 |
| D22Y | LC1D18G7 | LC1D18G7 | ⁹ | LC1D18G7 |
| D32Y | LC1D25G7 | LC1D25G7 | ⁹ | LC1D25G7 |
| D38Y | LC1D32G7 | LC1D32G7 | ⁹ | LC1D32G7 |
| D47Y | LC1D32G7 | LC1D32G7 | ⁹ | LC1D32G7 |
| D62Y | LC1D40G7 | LC1D40G7 | ⁹ | LC1D40G7 |
| D75Y | LC1D80G7 | LC1D80G7 | ⁹ | LC1D80G7 |
| D88Y | LC1D80G7 | LC1D80G7 | ⁹ | LC1D80G7 |
| C11Y | LC1D80G7 | LC1D80G7 | ⁹ | LC1D80G7 |
| C14Y | LC1D115G7 | LC1D115G7 | ⁹ | LC1D115G7 |
| C17Y | LC1D115G7 | LC1D115G7 | ⁹ | LC1D115G7 |
| C21Y | LC1D150G7 | LC1D150G7 | LA9 FG970 | LC1D150G7 |
| C25Y | LC1F185G6 | LC1F185G6 | LA9 FJ970 | LC1F185G6 |
| C32Y | LC1F330G7 | LC1F330G7 | LA9 FJ970 | LC1F330G7 |
| C41Y | LC1F330G7 | LC1F330G7 | LA9 FJ970 | LC1F330G7 |
| C48Y | LC1F400F7 | LC1F400F7 | LA9 FJ970 | LC1F400F7 |
| C59Y | LC1F500F7 | LC1F500F7 | LA9 FJ970 | LC1F500F7 |
| C66Y | LC1F630F7 | LC1F630F7 | LA9 FJ970 | LC1F630F7 |
| C79Y | LC1F630F7 | LC1F630F7 | LA9 FL970 | LC1F630F7 |
| M10Y | LC1F630F7 | LC1F630F7 | LA9 FL970 | LC1F630F7 |
| M12Y | LC1F780F7 | LC1F780F7 | LA9 FX970 | LC1F780F7 |

- ¹ All coils are selected for 120 V, 60 Hz operation. Refer to the Square D *Digest* for additional coil voltages or auxiliary contact configurations. One block may be added to each contactor.
- ² Power terminals are not included with LC1F contactors. Refer to the latest editions of Square D / Schneider Electric's full line product catalogs for additional ordering information.
- ³ The use of transient suppressors across all contactor coils is recommended. Refer to the latest editions of Square D / Schneider Electric's full line product catalogs for selection of transient suppressors.
- ⁶ Reversing contactors for C11 through M12 controllers must be assembled from components. Parts quantities for a basic contactor assembly, minus the power connection links and terminals, are indicated before each part number. Refer to the latest editions of Square D / Schneider Electric's full line product catalogs for power connector link and terminal kits. Reversing contactor interlock units used for the C79 through M12 controllers are designed for vertical interlocking of the individual contactors. Horizontally interlocked contactors are used for D17 through C59 controllers.
- ⁹ The D Line contactor is available as a reversing configuration. For these applications, change the IC1 part number prefix from LC1- to LC2- to order the IC1 and IC2 combination complete with mechanical interlocks.


Square D Company
8001 Highway 64 East
Knightdale, NC 27545 USA
1-888-SquareD (1-888-778-2733)
www.SquareD.com

Electrical equipment should be installed, operated, serviced, and maintained only by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this material.



ALTISTART® 48 Y-Range Soft Start Controllers Installation Guide

Retain for future use.



SQUARE D

TABLE OF CONTENTS

| | | |
|--|---|----|
| SECTION 1: QUICK START PROCEDURE | | 5 |
| SECTION 2: RECEIVING AND HANDLING | Introduction | 9 |
| | Terminology | 9 |
| | Handling the Controller | 10 |
| SECTION 3: TECHNICAL DATA | Technical Characteristics | 11 |
| | Specifications | 12 |
| | Dimensions and Weights | 15 |
| | Serial and Model Numbers | 16 |
| SECTION 4: MOUNTING | Mounting Precautions | 17 |
| | Mounting in a General Purpose Metal Enclosure | 18 |
| | Soft Starter Ventilation | 18 |
| | Mounting in a Dust and Damp-Proof Metal Enclosure | 18 |
| | Thermal Considerations for Sizing Enclosures | 19 |
| | Remote Keypad Display (if used) | 19 |
| SECTION 5: WIRING | Installation Precautions | 21 |
| | General Wiring Practices | 24 |
| | Adaptation to Line Input | 24 |
| | Power Connections | 25 |
| | Control Connections | 29 |
| | Layout of Control Terminals | 30 |
| SECTION 6: APPLICATION AND PROTECTION | Soft Starter Applications | 31 |
| | Standard Duty Applications | 31 |
| | Severe Duty Applications | 31 |
| | Reduced Torque | 31 |
| | INTELE™ Braking | 32 |
| | Motor Protection and Diagnostics | 33 |
| | Thermal Overload Protection | 33 |
| | Motor Thermal Protection with PTC Probes | 35 |
| | Preventive Maintenance | 36 |
| SECTION 7: PROGRAMMING | Programming and Setup | 37 |
| | Preliminary Recommendations | 37 |
| | Display Unit and Programming | 38 |
| | Display Principle | 38 |
| | Menus | 39 |
| SECTION 8: FAULT MANAGEMENT | Soft Starter Does Not Start, No Fault Displayed | 63 |
| | Non-Resettable Faults | 63 |
| | Resettable Faults when Causes Disappear | 64 |
| | Auto-Reset Faults (Customer Configurable) | 64 |
| | Manual-Reset Faults | 65 |
| | Reset Faults Using a Logic Input | 66 |
| | Troubleshooting Procedure | 67 |
| | Technical Support | 67 |
| | Factory Settings | 69 |
| APPENDIX A: RECOMMENDED WIRING DIAGRAMS | | 73 |
| APPENDIX B: RECOMMENDED COMPONENT LISTS | | 77 |

| | |
|--|----|
| APPENDIX C: OPTIONS AND ACCESSORIES | 79 |
| PowerSuite Advanced Dialogue Solutions | 79 |

SECTION 1— QUICK START PROCEDURE

CAUTION

HAZARD OF EQUIPMENT DAMAGE

Do not operate or install any equipment that appears damaged.

Failure to follow this instruction can result in injury or equipment damage.

1. Before installing or storing the ALTISTART® 48 (ATS48) soft starter, thoroughly inspect it according to the instructions in “Receiving and Preliminary Inspection” on page 9.
 - a. Verify that the soft starter catalog number printed on the label is the same as that on the packing slip and corresponding purchase order.
 - b. Remove the ATS48 soft starter from its packaging and check that it has not been damaged during transit. If any damage is found, notify the carrier and your Schneider Electric representative.
2. Install the ATS48 soft starter in accordance with the mounting, ventilation, and environmental requirements specified under “Mounting” on page 17.

DANGER

HAZARDOUS VOLTAGE

Disconnect all power supplying this equipment prior to working on it.

Failure to follow this instruction will result in death or serious injury.

3. With the power removed, make the following connections to the ATS48 soft starter:
 - a. Connect the 115 V or 230 Vac control supply to CL1 and CL2.
 - b. Connect the power supply to 1/L1, 3/L2, and 5/L3.
 - c. Connect the motor to 2/T1, 4/T2, and 6/T3.

NOTE: If a shorting/bypass contactor is used, connect it between L1, L2, and L3 on the line side supply terminals and A2, B2, and C2 of the ATS48 soft starter. Refer to Figure 1 and to the wiring diagrams in Appendix A beginning on page 73.

Figure 1: Power Block Diagram





Figure 2: Control Circuit Terminal Configuration



NOTE: Wire the fault relay in the line contactor power supply sequence in order to open the electrical circuit in the event of a fault/trip condition.

- Set parameter I_N (in the SEt menu, see page 41) to the motor nameplate current.
- Apply power to the control terminals (CL1 and CL2). **Do not** apply power to the power terminals yet, and do not give a run command. The soft starter displays nLP to indicate that it is not powered up.
- The ATS48 soft starter is factory configured for most standard duty applications. See Table 1 for the factory preset values. If the factory configuration is not suitable for your application, refer to “Programming” on page 37 for information on changing the parameter settings.
- Apply power to terminals 1/L1, 3/L2, and 5/L3. The soft starter will display rdY indicating that it is powered up.
- Connect +24 V to the RUN control terminal to start the system.

Table 1: Factory Configuration

| | |
|----------------------------------|--|
| Nominal motor current (I_N) | preset to correspond to 460 V rated motor current based on NFPA 70/NEC Table 430.150 ratings |
| Current Limit (ILt) | 400% of the motor current I_N |
| Acceleration ramp (ACC) | 15 seconds |
| Initial torque on starting (tq0) | 20% of the nominal torque |

Table 1: Factory Configuration *(continued)*

| | |
|---|---|
| Stop (StY) | Freewheel stop (-F-) |
| Motor thermal protection (tHP) | Class 10 thermal overload protection curve |
| Display | rdY (soft starter ready) when power and control voltage are present and the motor is operating. |
| Logic inputs <ul style="list-style-type: none"> • LI1 • LI2 • LI3 • LI4 | <ul style="list-style-type: none"> • STOP • RUN • Forced freewheel stop (LIA) • Forced local mode (LIL) |
| Logic outputs <ul style="list-style-type: none"> • LO1 • LO2 | <ul style="list-style-type: none"> • Motor thermal alarm (tA1) • Motor powered (mI) |
| Relay outputs <ul style="list-style-type: none"> • R1 • R2 • R3 | <ul style="list-style-type: none"> • Fault relay (r1F) • Bypass relay at the end of starting • Motor powered (mI) |
| Analog output (AO) | Motor current (OCr, 0–20 mA) |
| Communication parameters | <ul style="list-style-type: none"> • When connected via the serial link, the soft starter has a logic address (Add) of 0 • Transmission speed (tbr): 19200 bits per second • Communication format (FOr): 8 bits, no parity, 1 stop bit (8n1) |

SECTION 2— RECEIVING AND HANDLING

INTRODUCTION

The ALTISTART® 48 (ATS48) soft starter offers state-of-the-art acceleration and deceleration control of standard three-phase asynchronous induction (squirrel cage) motors. The ATS48 controller uses a patented technology to control the motor performance based on the motor torque rather than simple voltage or current based control. Advanced control algorithms are incorporated to ensure smooth rotation throughout the starting ramp without mechanical instability at the end of starting.

A microprocessor continuously monitors the motor and controller performance to provide maximum protection of the controller, motor, and driven machinery. A variety of starting and stopping modes are standard. A digital keypad display provides accurate controller setup and continuous motor performance display.

The ATS48 controller is available in twenty-one current ratings from 17 to 1200 A. All models use a common control interface for consistent and simple set up. ATS48 controllers are rated for use with 208 to 690 V motors, and are self-adjusting for a 50 or 60 Hz supply frequency.

This instruction bulletin covers the technical characteristics, specifications, installation, wiring, programming, and troubleshooting of all ATS48 controllers.

Many option kits are available for the ATS48 controllers. Refer to Appendix C beginning on page 79.

Terminology

Some of the terms and acronyms used in this manual are defined in Table 2.

Table 2: Definition of Terms

| Term | Definition |
|----------|---|
| FLA | Full load amps: the current rating of an induction motor at rated speed and load. This value may be found on the motor nameplate. |
| I_{CL} | Nominal current rating of the ATS48 controller. This value may be found on the controller nameplate. |
| I_N | User defined motor current rating. Same as FLA. |
| T_N | Nominal motor torque as calculated by the ATS48 controller. |
| V_N | Nominal voltage of supply power (mains supply). This should correspond to the motor rated voltage on the motor nameplate. |

REVISION LEVEL

This is a new document.

RECEIVING AND PRELIMINARY INSPECTION

Before installing the ATS48 controller, read this manual and follow all precautions.

Before removing the ATS48 controller from its packing material, verify that the packing carton is not damaged from shipping. Damage to the packing carton usually indicates improper handling. If any damage is found, notify the carrier and your Square D / Schneider Electric representative.

After removing the ATS48 controller from its packaging, inspect it for damage. If any shipping damage is found, notify the carrier and your sales representative. Verify that the ATS48 controller nameplate and label conform to the packing slip and corresponding purchase order.

⚠ CAUTION

EQUIPMENT DAMAGE HAZARD

Do not operate or install any controller that appears damaged.


Failure to follow this instruction can result in injury or equipment damage.

STORING AND SHIPPING

If the ATS48 controller is not being immediately installed, store it in a clean, dry area where the ambient temperature is between -13 and +158 °F (-25 and +70 °C). If the ATS48 controller must be shipped to another location, use the original shipping material and carton to protect it.

HANDLING THE CONTROLLER

Figure 3: Hoisting the ATS48 Controller



Do not remove the ATS48 controller from the carton until it is at the final installation site. The carton provides protection and prevents damage to the controller's exterior. Handle the controller carefully after removing it from the carton to avoid damage to the internal components, frame, or exterior. Once removed from the carton, the controller can be handled:

- With a hoist. When hoisting the controller, attach a spreader bar to the two lifting holes on top of the controller as shown in Figure 3.
- In a horizontal position, with the back of the controller resting on a pallet.

The ATS48 range comprises 6 sizes, with various weights and dimensions. Small controller can be removed from their packaging and installed without a handling device. A handling device must be used with large controllers; for this reason they are supplied with lifting holes.

NOTE: Do not rest the unit directly on the bus bar connectors.

⚠ WARNING

HANDLING AND LIFTING HAZARD

Keep the area below any equipment being lifted clear of all personnel and property. Use the lifting method shown in Figure 3.

Failure to follow this instruction can result in death or serious injury.

SECTION 3— TECHNICAL DATA

TECHNICAL CHARACTERISTICS

Tables 3 and 4 describe the technical characteristics of the ATS48 controller. The information is based on operation at a maximum ambient temperature of 40 °C without a shorting/bypass contactor and at 50 °C with a shorting/bypass contactor.

The ATS48 controller can be used in an ambient temperature of up to 60 °C as long as the maximum current rating for Class 10 thermal overload protection is derated by 2% for each degree above 40 °C without a shorting/bypass contactor or by 2% for each degree above 50 °C with a shorting/bypass contactor. The nominal motor current I_N must not exceed the maximum current rating for Class 10 thermal overload protection.

Table 3: Standard Duty Application, 208 to 690 V Supply (+10% to -15%, 50 or 60 Hz)

| hp @ 208 V | hp @ 230 V | kW @ 440 V | hp @ 460 V | kW @ 500 V | hp @ 575 V | kW @ 690 V | Max. Current Rating for Class 10 Thermal Overload Protection | I _{CL} Rating | Catalog Number |
|---------------|---------------|---------------|---------------|---------------|---------------|---------------|--|------------------------|----------------|
| 3 | 5 | 7.5 | 10 | 9 | 15 | 15 | 17 | 17 | ATS48D17Y |
| 5 | 7.5 | 11 | 15 | 11 | 20 | 18.5 | 22 | 22 | ATS48D22Y |
| 7.5 | 10 | 15 | 20 | 18.5 | 25 | 22 | 32 | 32 | ATS48D32Y |
| 10 | — | 18.5 | 25 | 22 | 30 | 30 | 38 | 38 | ATS48D38Y |
| — | 15 | 22 | 30 | 30 | 40 | 37 | 47 | 47 | ATS48D47Y |
| 15 | 20 | 30 | 40 | 37 | 50 | 45 | 62 | 62 | ATS48D62Y |
| 20 | 25 | 37 | 50 | 45 | 60 | 55 | 75 | 75 | ATS48D75Y |
| 25 | 30 | 45 | 60 | 55 | 75 | 75 | 88 | 88 | ATS48D88Y |
| 30 | 40 | 55 | 75 | 75 | 100 | 90 | 110 | 110 | ATS48C11Y |
| 40 | 50 | 75 | 100 | 90 | 125 | 110 | 140 | 140 | ATS48C14Y |
| 50 | 60 | 90 | 125 | 110 | 150 | 160 | 170 | 170 | ATS48C17Y |
| 60 | 75 | 110 | 150 | 132 | 200 | 200 | 210 | 210 | ATS48C21Y |
| 75 | 100 | 132 | 200 | 160 | 250 | 250 | 250 | 250 | ATS48C25Y |
| 100 | 125 | 160 | 250 | 220 | 300 | 315 | 320 | 320 | ATS48C32Y |
| 125 | 150 | 220 | 300 | 250 | 350 | 400 | 410 | 410 | ATS48C41Y |
| 150 | — | 250 | 350 | 315 | 400 | 500 | 480 | 480 | ATS48C48Y |
| — | 200 | 355 | 400 | 400 | 500 | 560 | 590 | 590 | ATS48C59Y |
| 200 | 250 | 400 | 500 | — | 600 | 630 | 660 | 660 | ATS48C66Y |
| 250 | 300 | 500 | 600 | 500 | 800 | 710 | 790 | 790 | ATS48C79Y |
| 350 | 350 | 630 | 800 | 630 | 1000 | 900 | 1000 | 1000 | ATS48M10Y |
| 400 | 450 | 710 | 1000 | 800 | 1200 | — | 1200 | 1200 | ATS48M12Y |

Table 4: Severe Duty Application, 208 to 690 V Supply (+10% to –15%, 50 or 60 Hz)

| hp @ 208 V | hp @ 230 V | kW @ 440 V | hp @ 460 V | kW @ 500 V | hp @ 575 V | kW @ 690 V | Max. Current Rating for Class 10 Thermal Overload Protection | I _{CL} Rating | Catalog Number |
|---------------|---------------|---------------|---------------|---------------|---------------|---------------|--|------------------------|----------------|
| 2 | 3 | 5.5 | 7.5 | 7.5 | 10 | 11 | 12 | 17 | ATS48D17Y |
| 3 | 5 | 7.5 | 10 | 9 | 15 | 15 | 17 | 22 | ATS48D22Y |
| 5 | 7.5 | 11 | 15 | 11 | 20 | 18.5 | 22 | 32 | ATS48D32Y |
| 7.5 | 10 | 15 | 20 | 18.5 | 25 | 22 | 32 | 38 | ATS48D38Y |
| 10 | — | 18.5 | 25 | 22 | 30 | 30 | 38 | 47 | ATS48D47Y |
| — | 15 | 22 | 30 | 30 | 40 | 37 | 47 | 62 | ATS48D62Y |
| 15 | 20 | 30 | 40 | 37 | 50 | 45 | 62 | 75 | ATS48D75Y |
| 20 | 25 | 37 | 50 | 45 | 60 | 55 | 75 | 88 | ATS48D88Y |
| 25 | 30 | 45 | 60 | 55 | 75 | 75 | 88 | 110 | ATS48C11Y |
| 30 | 40 | 55 | 75 | 75 | 100 | 90 | 110 | 140 | ATS48C14Y |
| 40 | 50 | 75 | 100 | 90 | 125 | 110 | 140 | 170 | ATS48C17Y |
| 50 | 60 | 90 | 125 | 110 | 150 | 160 | 170 | 210 | ATS48C21Y |
| 60 | 75 | 110 | 150 | 132 | 200 | 200 | 210 | 250 | ATS48C25Y |
| 75 | 100 | 132 | 200 | 160 | 250 | 250 | 250 | 320 | ATS48C32Y |
| 100 | 125 | 160 | 250 | 220 | 300 | 315 | 320 | 410 | ATS48C41Y |
| 125 | 150 | 220 | 300 | 250 | 350 | 400 | 410 | 480 | ATS48C48Y |
| 150 | — | 250 | 350 | 315 | 400 | 500 | 480 | 590 | ATS48C59Y |
| — | 200 | 355 | 400 | 400 | 500 | 560 | 590 | 660 | ATS48C66Y |
| 200 | 250 | 400 | 500 | — | 600 | 630 | 660 | 790 | ATS48C79Y |
| 250 | 300 | 500 | 600 | 500 | 800 | 710 | 790 | 1000 | ATS48M10Y |
| 350 | 350 | 630 | 800 | 630 | 1000 | 900 | 1000 | 1200 | ATS48M12Y |

SPECIFICATIONS

Table 5: Environmental Characteristics

| | |
|--|---|
| Degree of protection | <ul style="list-style-type: none"> IP20 for ATS48D17Y to C11Y IP00 for ATS48C14Y to M12Y |
| Shock resistance | Conforms to IEC 60068-2-27: <ul style="list-style-type: none"> 15 g, 11 ms |
| Vibration resistance | Conforms to IEC 60068-2-6, NCF 20706 and BV1: <ul style="list-style-type: none"> 15 mm peak from 2 to 13 Hz 1 gn from 13 to 200 Hz |
| Soft starter audible noise level | Audible noise measurements taken from 3 ft (1 m) away. The noise levels may change depending on the fan characteristics: <ul style="list-style-type: none"> ATS48D17Y to D47Y: 52 dBA ATS48D62Y to C11Y: 58 dBA ATS48C14Y to C17Y: 50 dBA ATS48C21Y to C32Y: 54 dBA ATS48C41Y to C66Y: 55 dBA ATS48C79Y to M12Y: 60 dBA |
| Resistance to electrostatic discharges | Conforms to IEC 61000-4-2, Level 3 |
| Immunity to radio-electric interference | Conforms to IEC 61000-4-3, Level 3 |
| Immunity to rapid electrical transients | Conforms to IEC 61000-4-4, Level 4 |

Table 5: Environmental Characteristics *(continued)*

| | |
|-----------------------------------|--|
| Ambient air temperature | Storage: |
| | <ul style="list-style-type: none"> -13 to +158 °F (-25 to +70 °C) |
| Ambient air temperature | Operation: |
| | <ul style="list-style-type: none"> 14 to +104 °F (-10 °C to +40 °C) without derating. Up to +140 °F (+60 °C), derate the current by 2% for each °C above 40 °C. 14 to 122 °F (-10 °C to +50 °C) with user provided shorting/bypass contactor. |
| Maximum relative humidity | 95% without condensation or dripping water conforming to IEC 60068-2-3 |
| Maximum ambient pollution | Conforms to IEC 60664-1, Pollution Degree 3 |
| Maximum operating altitude | 3300 ft (1000 m) without derating. Above this, derate the nominal current by 2.2% for each additional 330 ft (100 m) to a maximum of 6600 ft (2000 m). |
| Operating position | Maximum vertical inclination ±10° with respect to the normal mounting position. |

Table 6: Electrical Characteristics

| | |
|--|--|
| Operating category | Conforms to IEC 60947-4-2, AC-53a |
| Three-phase supply voltage | 208 Vac -15% to 690 Vac +10%, 50/60 Hz |
| Frequency | Automatic sensing (preset), ±5%: |
| | <ul style="list-style-type: none"> 60 Hz: 56.6 to 63.8 Hz 50 Hz: 47.6 to 52.6 Hz |
| Frequency | Manual selection, ±20%: |
| | <ul style="list-style-type: none"> 50 Hz: 40 to 60 Hz 60 Hz: 48 to 72 Hz |
| Rated current (I_{CL}) | 21 device ratings, 17 to 1200 A |
| Silicon control rectifiers (SCRs) | 1800 V peak inverse voltage (PIV) rating |
| Motor power | 3 to 1200 hp |
| Motor voltage | 208 / 230 / 380 / 460 / 575 / 690 Vac |
| Soft starter control circuit supply voltage | 110 Vac -15% to 230 Vac, 50/60 Hz |
| Maximum control circuit consumption (with fans operating) | <ul style="list-style-type: none"> ATS48D17Y to C17Y: 30 W ATS48C21Y to C32Y: 50 W ATS48C41Y to M12Y: 80 W |
| Protection | <ul style="list-style-type: none"> Integrated thermal I²t protection for motor (Class 2, 10, 10A, 15, 20, 25, 30 or no protection) and/or thermal protection with positive temperature coefficient (PTC) probes. Motor underload settings Current overload settings Phase reversal Phase loss Automatic restart |

The ATS48 controllers conform to IEC 60947-4-2 (EMC). In steady state, they emit a level of interference below the allowable levels defined in the standard.

Table 7: Electromagnetic Compatibility (EMC)

| | Standards | Test Levels | Examples (sources of interference) |
|---|---|--------------|---|
| Immunity tests | IEC 61000-4-2, Level 3 Electrostatic discharge: <ul style="list-style-type: none"> through contact through air | 6 kV 8 kV | Contact with an electrically charged person |
| | IEC 61000-4-3, Level 3 Radiated electromagnetic fields | 10 V/m | Equipment transmitting radio frequencies |
| | IEC 61000-4-5, Level 4 Rapid electrical transients: <ul style="list-style-type: none"> Power supply cables Control supply cables | 4 kV 2 kV | Opening/closing of a contactor |
| | IEC 61000-4-5, Level 3 Shock wave: <ul style="list-style-type: none"> Phase-to-Phase Phase-to-Ground | 1 kV 2 kV | — |
| | IEC 61000-4-12, Level 3 Damped oscillating waves | 1 kV – 1 MHz | Oscillating circuit on the line supply |
| Radiated and conducted emissions | IEC 60947-4-2, Class A | | |
| | IEC 60947-4-2, Class B on soft starters up to 170 A (ATS48D17Y to C17Y) shorting/bypass contactors must be used. | | |

Fuse selections in Table 8 are based upon 150% of nominal motor current. Ferraz-Shawmut fuses are recommended for the overcurrent protective device (OCPD).

Table 8: Short Circuit Protection Device (Type 1 Coordination)

| Catalog Number | Fuse Class (Time Delay) | Short Circuit Current Rating @ 575 V (A) | Recommended OCPD Rating (A) @ | | | |
|----------------|----------------------------|--|-------------------------------|-------|-------|-------|
| | | | 208 V | 230 V | 460 V | 575 V |
| ATS48D17Y | J | 5000 | 15 | 20 | 20 | 25 |
| ATS48D22Y | J | 5,000 | 25 | 30 | 30 | 30 |
| ATS48D32Y | J | 5,000 | 35 | 40 | 40 | 40 |
| ATS48D38Y | J | 5,000 | 45 | — | 50 | 45 |
| ATS48D47Y | J | 5,000 | — | 60 | 60 | 60 |
| ATS48D62Y | J | 5,000 | 70 | 80 | 80 | 80 |
| ATS48D75Y | J | 10,000 | 90 | 100 | 100 | 90 |
| ATS48D88Y | J | 10,000 | 110 | 125 | 110 | 110 |
| ATS48C11Y | J | 10,000 | 125 | 150 | 150 | 150 |
| ATS48C14Y | J | 10,000 | 175 | 200 | 175 | 175 |
| ATS48C17Y | J | 10,000 | 200 | 225 | 225 | 225 |
| ATS48C21Y | J | 10,000 | 250 | 300 | 250 | 300 |
| ATS48C25Y | J | 18,000 | 300 | 350 | 350 | 350 |
| ATS48C32Y | J | 18,000 | 400 | 450 | 450 | 400 |
| ATS48C41Y | J | 18,000 | 500 | 500 | 600 | 500 |
| ATS48C48Y | J (600 A) or L (650 A) | 18,000 | 600 | — | 650 | 600 |
| ATS48C59Y | L | 30,000 | — | 700 | 700 | 700 |
| ATS48C66Y | L | 30,000 | 750 | 900 | 800 | 800 |
| ATS48C79Y | L | 42,000 | 1000 | 1000 | 1000 | 1100 |
| ATS48M10Y | L | 85,000 | 1350 | 1200 | 1400 | 1400 |
| ATS48M12Y | L | 85,000 | 1500 | 1600 | 1600 | 1600 |

DIMENSIONS AND WEIGHTS

Figure 4: ATS48D17Y–C66Y




Table 9: ATS48D17Y–C66Y Dimensions

| ATS48.... | a in (mm) | b in (mm) | c in (mm) | e in (mm) | G in (mm) | H in (mm) | Ø in (mm) | Weight lb (kg) |
|------------------------------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|-------------------|
| D17Y, D22Y, D32Y, D38Y, D47Y | 6.30 (160) | 10.83 (275) | 7.48 (190) | 0.26 (6.6) | 3.94 (100) | 10.24 (260) | 0.28 (7) | 10.8 (4.9) |
| D62Y, D75Y, D88Y, C11Y | 7.48 (190) | 11.42 (290) | 9.25 (235) | 0.39 (10) | 5.91 (150) | 10.63 (270) | 0.28 (7) | 18.3 (8.3) |
| C14Y, C17Y | 7.87 (200) | 13.39 (340) | 10.43 (265) | 0.39 (10) | 6.30 (160) | 12.60 (320) | 0.28 (7) | 27.3 (12.4) |
| C21Y, C25Y, C32Y | 12.60 (320) | 14.96 (380) | 10.43 (265) | 0.59 (15) | 9.84 (250) | 13.78 (350) | 0.35 (9) | 40.1(18.2) |
| C41Y, C48Y, C59Y, C66Y | 15.75 (400) | 26.38 (670) | 11.81 (300) | 0.79 (20) | 11.81 (300) | 24.02 (610) | 0.35 (9) | 113.3 (51.4) |

Figure 5: ATS48C79Y–M12Y





Table 10: ATS48C79Y–M12Y Dimensions

| ATS48**** | a in (mm) | b in (mm) | c in (mm) | e in (mm) | G in (mm) | H in (mm) | Ø in (mm) | Weight lb (kg) |
|---------------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|-------------------|
| C79Y, M10Y, M12Y | 30.31 (770) | 35.04 (890) | 12.40 (315) | 0.79 (20) | 13.78 (350) | 33.46 (850) | 0.35 (9) | 253.6 (115) |

SERIAL AND MODEL NUMBERS

The serial and model numbers of the ATS48 controller are on the bar code sticker located on the front right hand side of the device.

Figure 6: Serial Number and Model Numbers



SECTION 4— MOUNTING

MOUNTING PRECAUTIONS

Follow these precautions when mounting the ATS48 controller:

- Controllers are open devices and must be installed in suitable enclosures or controlled access areas. The environment around the controller must meet Pollution Degree 3 requirements as defined in NEMA ICS1-1 or IEC 60664-1.

⚠ DANGER

HAZARDOUS VOLTAGE

ATS48 controllers are open devices and must be mounted in a suitable enclosure.

Electrical shock will result in death or serious injury.

- When the installation surface is not even, put a spacer behind the controller mounting pads to eliminate gaps. Fastening the controller exterior to an uneven surface may damage the controller.
- When installing the controller in an enclosure, cover the device to prevent metallic debris from falling into the controller.
- The ATS48 controller generates heat and must be properly ventilated. Refer to “Thermal Considerations for Sizing Enclosures” on page 19 to determine power dissipated.
- When several controllers are installed in a control panel, arrange them in a row. Do not stack controllers. Heat generated from the bottom controller can adversely affect the ambient temperature around the top controller.

⚠ CAUTION

CONTROLLER OVERHEATING

- Mount the ATS48 controller within $\pm 10^\circ$ of vertical.
- Do not locate the controller near heat radiating elements.
- Electrical current through the controller will result in heat losses that must be dissipated into the ambient air immediately surrounding the controller. To prevent thermal fault or equipment damage, provide sufficient enclosure cooling and/or ventilation to limit the ambient temperature around the controller


Failure to follow this instruction can result in injury or equipment damage.

Mounting in a General Purpose Metal Enclosure

Follow the instructions in this section in order to meet NEMA Type 1 (IP23) degree of protection. To ensure adequate air flow inside the controller, follow these guidelines:

- Leave sufficient space around the controller (see Figure 7).
- Ensure sufficient ventilation. If necessary, install a cooling fan with filters.

Figure 7: Ventilation and Clearances



Soft Starter Ventilation


On soft starters fitted with a cooling fan, the fan switches on automatically as soon as the heatsink temperature reaches 50 °C. It is switched off when the temperature drops to 40 °C.

Table 11: Fan Flow Rates

| Part Number | CFM | m³/hour |
|--------------------|------|---------|
| ATS48D32Y and D38Y | 24 | 14 |
| ATS48D47Y | 48 | 28 |
| ATS48D62Y to C11Y | 146 | 86 |
| ATS48C14Y and C17Y | 235 | 138 |
| ATS48C21Y to C32Y | 476 | 280 |
| ATS48C41Y to C66Y | 1020 | 600 |
| ATS48C79Y to M12Y | 2040 | 1200 |

Mounting in a Dust and Damp-Proof Metal Enclosure

Figure 8: Ventilation for Dust and Damp-Proof Enclosure



Follow the instructions in this section in order to meet NEMA Type 12 (IP54) degree of protection.

Maintain clearances as shown in Figure 7.

Do not use insulated or non-metallic enclosures as they have poor thermal conduction. Provide a stirring fan to circulate air inside the enclosure and prevent hot spots in the controller, as shown in Figure 8. This allows operation of the soft starter in an enclosure with a maximum internal temperature of 140 °F (60 °C). Ensure that the ambient temperature around the soft starters does not exceed this limit.

To reduce temperature rise within the enclosure, use a shorting/bypass contactor (duty cycle not to exceed 2 starts per hour) or a heat exchanger. Derate the soft starter current I_N by 2% per °C for temperatures above 40 °C if a shorting/bypass contactor is not used.

Thermal Considerations for Sizing Enclosures

When mounting the ATS48 soft starter in an enclosure, use the enclosure manufacturers' recommendations for proper sizing based on thermal considerations. For this, it is necessary to sum the power dissipated by each device in the enclosure. Table 12 lists the steady state power dissipation for the ATS48 soft starter, operating at rated current, with and without a shorting/bypass contactor.

Table 12: Watts Loss Information

| Catalog Number | Power Dissipation in Watts | | Catalog Number | Power Dissipation in Watts | |
|----------------|--------------------------------|-----------------------------------|----------------|--------------------------------|-----------------------------------|
| | with Shorting/Bypass Contactor | without Shorting/Bypass Contactor | | with Shorting/Bypass Contactor | without Shorting/Bypass Contactor |
| ATS48D17Y | 15 W | 59 W | ATS48C21Y | 50 W | 580 W |
| ATS48D22Y | 15 W | 74 W | ATS48C25Y | 50 W | 695 W |
| ATS48D32Y | 25 W | 104 W | ATS48C32Y | 50 W | 902 W |
| ATS48D38Y | 25 W | 116 W | ATS48C41Y | 80 W | 1339 W |
| ATS48D47Y | 25 W | 142 W | ATS48C48Y | 80 W | 1386 W |
| ATS48D62Y | 25 W | 201 W | ATS48C59Y | 80 W | 1731 W |
| ATS48D75Y | 25 W | 245 W | ATS48C66Y | 80 W | 1958 W |
| ATS48D88Y | 25 W | 290 W | ATS48C79Y | 80 W | 2537 W |
| ATS48C11Y | 25 W | 322 W | ATS48M10Y | 80 W | 2865 W |
| ATS48C14Y | 25 W | 391 W | ATS48M12Y | 80 W | 3497 W |
| ATS48C17Y | 25 W | 479 W | | | |


The total dissipated Watts loss is provided strictly for sizing the environmental HVAC cooling requirements based upon nominal current operating conditions. **The control power circuit consumption is 25 W.**

REMOTE KEYPAD DISPLAY (IF USED)




The VW3G48101 remote keypad display can be mounted on the door of a wall-mounted or floor-standing enclosure. The remote keypad display kit includes a seal for IP65 protection and a 9.82 ft (3 m) cable with connectors.

Communication is via the RJ-45/MODBUS connection on the starter (see Figure 10). The remote keypad display has the same signaling display and configuration buttons as the controller's integral keypad display. A switch to lock access to the parameters is located at the rear of the keypad display.

Figure 9: Remote Keypad Display, Front and Rear Views




The access switch on the remote keypad display is used as follows:

- Locked Position : Only monitoring parameters can be accessed. When the starter is running, it is not possible to select a different parameter to be displayed.
- Partial Locked Position : Limited access to the SEt, PrO, and SUP menu parameters.
- Unlocked Position : All parameters are accessible.

Any display restrictions to the starter by the access switch will still be in force once the controller has been disconnected and even if power to the controller is cycled.

Figure 10: Remote Keypad Display Cable Assembly and Connectors



SECTION 5— WIRING

Good wiring practice requires the separation of control circuit wiring from all power (line and load) wiring. Power wiring to the motor must have the maximum possible separation from all other power wiring. **Do not run them in the same conduit.** This separation reduces the possibility of coupling electrical noise between circuits.

INSTALLATION PRECAUTIONS

Follow these precautions when installing the ATS48 controller:

DANGER

HAZARDOUS VOLTAGE

- Read and understand this manual in its entirety before installing or operating ATS48 controllers. Installation, adjustment, repair, and maintenance of these controllers must be performed by qualified personnel.
- The user is responsible for conforming to all applicable code requirements with respect to grounding all equipment. See Figures 11–15 on pages 25–29 for grounding points.
- Many parts in this controller, including printed wiring boards, operate at line voltage. **DO NOT TOUCH.** Use only electrically-insulated tools while making adjustments.
- **DO NOT** touch unshielded components or terminal strip screw connections with voltage present.
- Before installing or servicing the controller:
 - Disconnect all power.
 - Place a "DO NOT TURN ON" label on the controller disconnect.
 - Lock the disconnect in the open position.
- Install all covers before applying power or starting and stopping the controller.

Failure to follow this instruction will result in death, serious injury, or equipment damage.

- Voltage and frequency specifications for the input line must match the controller configuration.
- A disconnect switch must be installed between the input line and the controller.

DANGER

HAZARDOUS VOLTAGE

- The solid state switches of the ATS48 controller's power circuit do not provide complete isolation from the AC line. Due to leakage currents through the solid-state switches, hazardous voltages can be present on the controller load-side power circuit whenever power is applied to the line side of the controller.
- Disconnect all power before servicing the controller or motor.

Electrical shock will result in death or serious injury.

- When using an isolation contactor, the contactor must close before or at the same time as the application of the controller run command. If line power is not detected at the L1, L2, and L3 terminals of the controller within 500 ms of this run command, a Phase Failure fault will occur.
- External overcurrent protection devices (OCPD), either fuses or a circuit breaker, must be installed on the line-side connections of the ATS48 controller. The maximum recommended OCPD rating, along with the associated controller short circuit withstand rating, is listed in Table 8 on page 14.

WARNING

OVERCURRENT DEVICES MUST BE PROPERLY COORDINATED

- An OCPD must be installed on the line-side of the ATS48 controller to achieve published short-circuit withstand ratings.
- Do not exceed the maximum OCPD ratings shown in Table 8 on page 14.
- Do not connect the controller to a power feeder whose short circuit capacity exceeds the controller short circuit withstand rating shown in Table 8 on page 14.

Failure to follow this instruction can result in death or serious injury.

- Power factor correction capacitors should not be connected to a motor controlled by an ATS48 controller. If power factor correction is required, the capacitors must be located on the line-side of the controller. A separate contactor should be used to switch the capacitors off when the motor is off, or during acceleration and deceleration.

CAUTION

EQUIPMENT DAMAGE HAZARD

Do not connect power factor correction capacitors to the load-side power circuit of the ATS48 controller.

Failure to follow this instruction can result in injury or equipment damage.

- The ATS48 controller uses solid-state power switches to control motor power. When checking the condition of conductor or motor insulation, do not connect the high potential dielectric test equipment or insulation resistance tester to the controller since the test voltages used may

damage the controller. Always disconnect the controller from the conductors or motor before performing such tests.

⚠ CAUTION

EQUIPMENT DAMAGE HAZARD

- Do not perform high potential dielectric tests on circuits while the circuits are connected to the ATS48 controller.
- Any circuit requiring high potential dielectric tests must be disconnected from the controller prior to performing the test.

Failure to follow this instruction can result in injury or equipment damage.

- The ATS48 controller contains electronic protection to detect and signal failure of the solid-state switches.
- Since the solid-state switches may be incapable of completely blocking the motor power should a fault occur, auxiliary isolation on the line side of the controller is required. Use either a circuit breaker equipped with a shunt trip coil or an electromagnetic contactor. Connect the isolation device to the fault relay of the controller so that it opens the controller power circuit in the event of a controller fault. The isolation device must be capable of interrupting motor locked rotor current.

Refer to Appendix A beginning on page 73 for typical circuit diagrams that display the logic controlling the isolation device via the fault relay.

⚠ CAUTION

MOTOR OVERHEATING

Failure of the solid-state switches on the ATS48 controller can cause single-phase operation of the motor.

- Use an isolation device consisting of either a circuit breaker equipped with a shunt trip coil or an electromagnetic contactor to open the line-side of the controller.
- The isolation device must be capable of interrupting the motor locked rotor current.
- Connect the fault relay of the controller to open the isolation device in the event of a controller fault.

Failure to follow this instruction can result in injury or equipment damage.

⚠ WARNING

BRANCH CIRCUIT CONDUCTOR HAZARD

If system grounding is not adequate to handle ground fault levels which can exceed 1300% of motor full load amps (FLA), then this device may not protect the branch circuit conductors. In this case, external ground fault protection must be properly coordinated. Recommended solutions include:

- Time delay fuses coordinated to 125% of motor FLA. The fuses listed in Appendix B beginning on page 79 are sized to ensure proper coordination and may be used for applications that do not require start times longer than 50 seconds at 300% current limit or 20 seconds at 500% current limit.
- External overload relay. For multi-motor applications, applications in which motor does not match the controller size, or applications that use a full voltage bypass scheme, an external overload relay can be coordinated to protect conductors from a high-impedance ground fault.

Failure to follow this instruction can result in death or serious injury.

GENERAL WIRING PRACTICES

When wiring ATS48 controllers, follow the wiring practices required by national and local electrical codes. In addition, follow these guidelines:

- Use metallic conduit for all controller wiring. Do not run control and power wiring in the same conduit.
- Separate metallic conduits carrying power wiring or low-level control wiring by at least 3 in (80 mm).
- Separate non-metallic conduits or cable trays used to carry power wiring from metallic conduit carrying low-level control wiring by at least 12 in (305 mm).
- Always cross power and control wiring at right angles.

ADAPTATION TO LINE INPUT

The control circuit is completely independent of the power circuit. To apply control voltage, follow the instructions on the label located on the controller terminal strip. Remove the terminal cover label and connect single phase voltage of 110 to 230 Vac supply to terminals CL1 and CL2.

The power circuit adapts automatically to the input line voltage and frequency over a range of 208 to 690 V (+10% to -15%) for standard controllers.

POWER CONNECTIONS

Table 13: Wire Size and Tightening Torque

| Terminals | | ATS48D17Y–D47Y | ATS48D62Y–C11Y | ATS48C14Y–C17Y | ATS48C21Y–C32Y | ATS48C41Y–C66Y | ATS48C79Y–M12Y |
|--|--|-----------------------------|-------------------------------|--------------------------------|--------------------------------|----------------------------------|----------------------------------|
| Power Input, Power Output, Bypass/Shorting Contactor | | | | | | | |
| L1 / L2 / L3 T1 / T2 / T3 A2 / B2 / C2 | Max. Wire Size ¹ AWG (mm) ² | 8 AWG (16 mm ²) | 2/0 AWG (50 mm ²) | 2/0 AWG (95 mm ²) | Bus Bar (240 mm ²) | Bus Bar (2x240 mm ²) | Bus Bar (4x240 mm ²) |
| | Tightening Torque lb-in (N•m) | 26 lb-in (3 N•m) | 88 lb-in (10 N•m) | 300 lb-in (34 N•m) | 300 lb-in (34 N•m) | 500 lb-in (57 N•m) | 500 lb-in (57 N•m) |
| Ground Connections | | | | | | | |
| GND | Max. Wire Size AWG (mm) ² | 8 AWG (10 mm ²) | 4 AWG (16 mm ²) | Bus Bar (120 mm ²) | Bus Bar (120 mm ²) | Bus Bar (240 mm ²) | Bus Bar (2x240 mm ²) |
| | Tightening Torque ² lb-in (N•m) | 15 lb-in (1.7 N•m) | 26 lb-in (3 N•m) | 238 lb-in (27 N•m) | 238 lb-in 27 N•m | 238 lb-in 27 N•m | 238 lb-in (27 N•m) |

¹ Power terminals are suitable for use with 75 °C rated conductors; copper only.

² Requires user supplied lug.

Figure 11: Power Connections ATS48D17Y to C11Y




Figure 12: Power Connections ATS48C14Y to C17Y




Figure 13: Power Connections ATS48C21Y to C32Y




Figure 14: Power Connections ATS48C41Y to C66Y





Figure 15: Power Connections ATS48C79Y to M12Y



CONTROL CONNECTIONS

Although all control inputs and outputs of the controller are isolated from the input lines, follow these control wiring precautions:

- Keep control wiring conductor runs short and direct.
- Ensure that the control contacts used with the controller inputs are rated for operation at open circuit voltages of 24 Vdc and closed circuit currents of 10 mAdc.
- The analog output requires twisted cable with a pitch of 1–2 inches. Use a cable shield. The shield must be terminated to ground at one end.
- Ensure that the coils of all relays and solenoids connected to the output contacts of the controller are equipped with appropriate transient suppressors.
- For proper control wiring, route conductors to avoid contact with other voltage potentials in the controller. Wire insulation must have the appropriate voltage rating for the voltage present.
- The control terminals are fitted with one way plug-in connectors with:
 - Maximum wire size: 12 AWG (2.5 mm²)
 - Maximum tightening torque: 3.5 lb-in. (4 N•m)
- On ATS48C17Y to ATS48M12Y the protective cover must be removed in order to access the control terminals.

Layout of Control Terminals

Figure 16: Control Terminals




Table 14: Control Terminal Blocks

| Terminal | Function | Characteristics |
|-------------|--|---|
| CL1, CL2 | Control power supply | 90 to 270 Vac, 50/60 Hz <ul style="list-style-type: none"> Switch mode power supply with 25 VA consumption |
| R1A, R1C | R1 Relay: N.O. programmable contact | Minimum switching capacity: 10 mA for 6 Vdc |
| R2A, R2C | R2 Relay: N.O. starting relay contact | Maximum switching capacity on inductive load |
| R3A, R3C | R3 Relay: N.O. programmable contact | <ul style="list-style-type: none"> 1.8 A for 230 Vac and 30 Vdc Maximum voltage 400 Vac. |
| STOP RUN | Stop controller Run controller | 4 logic inputs with 4.3 kΩ impedance Voltage (V): 30 V max., Current (I): 8 mA max. <ul style="list-style-type: none"> State 1: V > 11V, I > 5 mA State 0: V < 5V, I < 2 mA |
| LI3, LI4 | Programmable inputs | |
| 24V | Logic input power supply | +24 V ±25% isolated and protected against short circuits and overloads, maximum current of 200 mA. |
| LO+ | Logic output power supply | Connect to 24 V or an external supply source |
| LO1 LO2 | Programmable logic outputs | 2 open collector outputs, compatible with Level 1 [PLC], IEC 60065A-68 standard. <ul style="list-style-type: none"> Power supply +24 V (12 V min., 30 V max.) Maximum current 200 mA per output with an external source |
| AO1 | Programmable analog output | Output can be configured as 0–20 mA or 4–20 mA <ul style="list-style-type: none"> Accuracy ±5% of the maximum value, maximum impedance 500 Ω |
| COM | I/O common | 0 V |
| PTC1, PTC2 | Input for PTC probes | Total resistance of probe circuit: 750 Ω at 25 °C <ul style="list-style-type: none"> For example, three 250 Ω probes in series |
| RJ-45 | Connector for <ul style="list-style-type: none"> Remote keypad display PowerSuite Communication bus | RS-485 MODBUS |

SECTION 6— APPLICATION AND PROTECTION

SOFT STARTER APPLICATIONS

The ATS48 soft starter must be selected for the nominal power of the motor and for the type of application, standard or severe duty. Standard and severe define the limiting values of the current and the duty cycle characteristics. The ATS48 controller is factory preset to start the motor in standard duty applications.

Standard Duty Applications

In standard duty applications, the ATS48 soft starter is designed to provide:

- Starting at 400% of I_N for 23 seconds, or 300% of I_N for 46 seconds, from a cold state
- Starting at 400% of I_N for 12 seconds, or 300% of I_N for 23 seconds, with a load factor of 50% and 10 starts per hour or an equivalent thermal cycling
- The motor thermal protection conforms to Class 10 overload protection.

Severe Duty Applications

In severe duty applications, the ATS48 soft starter is designed to provide:

- Starting at 400% of I_N for 48 seconds, or 300% of I_N for 90 seconds, from a cold state
- Starting at 400% of I_N for 25 seconds with a load factor of 50% and 5 starts per hour or an equivalent thermal cycling
- The motor thermal protection conforms to Class 20 thermal overload protection.

Reduced Torque

The key to applying a soft start successfully is matching the load to the motor capability while starting with reduced voltage applied. The asynchronous motor associated with the ATS48 soft starter must be able to accelerate the driven load when supplied with reduced voltage and current. When reduced voltage is applied to a motor during acceleration, the current the motor draws is reduced by the ratio of the voltage applied. The torque produced by the motor varies with the square of the voltage at a fixed frequency. Figure 17 on page 32 shows the speed/torque characteristics as a function of the supply voltage.

Figure 17: Torque as a Function of Applied Voltage





Figure 18: Torque as a Function of Starting Current



A soft start progressively increases voltage to the motor. By ramping the voltage, the ATS48 soft starter limits the amount of current the motor can draw during starting to a user-defined setting. Figure 18 shows the speed/torque characteristics of a motor as a function of starting current. The ATS48 soft starter provides optimal acceleration by ramping the acceleration torque within the envelope of curve T_{d1}.

INTELE™ Braking

When using INTELE braking, the stop time (t3) is less than the freewheel stopping time (t1). INTELE braking is a two-part braking process which does not require external components. It produces less motor heat than traditional DC injection braking.

INTELE braking is best used when all of the criteria below are met:

- 4-pole or 6-pole motors only
- motor slip is less than or equal to 3%

$$t(\text{sec}) = \frac{WK^2 \times \Delta \text{rpm}}{308 \times (T_{\text{FLT}} \times 0.40)}$$

where:

$t(\text{sec})$ = Calculated value must be equal to or less than 40

WK^2 = Connected motor load inertia (lb-ft²)

Δrpm = Change in rpm or synchronous speed

T_{FLT} = Full Load Torque (lb-ft)

MOTOR PROTECTION AND DIAGNOSTICS

Thermal Overload Protection

The ATS48 controller provides state-of-the-art motor protection. On all controllers, the motor protection features are available even if a shorting/bypass contactor is used to bypass the SCRs after the motor is up to speed. To assist with troubleshooting, the 3-digit LCD displays fault status codes. The controller memory registers and maintains the previous 5 faults, even following power loss.


The ATS48 controller is a UL Listed motor controller with integrated motor and controller thermal protection. The motor and controller temperature are continuously calculated based on the controller nominal current and the current that is actually drawn. An electronic circuit, which stores the thermal state of the motor even if the supply power is disconnected, simulates the cooling curve.

Overload of any kind over any duration can cause the motor temperature to rise. As Figure 19 shows, the ATS48 controller creates a digital model of the motor temperature based on two thermal images. The first (T1) represents the level of temperature rise corresponding to iron (motor frame). The second (T2) represents the temperature rise of copper (stator, windings). For each thermal image, two levels of alarm are detected.

An overload pre-alarm is signaled by logic output LO1 when the motor has exceeded its nominal temperature rise threshold. A pre-alarm is signaled when the thermal state exceeds 105% for T1 and/or 130% for T2.

A thermal fault signal stops the motor when the temperature rise exceeds the critical threshold. A thermal fault is signaled by relay R1 when the motor thermal state exceeds 110% for T1 and 140% for T2.

Figure 19: Thermal Trip Curves



The ATS48 controller is preset to provide Class 10 thermal overload protection for standard duty applications. The ATS48 controller can be adjusted to provide Class 2, 10A, 10, 15, 20, 25, or 30 thermal overload protection, as necessary. Class 2 protection is available for applications such as submersible pumps, where very tight control of motor temperature is required. Class 30 protection is available for applications such as high inertia

loading, where a longer than normal starting time is required to accelerate the load to full speed. In addition, the internal overload protection may be disabled if motor protection is provided externally.

The various thermal overload protection classes are defined to meet the standards of IEC 60947-4-2 for starting from both cold and hot states. A cold state is defined as the stabilized motor thermal state when the motor is off. Figure 20 shows the approximate trip times for starting from a cold state.

Figure 20: Cold Start Curves




Table 15: Cold Start Trip Time

| Standard Application (Class 10 Thermal Overload Protection) | | Severe Application (Class 20 Thermal Overload Protection) | |
|---|------------------|---|------------------|
| 3 I _N | 5 I _N | 3.5 I _N | 5 I _N |
| 46 s | 15 s | 63 s | 29 s |

Hot state is defined as the stabilized motor thermal state when the motor has been running at full load capacity. Figure 21 shows the approximate trip times for starting from a hot state.

Figure 21: Hot Start Curves




Table 16: Hot Start Trip Time

| Standard Application (Class 10 Thermal Overload Protection) | | Severe Application (Class 20 Thermal Overload Protection) | |
|---|------------------|---|------------------|
| 3 I _N | 5 I _N | 3.5 I _N | 5 I _N |
| 23 s | 7.5 s | 32 s | 15 s |

Motor Thermal Protection with PTC Probes

PTC probes integrated in the motor to measure the motor temperature can be connected to the control card terminals. This analog value is managed by the controller.

The PTC probe thermal overshoot value can be processed and used in two ways:

- To stop the machine in the event of a fault if the signal is active.
- To activate an alarm if the signal is active. This alarm can be displayed in a controller status word (serial link) or on a configurable logic output.

NOTE: PTC probe protection does not deactivate the motor thermal protection provided by the calculation. Both types of protection can operate in parallel.

PREVENTIVE MAINTENANCE

The following steps should be done at regular intervals:

1. Check the condition and tightness of the connections.
2. Make sure ventilation is effective and the temperature around the controller remains at an acceptable level.
3. Remove any dust and debris from the controller, if necessary.

SECTION 7— PROGRAMMING

PROGRAMMING AND SETUP

Preliminary Recommendations

WARNING

LOSS OF CONTROL

- The designer of any control scheme must consider the potential failure modes of control paths and, for certain critical control functions, provide a means to achieve a safe state during and after a path failure.
- Examples of critical control functions are Emergency Stop and Overtravel Stop.
- Separate or redundant control paths must be provided for critical control functions.

Failure to follow this instruction can result in death, serious injury, or equipment damage.

If starting the soft starter from line power, limit operations to the duty cycle ratings described on page 31. Use inputs LI1 to LI4 to control the soft starter.

When changing the factory configuration, record your parameter settings in the Factory Settings table beginning on page 69.

When first commissioning an ATS48 controller on a 60 Hz system, perform a factory parameter reset (see FCS on page 50).

Programming the ATS48 controller is simplified by internal sequence selections and interlocks. For ease of setup, Square D recommends accessing the menus in the following order.


1. IO—Assignment of the inputs/outputs
2. drC—Advanced settings
3. SEt—Settings

Some steps may not be necessary.

Copy and use the Factory Settings table on pages 69–72 to record your settings.

DISPLAY UNIT AND
PROGRAMMING

Figure 22: Display Functions



NOTE: Pressing ▲ or ▼ does not store the choices. To store the displayed choice, press ENT. The display flashes when a value is stored.

Display Principle


The display principle for numbers differs depending on the maximum scale of the parameter and its value, see Table 17 for examples.

Table 17: How to Read Displayed Numbers

| Range | Example | |
|------------------|---------|-------|
| | Display | Value |
| Max. scale 9990 | | |
| 0.1 to 99.9 | 05.5 | 5.5 |
| | 55.0 | 55 |
| | 55.5 | 55.5 |
| 100 to 999 | 555 | 555 |
| 1000 to 9990 | 5.55 | 5550 |
| Max. scale 99900 | | |
| 1 to 999 | 005 | 5 |
| | 055 | 55 |
| | 550 | 550 |
| 1000 to 9990 | 5.55 | 5550 |
| 10000 to 99900 | 55.5 | 55500 |

Menus are accessible in the order shown in Figure 23.


Figure 23: Accessing Menus



(1) Menu St2. is only available if the second set of motor parameters function is configured. See the I/O menu on page 51.

To store the displayed choice, press ENT. The display flashes when a value is stored. Navigate through the menus, depending upon the button pressed, as shown in Figure 24.

Figure 24: Accessing Parameters




Refer to Table 18 for soft starter status codes.

Table 18: Soft Starter Status Codes

| Status Code | Condition |
|--|---|
| Fault code | Faulty soft starter |
| nLP | Soft starter without run command and: <ul style="list-style-type: none">Power not suppliedPower supplied |
| rdY | |
| tbS | Starting time delay not elapsed |
| HEA | Motor heating in progress |
| Monitoring parameter selected by the user (SUP menu). Factory setting: motor current | Soft starter with run command |
| brL | Soft starter braking |
| Stb | Waiting for a command (RUN or STOP) in cascade mode |

NOTE: Shaded rows indicate typically locked out features.

Figure 25: Settings Menu



To access the parameters, see Figure 24 on page 39.

Table 19: Settings Menu (SEt) Parameters



| Code | Description | Setting Range | Factory Setting |
|-----------------|--|--|------------------------|
| I _N | Nominal motor current | 0.4 to 1.3 I _{CL} | * |
| | Adjust the value to the nominal motor current indicated on the motor nameplate. Ensure that the current is between 0.4 and 1.3 I _{CL} (I _{CL} : soft starter rating). * The factory setting corresponds to the usual value of a 460 V standardized motor in accordance with NEC and with Class 10 thermal overload protection. | | |
| I _{Lt} | Current limit | 150 to 700% of I _N , limited to 500% of I _{CL} | 400% of I _N |
| | The current limit ILt is expressed as a percentage of I _N . It is limited to 500% of I _{CL} (soft starter rating, see Tables 3 and 4 on pages 11 and 12). Current limit = ILt x I _N . Example 1: I _N = 22 A, ILt = 300%, Current limit = 300% x 22 A = 66 A Example 2: ATS48C21Y, with I _{CL} = 210 A I _N = 195 A, ILt = 700%; Current limit = 700% x 195 = 1365, limited to 500% x 210 = 1050 A | | |
| ACC | Acceleration ramp time | 1 to 60 s | 15 s |
| | This is the rise time of the soft starter torque between 0 and the nominal torque T _N (i.e., the gradient of the torque ramp on acceleration).  | | |
| t _{q0} | Initial starting torque | 0 to 100% of T _N | 20% |
| | Initial torque setting during the starting phases, varies from 0 to 100% of the nominal torque.  | | |
| SEY | Type of stop | d-b-F | -F- |
| | Three types of stop are possible: <ul style="list-style-type: none"> -d-: Soft stopping by control of motor torque. The soft starter applies torque to the motor in order to decelerate progressively on the ramp, avoiding a rapid stop. This type of stop reduces the risk of water hammer on a pump. -b-: INTELE braking stop: The soft starter generates braking torque in the motor which will slow the motor down if there is considerable inertia. (See page 32.) -F-: Freewheel stop: The soft starter applies no torque to the motor. | | |

Table 19: Settings Menu (SEt) Parameters (continued)



| Code | Description | Setting Range | Factory Setting |
|------|--|---------------|-----------------|
| dEC | Deceleration ramp time | 1 to 60 s | 15 s |
| | <p>This parameter can only be accessed if StY is set to -d-. Selects the time (1 to 60 s) the soft starter will take to reduce the estimated torque to zero during a type -d- stop. This setting determines the gradient of the torque ramp on deceleration. This feature is useful in pumping applications to prevent hydraulic shock which may occur if the motor decelerates too quickly.</p>  | | |
| EdC | Final deceleration torque | 0 to 100% | 20% |
| | <p>This parameter can only be accessed if StY is set to -d- and if the CLP parameter in the drive menu (drC) is still set to On (the factory setting). Selects the final torque level (0 and 100% of estimated torque) during a type -d- stop. This is the threshold at which the controlled stop ends and the freewheel portion of the stop begins. If the estimated torque at the start of deceleration is below 20, (i.e., 20% of the nominal torque) controlled deceleration is not activated, and the motor changes to freewheel mode.</p>  | | |

Table 19: Settings Menu (SEt) Parameters (continued)



| Code | Description | Setting Range | Factory Setting |
|------|--|---------------|-----------------|
| brC | Internal braking torque level | | 0 to 100% |
| | <p>This parameter can only be accessed if StY is set to -b-. Selects the braking torque level for stop type -b-. Braking is active up to 20% of the nominal speed. The total stop ramp depends on the setting of this parameter and also dependent on the motor loading. See EbA below.</p>  <p>Impulse brake injection time: $T2 = T1 \times EbA$</p> <p><i>NOTE: Time T1 is not determined by brC. T1 is the time required in seconds for the motor to fall from 100% of the nominal speed to 20% (depends on the motor and application characteristics).</i></p> | | |
| EbA | Injection time at the end of braking | 20 to 100% | 20% |
| | <p>This parameter can only be accessed if StY is set to -b-. Selects adjustment of the current injection time at the end of braking for stop type -b-. Can be set at 20 to 100% of the INTELE braking time (T1).</p> <p>Example:</p> <p>INTELE braking = 10 s (T1) The stopping time can vary from 2 to 10 s (T2) EbA = 20 Corresponds to an injection time of 2 s EbA = 100 Corresponds to an injection time of 10 s Factory setting: 20</p> | | |

Figure 26: Protection Menu (PrO)



To access the parameters, see Figure 24 on page 39.

The protection parameters can only be modified when the motor is stopped.

⚠ CAUTION

UNINTENDED OPERATION

- The factory configuration of a monitoring alarm (ALA) indicates the presence of a fault but will not directly protect the installation.
- When using parameter ArS, ensure that an accidental start will not endanger personnel or equipment in any way

Failure to follow this instruction can result in death or serious injury.

Table 20: Protection Menu (PrO) Parameters


| Code | Description | Setting Range | Factory Setting |
|------------|--|----------------------|-----------------|
| | Motor thermal protection | | 10 |
| | See "Thermal Overload Protection" on page 33. | | |
| <i>tHP</i> | <ul style="list-style-type: none"> • 30: Class 30 • 25: Class 25 • 20: Class 20 (severe application) • 15: Class 15 • 10: Class 10 (standard application) • 10A: Class 10A • 2: Sub-class 2 • OFF: no protection | | |
| | Activation of motor underload | | OFF |
| | If the motor torque is less than threshold setting of parameter LUL for longer than the time parameter tUL is set for, one of the following occurs: | | |
| | <ul style="list-style-type: none"> • ALA: an alarm activates (internal bit and configurable logic output) • dEF: the soft starter is locked and the ULF fault displays • OFF: no protection | | |
| <i>ULL</i> |  | | |
| | Motor underload threshold | 20% to 100% of T_N | 60% |
| <i>LUL</i> | This parameter is not available if ULL is set to OFF. LUL can be set from 20% to 100% of the nominal motor torque. | | |
| | Motor underload time | 1 to 60 s | 60 s |
| <i>tUL</i> | This parameter is not available if ULL is set to OFF. Time delay tUL activates as soon as the motor torque falls below threshold LUL. It resets to zero if the torque rises above this LUL threshold by + 10% (hysteresis). | | |
| | Excessive starting time | 10 to 999 s or OFF | OFF |
| <i>tLS</i> | If the starting time exceeds the value of tLS, the soft starter is locked and displays the fault StF. The conditions for the end of starting are: line voltage applied to the motor (min. firing angle) and motor current less than 1.3 I_N . | | |
| | <ul style="list-style-type: none"> • OFF: no protection | | |

Table 20: Protection Menu (PrO) Parameters (continued)



| Code | Description | Setting Range | Factory Setting |
|-------|--|----------------------|-----------------|
| OIL | Activation of current overload | | OFF |
| | <p>This function is only active in steady state. If the motor current exceeds the threshold setting of parameter LOC for longer than the time parameter tOL is set for, one of the following occurs:</p> <ul style="list-style-type: none"> ALA: an alarm activates (internal bit and configurable logic output) dEF: the soft starter is locked and the OLC fault displays OFF: no protection  | | |
| LOC | Current overload threshold | 50% to 300% of I_N | 80% |
| | <p>This parameter is not available if OIL is set to OFF. LOC can be set from 50% to 300% of the nominal motor current.</p> | | |
| tOL | Current overload time | 0.1 to 60 s | 10 s |
| | <p>This parameter is not available if OIL is set to OFF. Time delay tOL activates as soon as the motor current rises above threshold LOC. It resets to zero if the current falls below this LOC threshold again by at least 10% (hysteresis).</p> | | |
| PHr | Protection against line phase inversion | 321, 123, or no | no |
| | <p>If the line phases are not in the order configured, the soft starter locks and displays the fault PIF. This parameter tells the soft starter the line phase order.</p> <ul style="list-style-type: none"> 321: reverse (L3 - L2 - L1) 123: forward (L1 - L2 - L3) no: not monitoring | | |
| tbs | Time before starting | 0 to 999 s | 2 s |
| | <p>This parameter avoids starts in quick succession which may overheat the motor. The time delay starts when the motor changes to freewheel mode. In 2-wire control, the motor is restarted after the time delay if the RUN command input is still activated. In 3-wire control, the motor is restarted after the time delay if a new RUN command is sent (rising edge). The soft starter displays tbs during the time delay.</p> | | |
| PHL | Phase loss threshold | 5 to 10% | 10% |
| | <p>If the motor current falls below this threshold in one phase for 0.5 s or in all three phases for 0.2 s, the soft starter locks and displays the fault PHF. Can be set at between 5 and 10% of the I_{CL} soft starter rating.</p> | | |
| PEL | Activation of motor monitoring by PTC probes | | OFF |
| | <p>The PTC probes on the motor must be connected to the correct analog input. This protection is independent of the calculated thermal protection (tHP parameter). Both types of protection can be used simultaneously.</p> <ul style="list-style-type: none"> ALA: an alarm is activated (internal bit and assignable logic output) dEF: the soft starter is locked and the OtF fault is displayed OFF: no protection | | |

Table 20: Protection Menu (PrO) Parameters *(continued)*

| Code | Description | Setting Range | Factory Setting |
|------|--|---------------|-----------------|
| Pr5 | Automatic restart | On - OFF | OFF |
| | <p>If this function is active and the soft starter locks on a fault, the soft starter automatically restarts if the fault has disappeared and the other operating conditions permit the restart. A series of automatic attempts are made to restart the soft starter at intervals of 60 s. If a restart has not been possible after 6 attempts, the procedure is abandoned and the soft starter remains locked until it is switched off then switched on again or reset manually (see "Fault Management" on page 63).</p> <p>The following faults permit this function: PHF, FrF, CLF, USF.</p> <p>The soft starter fault relay remains activated if this function is active. The run command must be maintained.</p> <p>This function can only be used in 2-wire control.</p> <ul style="list-style-type: none"> • OFF: Function inactive • On: Function active | | |
| PrH | Reset motor thermal state calculated by the soft starter | no - YES | no |
| | <ul style="list-style-type: none"> • no: Function inactive • YES: Function active | | |

Figure 27: Advanced Setting Menu (drC)



The Advanced setting parameters can only be modified when the motor is stopped.

⚠ CAUTION

NO BRAKING AND LIMITED STOPPING

With parameter dLt, only freewheel type stopping is possible:

- Cascading is not possible
- Preheating is not possible

This limitation can result in injury.

Table 21: Advanced Setting Menu (drC) Parameters



| Code | Description | Setting Range | Factory Setting |
|-------|--|-------------------|-----------------|
| t L I | Torque limit | 10 to 200% or OFF | OFF |
| | Use this parameter to limit the torque reference to avoid regenerative behavior in applications with high inertia. It can be used for constant torque starting if tq0 = tLI. <ul style="list-style-type: none"> • OFF: no limit • 10 to 200: limit set as a percentage of the nominal torque | | |
| b S t | Voltage boost level | 50 to 100% or OFF | OFF |
| | If active, this parameter applies a user-set voltage when a run command is present for 100 ms. Once this time has elapsed, the soft starter follows a standard acceleration ramp starting at the initial torque value set (tq0). This function can be used to avoid any starting torque (phenomenon caused by friction on stopping or by mechanical play). <ul style="list-style-type: none"> • OFF: Function inactive • 50 to 100: setting as a percentage of the nominal motor voltage  <p><i>NOTE: When overrating the soft starter (Im motor > Im ATS48 soft starter), if the bSt value is set too high the soft starter can nuisance trip as an overcurrent (OCF) fault.</i></p> | | |
| S S t | Tests on small motor | On - OFF | OFF |
| | Use this parameter to check the soft starter in a testing or maintenance environment, on a motor whose power is very much lower than the soft starter rating (in particular for high power soft starters). It automatically deactivates the torque control parameter, CLP. <ul style="list-style-type: none"> • OFF: function inactive • On: function active SSt returns to the OFF state as soon as the control voltage is disconnected. On the next power up, the PHF fault and the CLP parameter return to their initial configuration. | | |
| C L P | Torque control (type of control) | On-OFF | On |
| | <ul style="list-style-type: none"> • OFF: function inactive • On: function active In the On position, starting and deceleration follow the torque ramp. In the OFF position, starting and deceleration are controlled by voltage variation. Voltage control is recommended for applications which use motors in parallel on one soft starter or a motor whose power is very low in relation to the soft starter rating. When tests on smaller motor, SSt, is active CLP is set to OFF. | | |

Table 21: Advanced Setting Menu (drC) Parameters *(continued)*

| Code | Description | Setting Range | Factory Setting |
|-------|--|---------------|-----------------|
| L S C | Stator loss compensation | 0 to 90% | 50% |
| | Parameter active in acceleration phases (and deceleration phases if StY is set to -d-). In the event of torque oscillations, reduce this parameter gradually until the device is functioning correctly. Oscillations are most common if the soft starter is connected in motors with excessive slip. | | |
| E I G | Deceleration gain (for torque control) | 10 to 50% | 40% |
| | This parameter can only be accessed if CLP is set to On and if the StY parameter (SET Settings menu) is set to -d-. It can be used to eliminate instability during deceleration. Adjust the parameter in accordance with the oscillations. | | |
| C S C | Activation of the cascade function | On-OFF | OFF |
| | <ul style="list-style-type: none"> • OFF: function inactive • On: function active This parameter can only be accessed if relay R1 has previously been assigned to the isolation relay function and if the forced freewheel stop and motor preheating functions are not configured in parameters LI3 or LI4 (IO menu). Assign an input LI = LIC. 255 motors max. | | |
| U L n | Line voltage | 180 to 790 V | 690 V |
| | This parameter is used to calculate the power displayed (LPr and LAP parameters from the SUP menu). The display will only be accurate if this parameter has been set correctly. | | |
| F r C | Line frequency | 50-60- AUt | AUt |
| | <ul style="list-style-type: none"> • 50: 50 Hz (monitoring tolerance of frequency fault FrF = ± 20%). • 60: 60 Hz (monitoring tolerance of frequency fault FrF = ± 20%). • AUt: automatic recognition of the line frequency by the soft starter with frequency fault monitoring tolerance FrF = ± 5%. Selections 50 and 60 are recommended if the power supply is provided by a generating set, given their high tolerance. | | |
| r P r | Reset kWh or the operating time | no-APH- trE | no |
| | <ul style="list-style-type: none"> • no: function inactive • APH: kWh reset to zero • trE: operating time reset to zero The reset command must be confirmed with ENT. APH and trE take effect immediately. The parameter then automatically returns to no. | | |
| F C S | Return to factory settings | no-YES | no |
| | This is used to reset all parameters to their factory settings. <ul style="list-style-type: none"> • no: function inactive • YES: function active, must be pressed and held down (for approx. 2 s) in order to be accepted. The display flashes to confirm. The FCS parameter then automatically resets to no when you press ESC. This parameter cannot be modified via the remote keypad display. | | |

Figure 28: I/O Menu (IO)



To access the parameters, see Figure 24 on page 39.

NOTE: Logic input RUN, logic input STOP, and soft starter shorting/bypass contactor control (R2) cannot be assigned.

The I/O parameters can only be modified when the motor is stopped.

Table 22: I/O Menu (IO) Parameters


| Code | Description | Setting Range | Factory Setting |
|------|--|---------------|-----------------|
| | Logic inputs | | LIA LIL |
| | <p>The selected function is active if the input is powered up.</p> <ul style="list-style-type: none"> no: not assigned. LIA: forced freewheel stop It forces the configuration of a freewheel type stop, but does not control the stop, as soon as a STOP command is received. This selection does not appear if the CSC parameter in the drC menu is set to On. LIE: external fault This enables the soft starter to detect an external user fault (level, pressure, etc.). The motor comes to a freewheel stop and the soft starter displays EtF. LIL: force to local control mode If a serial link is used and this function is set, the soft starter changes from line mode (control via serial link) to local mode (control via keypad displays). LIt: reset motor thermal fault LIC: activation of the cascade function. This function disables motor thermal protection and requires that relay R1 be configured as an isolating relay. It can be used to start and decelerate several identical motors one after the other with a single soft starter. Llr: reset faults which can be reset LIS: activation of second set of motor parameters. This function allows start and deceleration of two different motors, one after the other, or one motor with two different configurations using a single soft starter. LIH: motor preheating This selection does not appear if the CSC parameter in the drC menu is set to On. It is used to prevent the motor from freezing or to prevent temperature deviations which may cause condensation. If the input is active, once the motor has stopped an adjustable current IPr flows through motor after an adjustable time delay tPr. This current heats the motor without causing it to rotate. IPr and tPr must be adjusted (see below). | | |
| | <p>Speed</p> <p>IPr current</p> <p>tbS</p> <p>tPr</p> <p>When the input activates and the motor has stopped and after time delays tPr and tbS (PrO menu) have elapsed, preheating starts. Preheating stops if the input deactivates, if a run command is sent, or if the STOP input activates.</p> <ul style="list-style-type: none"> LII: inhibits all protection <p>NOTE: Use of this function invalidates the soft starter warranty.</p> <p>This is meant to be used to override the soft starter in the event of an emergency (smoke extraction system for example).</p> | | |
| | Preheating level | 0 to 100% | 0% |
| IPr | <p>This parameter appears after LI3 or LI4 have been assigned to function LIH (motor preheating). It is used to set the preheating current. Use a true value current reading ammeter to set the current level.</p> <p>Parameter I_N has no effect on the IPr current.</p> | | |
| | Time delay before preheating | 0 to 999 mn | 5 mn |
| tPr | <p>This parameter appears after LI3 or LI4 have been assigned to function LIH (motor preheating). Preheating starts when the input activates, after time delays tPr and tbS (PrO menu) have elapsed.</p> | | |


NOTE: Shading indicates a typically locked function. To unlock the function see LI3, LI4 Logic inputs. In order for functions LIH and LII to take effect, ENT must be pressed for 10 s (confirmed by flashing display). **These parameters cannot be modified via the remote keypad display.**


Table 22: I/O Menu (IO) Parameters *(continued)*

| Code | Description | Setting Range | Factory Setting |
|----------------|---|---------------|-----------------|
| | Logic outputs | | tAl mI |
| L 0 1 L 0 2 | <ul style="list-style-type: none"> no: not assigned. tAl: motor thermal alarm, see page 33. mI: motor powered. AIL: motor current alarm (threshold OIL and time tOL of PrO menu exceeded). See page 46. AUL: motor underload alarm (threshold LUL and time tUL of PrO menu exceeded). See page 45. APC: motor PTC probe alarm. See PtC on page 46. AS2: second set of motor parameters activated. See LIS on page 52. | | |
| | Relay R1 | | r1F |
| r 1 | <ul style="list-style-type: none"> r1F: fault relay. In this mode, relay R1 activates when the soft starter is powered up (minimum CL1/CL2 control). Relay R1 deactivates when a fault occurs and the motor switches to freewheel mode. See the special case when the automatic restart function is activated and "Fault Management" on page 63. r1I: isolation relay. Relay R1 is designed to control the line contactor on the basis of the RUN and STOP commands and to indicate faults. In this mode, relay R1 activates by a RUN command (or a preheating command). It deactivates at the end of braking or deceleration or when the motor switches to freewheel mode after a STOP command. It also deactivates when a fault occurs. The motor switches to freewheel mode at this point. | | |
| | end of starting relay R2 | | |
| R2 | <p>The end of starting relay R2 is activated when the soft starter is powered up, no faults are present, and the motor has completed the start-up phase. It is deactivated in the event of a stop request or a fault. It has one normally open contact (N/O).</p> <p>It can be used to bypass the ATS48 soft starter at the end of the starting phase.</p> <p>This is not a programmable feature.</p> | | |
| | Relay R3 | | mI |
| r 3 | <ul style="list-style-type: none"> no: not assigned. tAl: motor thermal alarm. See page 33. mI: motor powered. AIL: motor current alarm (threshold OIL and time tOL of PrO menu exceeded). See page 46. AUL: motor underload alarm (threshold LUL and time tUL of PrO menu exceeded). See page 45. APC: motor PTC probe alarm. See PtC on page 46. AS2: second set of motor parameters activated. See LIS on page 52. | | |
| | Analog output | | OCr |
| R 0 | <ul style="list-style-type: none"> no: not assigned OCr: motor current Otr: motor torque OtH: motor thermal state OCO: power factor OPr: active power | | |
| | Configuration of the analog output AO | 020–420 | 020 |
| D 4 | <ul style="list-style-type: none"> 020: 0–20 mA signal 420: 4–20 mA signal | | |
| | Scaling of the analog output | 50 to 500% | 200 |
| R 5 C | This parameter allows you to scale the analog output as a percentage of the nominal value of the parameter configured or, if the parameter is power factor, of 1 for the power factor. | | |

Figure 29: Second Motor Parameters Menu (St2)



 Parameters

 Parameter availability is dependent on the StY setting in the SET menu.

This menu is only visible if a logic input is assigned to the function for activating a second set of motor parameters (LIS) in the I/O menu.

Table 23: Second Motor Parameters Menu (St2) Parameters



| Code | Description | Setting Range | Factory Setting |
|------|--|--|------------------------|
| In2 | Nominal motor current | 0.4 to 1.3 I _{CL} | See note. |
| | Adjust the value of the nominal motor current indicated on the motor nameplate. Ensure that the current is between 0.4 and 1.3 I _{CL} (soft starter rating). See Tables 3 and 4 on pages 11 and 12. <i>NOTE: The factory setting of In2 corresponds with the usual value of a 460 V standardized motor in accordance with NEC and with Class 10 thermal overload protection.</i> | | |
| IL2 | Current limit | 150 to 700% of I _N , limited to 500% of I _{CL} | 400% of I _N |
| | The Current limit IL2 is expressed as a percentage of In2. It is limited to 500% of I _{CL} (see Tables 3 and 4 on pages 11 and 12). Current limit = IL2 x In2 Example 1: In2 = 21 A, IL2 = 300%, Current limit = 300% x 21 A = 63 A Example 2: ATS48C21Y, with I _{CL} = 210 A In2 = 195 A, IL2 = 700%, Current limit = 700% x 195 = 1365, limited to 500% x 210 = 1050 A | | |
| AC2 | Acceleration ramp time | 1 to 60 s | 15 s |
| | This is the rise time of the soft starter torque between 0 and the nominal torque T _N (i.e., the gradient of the torque ramp on acceleration).  | | |
| tq2 | Initial starting torque | 0 to 100% of T _N | 20% |
| | Initial torque setting during the starting phases, varies from 0 to 100% of the nominal torque.  | | |

Table 23: Second Motor Parameters Menu (St2) Parameters
(continued)




| Code | Description | Setting Range | Factory Setting |
|-------|--|-------------------|-----------------|
| d E 2 | <p>Deceleration ramp time</p> <p>This parameter can only be accessed if StY is set to -d-.</p> <p>It sets a time, from 1 to 60 s, to switch from the estimated torque to zero torque (gradient of the torque ramp on deceleration when a -d- stop is applied). This modifies the progression of the deceleration and avoids hydraulic shocks in pump applications by modifying the gradient of the torque reference.</p>  | 1 to 60 s | 15 s |
| E d 2 | <p>Final deceleration torque</p> <p>This parameter can only be accessed if StY is set to -d- and if the CLP parameter in the drive menu (drC) is still set to the factory setting (On).</p> <p>It sets the final torque level from 0 and 100% of the torque estimated at the beginning of deceleration. In pump applications, deceleration control is not necessarily below a load level set by Ed2.</p> <p>If the estimated torque at the start of deceleration is below 20, (i.e., 20% of the nominal torque) controlled deceleration does not activate and the motor changes to freewheel mode.</p>  | 0 to 100% | 20% |
| t L 2 | <p>Maximum torque limit</p> <p>This limits the torque reference to avoid regenerative behavior in applications with high inertia. It can be used for constant torque starting if tq2 = tLI.</p> <ul style="list-style-type: none"> • OFF: no limit • 10 to 200: limit set as a percentage of the nominal torque | 10 to 200% or OFF | OFF |
| t I 2 | <p>Deceleration gain (for torque control)</p> <p>This parameter can only be accessed if CLP is set to On and if the StY parameter (SET Settings menu) is set to -d-.</p> <p>It is used to eliminate instability during deceleration.</p> <p>Adjust the parameter in accordance with the oscillations.</p> | 10 to 50% | 40% |

Figure 30: Communication Menu (COP)



The communication menu parameters can only be modified when the motor is stopped. The internal protocol used is MODBUS.

WARNING

LOSS OF COMMUNICATION CAN CAUSE LOSS OF PROTECTION
When using parameter tLP, ensure that the time set will not interfere with the safe operation of the machine.
Failure to follow this instruction can result in death or serious injury.


Table 24: Communication Menu (COP) Parameters

| Code | Description | Setting Range | Factory Setting |
|-------|--|------------------|-----------------|
| R d d | Soft starter address by the RS-485 serial link | 0 to 31 | 0 |
| t b r | Communication speed in kbps. | 4.8 - 9.6 - 19.2 | 19.2 |
| F D r | Communication format <ul style="list-style-type: none">8o1: 8 data bits, odd parity, 1 stop bit8E1: 8 data bits, even parity, 1 stop bit8n1: 8 data bits, no parity, 1 stop bit8n2: 8 data bits, no parity, 2 stop bits | | 8n1 |

Table 24: Communication Menu (COP) Parameters (continued)

| Code | Description | Setting Range | Factory Setting |
|-------|---|---------------|-----------------|
| t L P | Serial link timeout setting | 0.1 to 60 s | 5 s |
| P C t | Configuration of the serial link for communication with the remote keypad display <ul style="list-style-type: none">On: function active. Temporarily configures the soft starter (tbr and FOR) for communication with the remote keypad display.OFF: function inactive PCt returns to the OFF state as soon as the control voltage is disconnected. On the next power up, the tbr and FOR parameters return to their initial configuration. | | OFF |

Figure 31: Parameter Displayed Menu (SUP)



The parameters in the SUP menu below can be modified with the motor stopped or running.

The factory setting displays the motor current (parameter LCr).

To save the chosen display:

- Press the ENT key once: the choice is temporary, it will be cleared at the next power up.
- Press the ENT key again for 2 seconds: the display flashes, the choice is permanent and cannot be modified.

Table 25: Parameter Displayed Menu (SUP) Parameters

| Code | Parameter | Unit |
|---------------------------|--|---------|
| $\square \square \square$ | Power Factor | 0.01 |
| $t H r$ | Motor thermal state varies from 0 to 125%. 100% corresponds to the nominal thermal state for the current I_N set. | % |
| $L C r$ | Motor current In amperes up to 999 A (examples: 01.5 is 1.5 A, 15.0 is 15 A, 150 is 150 A) In kiloamperes starting at 1000 A (examples: 1.50 is 1500 A, 1.15 is 1150 A) | A or kA |
| $r n t$ | Operating time in hours since the last reset. In hours up to 999 hrs (examples: 001 is 1 hr and 111 is 111 hrs) In kilo-hours from 1000 to 65535 (examples: 1.11 is 1110 hrs and 11.1 is 11100 hrs) Above 65535 hrs (65.5) the display resets to zero. Operating time is counted when the motor is not stopped, i.e. when the thyristors are fired (heating, acceleration, steady state, deceleration, braking) and in continuous bypass operation. The hour counter can be reset in line mode using the control word or via the keypad display with the motor stopped. When the power is removed from the 115 Vac control power supply the hour counter is saved in the EEPROM. | h or kh |
| $L P r$ | Active power varies from 0 to 255%. 100% corresponds to the power at nominal current and at full voltage. | % |
| $L t r$ | Motor torque varies from 0 to 255%. 100% corresponds to the nominal torque. | % |
| $L R P$ | Active power in kW This parameter requires configuration of the exact value of the line voltage ULn in the drC menu. | kW |
| $E t R$ | Display of the current state <ul style="list-style-type: none"> • nLP: soft starter without run command and power not supplied • rdY: soft starter without run command and power supplied • tbS: starting time delay not elapsed • ACC: acceleration in progress • dEC: deceleration in progress • rUn: steady state operation • brL: braking in progress • CLl: soft starter in current limiting mode • nSt: force to freewheel stop by serial link | |
| $L F t$ | Last fault detected (see page 63). If no faults have been saved, the display shows $n \square F$. | |

Table 25: Parameter Displayed Menu (SUP) Parameters *(continued)*

| Code | Parameter | Unit |
|--------------|--|------|
| <i>P H E</i> | <p>Phase rotation direction as viewed from the soft starter</p> <ul style="list-style-type: none"> 123: forward (L1 - L2 - L3) 321: reverse (L3 - L2 - L1) | |
| <i>⏏ d</i> | <p>Keypad display locking code enables the soft starter configuration to be protected using an access code (password).</p> <p>OFF: no access locking codes</p> <ul style="list-style-type: none"> To lock access, enter a code (2 to 999). The number displayed can be increased using the ▲ key. Now press ENT. On appears on the screen to indicate that the parameters have been locked. <p>On: a code is locking access (2 to 999)</p> <ul style="list-style-type: none"> To unlock access, enter the code (increasing the number displayed using the ▲ key) and press ENT. The code remains on the display and access is unlocked until the next power down. Parameter access will be locked again on the next power-up. If an incorrect code is entered, On appears on the display and the parameters remain locked. <p>XXX: parameter access is unlocked (the code remains on the screen).</p> <ul style="list-style-type: none"> To reactivate locking with the same code when the parameters have been unlocked, return to On using the ▼ button and then press ENT. On appears on the screen to indicate that the parameters have been locked. To lock access with a new code when the parameters have been unlocked, enter a new code (change the number displayed using the ▲ or ▼ keys) and press ENT. On appears on the screen to indicate that the parameters have been locked. To clear locking when the parameters have been unlocked, return to OFF using the ▼ button and press ENT. OFF remains on the screen. The parameters are unlocked and will remain unlocked until the next restart. <p>Remember to document your access code (password). Failure to do so could prevent use of the keypad in programming and configuration modes.</p> | |

When access is locked using a code, only the monitoring parameters can be accessed, and with only a temporary choice of parameter displayed.

The choice of application functions can be limited by the incompatibility between certain functions. The functions that are not listed in this table are not incompatible with any other functions.

Figure 32: Compatibility

| Functions | Soft stop | INTELE braking stop | Force freewheel stop | Thermal protection | Loss of a motor phase | Test on small motor | Cascade | Preheating |
|-----------------------|-----------|---------------------|----------------------|--------------------|-----------------------|---------------------|---------|------------|
| Soft stop | | | | | | | | |
| INTELE braking stop | | | | | | | | |
| Force freewheel stop | | | | | | | | |
| Thermal protection | | | | | | | | (2) |
| Loss of a motor phase | | | | | | | | (1) |
| Test on small motor | | | | | | | | |
| Cascade | | | | | | | | |
| Preheating (3) | | | | (2) | (1) | | | |

| | |
|--|------------------------|
| | Compatible functions |
| | Incompatible functions |
| | Not significant |

- (1) Motor phase loss not detected
(2) While the motor is preheating, the thermal protection is disabled. Set the preheating current IPr.
(3) In order for this feature to take effect, press ENT for 10 s (confirmed by flashing display). This parameter cannot be modified via the remote keypad display.

SECTION 8— FAULT MANAGEMENT

As a general rule, if a problem arises when the soft starter is started, it is advisable to restore the factory settings and reprogram your settings one by one. If this does not fix the problem follow the instructions below.

SOFT STARTER DOES NOT START, NO FAULT DISPLAYED

Determine whether or not the code displayed corresponds to the normal state of the soft starter (see Table 17 on page 38).

If no fault is displayed and the soft starter does not start:

- Check that the line supply is present on the control supply CL1/CL2 (see page 30).
- Check for the presence of the RUN/STOP commands (see Appendix A).

NON-RESETTABLE FAULTS

When a non-resettable fault appears the soft starter locks and the motor switches to freewheel mode.

The following are signals that a non-reset fault has occurred:

- Relay R2 opens.
- After the soft starter locks, Relay R1 opens.
- The fault code flashes on the display.
- The last 5 faults are stored and viewable with the PowerSuite software workshop.

Do the following before restarting the soft starter:

- Remove the fault cause(s), see Table 26.
- disconnect and reconnect the control supply

Table 26: Non-Reset Fault Correction

| Fault Displayed | Probable Cause | Corrective Action |
|-----------------|---|--|
| <i>I n F</i> | Internal fault | Disconnect and reconnect the control supply. If the fault persists, contact Schneider Electric product support. |
| <i>D C F</i> | Overcurrent: <ul style="list-style-type: none"> • impeding short-circuit on soft starter output • internal short-circuit • bypass contactor stuck • soft starter is overloaded | Disconnect power to the soft starter, then: <ul style="list-style-type: none"> • Check the connecting cables and the motor isolation. • Check the thyristors. • Check the bypass contactor for a stuck contact. • Check the parameter value bSt in the menu drC (page 49). |
| <i>P I F</i> | Phase inversion The line phase inversion does not conform to the PHr, parameter setting in the Protection menu. | Invert two line phases or set PHr to no. |
| <i>E E F</i> | Internal memory fault | Disconnect and reconnect the control supply. If the fault persists, contact Schneider Electric product support. |

RESETTABLE FAULTS WHEN CAUSES DISAPPEAR

When a resettable fault appears the soft starter locks and the motor switches to freewheel mode.

The following are signals that a resettable fault has occurred:

- Relay R2 opens.
- If relay R1 is configured as an isolating relay, it opens.
- The fault code flashes on the display as long as the fault is present.
- The last 5 faults are stored and viewable with the PowerSuite software workshop.

Do the following before restarting the soft starter:

- Remove the cause of the fault, see Table 27.
- In 2-wire control, maintain the run command on the RUN input.
- In 3-wire control, initiate a new run command (rising edge) on the RUN input.

Table 27: Resettable Fault Correction

| Fault Displayed | Probable Cause | Corrective Action |
|-----------------|---|---|
| CF F | Invalid configuration on power-up | <ul style="list-style-type: none"> • Revert to the factory setting in the drive menu drC. • Reconfigure the soft starter. |
| CF I | Invalid configuration The configuration loaded in the soft starter via the serial link is incompatible. | <ul style="list-style-type: none"> • Check the initial configuration. • Load a compatible configuration. |

AUTO-RESET FAULTS (CUSTOMER CONFIGURABLE)

When an auto-reset fault appears the soft starter locks and the motor switches to freewheel mode. When an auto-reset fault occurs, the soft starter will automatically restart when the fault has cleared.

The following are signals that an auto-reset fault has occurred:

- Relay R2 opens.
- If relay R1 is configured as an isolating relay, it opens. R1 remains closed if it is configured as a fault relay, see page 53.
- The fault code flashes on the display as long as the fault is present.
- The last 5 faults are stored and viewable with the PowerSuite software workshop.

In 2-wire control, perform the following steps for any of the faults listed in Table 28 before restarting the soft starter:

- Remove the cause of the fault.
- Maintain the run command on the RUN input.

NOTE: The soft starter attempts to restart six times at 60 second intervals. If the fault is still present at the 6th attempt it trips, requiring a manual reset (see "Manual-Reset Faults" on page 65). If relay R1 is configured as a fault relay it opens.

Table 28: Auto-Reset Fault Correction (2-wire control)

| Fault Displayed | Probable Cause | Corrective Action |
|-----------------|---|---|
| <i>P H F</i> | Loss of a line phase | Check the line, the connection to the soft starter, and any isolating devices located between the line and the soft starter (such as contactors, fuses, and circuit-breakers). |
| | Loss of a motor phase If the motor current falls below an adjustable threshold PHL for 0.5 s (single phase) or for 0.2 s (3-phase). This fault can be configured in the Protection menu PrO, parameter PHL. | <ul style="list-style-type: none"> Check the motor connection and any isolating devices located between the soft starter and the motor (such as contactors, fuses, and circuit-breakers). Check the motor state. Ensure that parameter PHL is compatible with the motor. |
| <i>F r F</i> | Line frequency is out of tolerance. This fault can be configured in the Advanced settings menu drC, parameter FrC. | <ul style="list-style-type: none"> Check the line. Ensure that parameter FrC is configured properly for the line used (generating set for example). |

For any of the faults listed in Table 29 perform the following steps before restarting the soft starter:

- Remove the cause of the fault.
- In 2-wire control, maintain the run command.

Table 29: Auto-Reset Fault Correction

| Fault Displayed | Probable Cause | Corrective Action |
|-----------------|--|---|
| <i>U S F</i> | Power supply fault on a run command | Check the power supply circuit and voltage. |
| <i>C L F</i> | Control line failure | Loss of CL1/CL2 for more than 200 ms |

If the automatic restart function is not selected, see “Manual-Reset Faults” below for the indication of these faults and the restart instructions.

MANUAL-RESET FAULTS

When a manual reset fault appears, the soft starter locks and the motor switches to freewheel mode.

The following are signals that a manual-reset fault has occurred:

- Relay R2 opens.
- Relay R1 opens.
- The fault code flashes on the display as long as the fault is present.
- The last 5 faults are stored and viewable with the PowerSuite software workshop.

Perform the following steps before restarting the soft starter:

- Remove cause of the fault.
- In 2-wire and 3-wire control, initiate a new run command (rising edge) on the RUN input to reset the fault.

NOTE: A reset will not take place on a run command if LI is assigned to the fault reset (LIr) function.

- In 2-wire and 3-wire control, initiate another new run command (rising edge) on the RUN input to reset the fault.

Table 30: Manual-Reset Fault Correction

| Fault Displayed | Probable Cause | Corrective Action |
|-----------------|--|---|
| <i>S L F</i> | Serial link fault | Check the RS-485 connection. |
| <i>E L F</i> | External fault | <ul style="list-style-type: none"> • Check the custom fault. • Check the mechanism for wear, mechanical play, lubrication, blockages, etc.. • Check the value of the tLs setting in the PrO menu, page 45. • Make sure the soft starter and motor are sized properly for the load and application. |
| <i>O L C</i> | Current overload | <ul style="list-style-type: none"> • Check the mechanism for wear, mechanical play, lubrication, blockages, etc.. • Check the value of parameters LOC and tOL in the PrO menu, page 46. |
| <i>O L F</i> | Motor thermal fault | <ul style="list-style-type: none"> • Check the mechanism for wear, mechanical play, lubrication, blockages, etc.. • Make sure the soft starter and motor are sized properly for the load and application. • Check the value of parameter tHP in the PrO menu (page 45) and that of parameter I_N in the SEt menu, page 41. • Check the electrical isolation of the motor. • Wait for the motor to cool before restarting. |
| <i>O L F</i> | Motor thermal fault detected by the PTC probes | <ul style="list-style-type: none"> • Check the mechanism for wear, mechanical play, lubrication, blockages, etc.. • Make sure the soft starter and motor are sized properly for the load and application. • Check the value of the PtC setting in the PrO menu, page 46. • Wait for the motor to cool before restarting. |
| <i>U L F</i> | Motor underload | <ul style="list-style-type: none"> • Check the hydraulic circuit. • Check the value of parameters LUL and tUL in the PrO menu, page 45. |
| <i>L r F</i> | Locked rotor in steady state This fault is only active in steady state with soft starter bypass contactor. It is detected if the current in a phase is greater than or equal to $5 I_N$ for more than 0.2 s. | Check the mechanism for wear, mechanical play, lubrication, blockages, etc.. |

RESET FAULTS USING A LOGIC INPUT

If a logic input LI is configured to reset motor thermal fault, LI_t, or any other resettable fault, LI_r, for the motor to restart, the following conditions must be met:

- The soft starter must send a pulse on logic input LI.
- In 2-wire control, the run command must be maintained on the RUN input.
- In 3-wire control, a new run command (rising edge) must be initiated on the RUN input.

TROUBLESHOOTING PROCEDURE

When troubleshooting the soft starter, discuss the symptoms of the reported problem with the operating personnel. Ask the operator to describe the problem and to identify when and where it first occurred. Then directly observe the controller and process. Copy the Troubleshooting Sheet on page 68 and use it to record the controller, motor, and peripheral equipment nameplate data.

TECHNICAL SUPPORT

For more information, call, fax, or write:

Square D / Schneider Electric Technical Support
8001 Highway 64 East
Knightdale, NC 27545-9023

Telephone: 919-266-8600 or 1-888-SQUARED (1-888-778-2733)

Fax: 919-217-6508

e-Mail: drivespsg@squared.com

ALTISTART 48 TROUBLESHOOTING SHEET

When requesting after-sales service, it is important to disclose all conditions under which the Square D / Schneider Electric equipment currently operates. This will help in diagnosing the system quickly.

FAX to: **Technical Support @ 919-217-6508**

| |
|---------------|
| DATE: |
| CONTACT NAME: |
| COMPANY: |
| ADDRESS: |
| CITY: |
| STATE: |
| PHONE: |
| FAX: |

SOFT START CONFIGURATION

PART NUMBER: ATS48- SERIAL NUMBER: 6W-

APPLICATION/EQUIPMENT DESIGNATION: _____

MOTOR NAMEPLATE DATA

HORSEPOWER: _____ VOLTAGE (3 PHASE): _____ FREQUENCY: _____ POLES: _____ FLA: _____

SERVICE FACTOR: _____ MOTOR TYPE/DESIGN: ☐ NEMA A ☐ NEMA B ☐ NEMA C ☐ NEMA D

MOTOR CABLE TYPE: _____ APPROXIMATE CABLE LENGTH (IN FEET): _____

POWER SOURCE AND ENVIRONMENT

VOLTAGE BETWEEN L1 AND L2: _____ VOLTAGE BETWEEN L2 AND L3: _____ VOLTAGE BETWEEN L3 AND L1: _____

SERVICE TRANSFORMER RATING: _____ KVA, _____ % Z FREQUENCY: ☐ 60HZ OR ☐ 50 HZ

AMBIENT TEMPERATURES: _____ MIN °C (°F) _____ MAX °C (°F) HUMIDITY: _____

ALTITUDE IF GREATER THAN 3300 FEET ABOVE SEA LEVEL, SPECIFY: _____ FT

SOFT START FAULT CODES

REFER TO TABLES 28 THROUGH 33 FOR POSSIBLE CAUSES & CORRECTIVE ACTION

| NON-RESET FAULTS | AUTO-RESET FAULTS (CUSTOMER CONFIGURABLE) | MANUAL RESET FAULTS | <input type="checkbox"/> OLF – MOTOR THERMAL FAULT |
|--|--|--|--|
| <input type="checkbox"/> INF – INTERNAL FAULT | <input type="checkbox"/> PHF – LOSS OF PHASE OR LOSS OF MOTOR PHASE | <input type="checkbox"/> SLF – SERIAL LINK FAULT | <input type="checkbox"/> OHF – STARTER THERMAL FAULT |
| <input type="checkbox"/> OCF - OVERCURRENT | <input type="checkbox"/> FRF – LINE FREQUENCY (OUT OF TOLERANCE) | <input type="checkbox"/> EtF – EXTERNAL FAULT | <input type="checkbox"/> OtF – MOTOR THERMAL FAULT VIA PTC PROBES |
| <input type="checkbox"/> PIF – PHASE INVERSION | <input type="checkbox"/> USF – POWER SUPPLY | <input type="checkbox"/> StF – EXCESSIVE STARTING TIME | <input type="checkbox"/> ULF – MOTOR UNDERLOAD |
| <input type="checkbox"/> EEF – INTERNAL MEMORY | <input type="checkbox"/> CLF – CONTROL LINE FAILURE (CL1/CL2) | <input type="checkbox"/> OLC – CURRENT OVERLOAD | <input type="checkbox"/> LrF – LOCKED ROTOR (IN STEADY STATE) |
| RESETTABLE FAULTS WHEN CAUSES DISAPPEAR | <input type="checkbox"/> CFF – INVALID CONFIGURATION (POWER UP) | <input type="checkbox"/> CFI – INVALID CONFIGURATION (COMM) | |

DETAILED DESCRIPTION OF PROBLEM (ATTACH WIRING DIAGRAM/SCHEMATICS IF APPLICABLE):

FACTORY SETTINGS

| | Code | Designation | Factory Setting | Customer Setting | Parameter Range and Units |
|------------------------|------------------------------|---|------------------------------|------------------|---|
| SEt Menu Settings | <i>I n</i> | Current setting | Depends upon starter rating. | | 0.5 to 1.3 I _{CL} (A) |
| | <i>I L</i> | Current limit | 400 | | 150 to 500% of I _n |
| | <i>R C C</i> | Acceleration ramp time | 15 | | 1 to 60 s |
| | <i>S D</i> | Initial starting torque | 20 | | 0 to 100% of T _N |
| | <i>S y</i> | Type of stop | -F- (free wheel) | | -d- deceleration -b- braked -F- free wheel |
| | <i>d E C</i> <i>E d C</i> | Deceleration ramp time Final deceleration torque | 15 20 | | 1 to 60 s 0 to 100% of estimated torque |
| | <i>b r C</i> <i>E b R</i> | Internal braking torque level Injection time at the end of braking | 50 20 | | 0 to 100 20 to 100 |
| PRO Menu Protection | <i>t H P</i> | Motor thermal protection | 10 | | OFF, 2, 10A, 10, 20, 25 or 30 |
| | <i>U L L</i> | Activation of motor underload | OFF | | OFF dEF: treated as fault ALA: treated as alarm |
| | <i>L U L</i> <i>t U L</i> | Motor underload threshold Motor underload time | 60 60 | | 20 to 100% of I _N 1 to 60 s |
| | <i>t L S</i> | Excessive starting time | OFF | | OFF - 10 to 999 s |
| | <i>O I L</i> | Activation of current overload | OFF | | ALA: treated as alarm dEF: treated as fault OFF: no protection |
| | <i>L O C</i> <i>t O L</i> | Current overload threshold Current overload time | 80 10 | | 50 to 300% of I _N 0.1 to 600 s |
| | <i>P H r</i> | Protection against line phase inversion | no | | 321: reverse (L3-L2-L1) 123: forward (L1-L2-L3) no: no monitoring |
| | <i>t b S</i> | Time before starting | 2 | | 0 to 999 s |
| | <i>P H L</i> | Phase loss threshold | 10 | | 5 to 10% |
| | <i>P t C</i> | Activation of motor monitoring by PTC probes | OFF | | OFF dEF: treated as fault ALA: treated as alarm |
| | <i>R r S</i> | Automatic restart | OFF | | OFF - On |
| | <i>r t H</i> | Reset motor thermal state | No | | No - YES |

FACTORY SETTINGS *(continued)*

| | Code | Designation | Factory Setting | Customer Setting | Parameter Range and Units |
|-------------------------------|--------------|--|-----------------|------------------|------------------------------------|
| drC Menu Advanced Settings | <i>t L l</i> | Torque limit | OFF | | OFF - 10 to 200% of T _N |
| | <i>b S t</i> | Voltage boost level | OFF | | 50 to 100% of mains voltage |
| | <i>S S t</i> | Tests on a small motor | OFF | | On - OFF |
| | <i>l L P</i> | Torque control (type of control) | On | | On - OFF |
| | <i>L S l</i> | Stator loss compensation | 50 | | 0 to 90% |
| | <i>t l G</i> | Deceleration gain (for torque control) | 40 | | 10 to 50% |
| | <i>l S l</i> | Activation of cascade function | OFF | | On - OFF |
| | <i>U L n</i> | Line voltage | 690 | | 180 to 790 V |
| | <i>F r l</i> | Line frequency | AUt | | 50 - 60 - AUt |
| | <i>r P r</i> | Reset kWh or the operating time | no | | No - APH - trE |
| | <i>F l S</i> | Return to factory settings | no | | No - YES |

FACTORY SETTINGS *(continued)*

| | Code | Designation | Factory Setting | Customer Setting | Parameter Range and Units |
|---|--------------|---------------------------------------|-----------------|------------------|--|
| IO Menu (Management of Inputs / Outputs) | L 13 L 14 | Logic inputs | LIA LIL | | No: not assigned LIA: forced free wheel LIE: external fault LIH: not implemented LIL: force to local control mode LII: inhibition of faults LI: reset motor thermal fault LIC: activate cascade function LIR: fault reset LIM: second configuration |
| | IPr | Preheating level | 0% | | 0 to 100% |
| | tPr | Time delay before preheating | 5 mn | | 0 to 999 minutes |
| | L 01 L 02 | Logic outputs | tAl ml | | No: not assigned tAl: motor thermal alarm ml: motor powered AlL: motor current alarm AUL: motor underload alarm APC: motor PTC sensor alarm AS2: second configuration active |
| | I | Relay R1 | r1F | | R1F: fault R1I: isolation relay |
| | 3 | Relay R3 | ml | | No: not assigned tAl: motor thermal alarm ml: motor powered AlL: motor current alarm AUL: motor underload alarm APC: motor PTC sensor alarm AS2: second configuration active |
| | AO | Analog output | Ocr | | No: not assigned Ocr: motor current Otr: motor torque OtH: motor thermal state OC0: power factor OPr: active power |
| | 04 | Configuration of the analog output AO | 020 | | 020: 0 – 20 mA 420: 4 – 20 mA |
| | ASC | Scaling of the analog output | 200 | | 50 to 500% |

FACTORY SETTINGS *(continued)*

| | Code | Designation | Factory Setting | Customer Setting | Parameter Range and Units |
|--|-------|--|------------------------------|------------------|---|
| St2 Menu 2 nd Motor Parameters | I n 2 | Nominal motor current | Depends upon starter rating. | | 0.5 -1.3 I _{CL} (A) |
| | I L 2 | Current limit | 400 | | 150 – 700% of I _n , limited to 500% of I _{CL} |
| | R L 2 | Acceleration ramp time | 15 | | 1-60 s |
| | t 9 2 | Initial starting torque | 20 | | 0 – 100% of T _N |
| | d E 2 | Deceleration ramp time | 15 | | 1 to 60 s |
| | E d 2 | Threshold for changing to freewheel stop mode at end of deceleration | 20 | | 0 to 100% of estimated torque |
| | t L 2 | Maximum torque limit | OFF | | 10 to 200% |
| | t l 2 | Deceleration gain (for torque control) | 40 | | 10 to 50% |
| COP Menu Communication | R d d | Starter address | 0 | | 0 to 31 |
| | t b r | Communication speed | 19.2 | | 4.8 – 9.6 – 19.2 |
| | F D r | Communication format | 8n1 | | 8o1: 8 bits, odd, 1 stop bit 8E1: 8 bits, even, 1 stop bit 8n1: 8 bits, no parity, 1 stop bit 8n2: 8 bits, no parity, 2 stop bit |
| | t L P | Serial link timeout setting | 5 | | 0.1 to 60 s |
| | P L t | Configuration of serial link for communications with remote keypad display | OFF | | On – OFF |

APPENDIX A—RECOMMENDED WIRING DIAGRAMS

Figures 33–35 illustrate circuit diagrams for typical non-reversing and reversing applications in 2-wire and 3-wire control. The recommended circuit diagrams include SCR fault isolation for optimal protection of the motor, driven machinery, and operating personnel.

Table 31: Description of Logic for Recommended Wiring Diagrams

| Item | Name | Description |
|-------------|------------------------------------|---|
| IC1 IC1A | Isolation Contactor (Fwd) | The isolation contactor logic closes IC1 upon a start command and opens IC1 after the stop is complete. The RCR (or RFR and RRR for reversing) are timed contacts that must have a time delay greater than the deceleration ramp time or the INTELE braking time. When a coast stop is selected, the time delay must be set for a time that will allow complete decay of the motor residual voltage. The isolation contactor opens immediately upon a fault. The pilot relay (IC1A) is required when the IC1 contactor coil exceeds the relay rating. |
| IC2 IC2A | Isolation Contactor (Rev) | Used for reversing applications only, the IC2 must be mechanically interlocked to IC1. A reversing contactor may be used for the combination of IC1 and IC2. In general, the operation of IC2 is identical to IC1. The pilot relay (IC1A) is required when the IC1 contactor coil exceeds the relay rating. |
| SC SCA | Shorting Contactor and Pilot Relay | The shorting contactor is used to reduce the heat dissipated by the controller when the motor is operating at full speed and voltage. The controller provides proper sequencing of this contactor by the “end-start-up” relay. When the start is completed, the shorting contactor will be commanded to close. The controller will continue to monitor the motor thermal state and provide motor overload protection. Upon a stop command, the SC contactor will open, transferring the motor current to the SCRs to allow for controlled deceleration if desired. The pilot relay (SCA) is required when the SC contactor coil exceeds the relay rating. |
| TS | Transient Suppressors | Transient suppression of all relay and contactor coils (except ST) is recommended to minimize the possibility of electrical interference with the controller electronics and to increase relay contact life. |
| RCR | Run Command Relay | Used in all non-reversing logic (optional in shunt trip) for proper sequencing of contactor logic. When energized, RCR initiates the start sequence. When de-energized, stopping is initiated. Operator controls can be either on/off selector switch, HOA selector switch or start/stop push buttons. RCR remains energized during a fault. Once the fault condition has been cleared, RCR must be de-energized by a “stop” command then re-energized to restart the controller. |
| RFR | Run Forward Relay | Used for reversing applications only, this coil duplicates the functionality of RCR for the forward direction and is interlocked with the RFR relay. |
| RRR | Run Reverse Relay | Used for reversing applications only, this coil duplicates the functionality of RCR for the reverse direction and is interlocked with the RRR relay. |
| ST | Shunt Trip Coil | This coil is attached to the shunt trip coil on the disconnect and will energize 2 seconds after a controller fault by the TR timer contact. The time delay is to prevent nuisance tripping of the circuit breaker during controller power-up or during line undervoltage conditions. |
| TR | Trip Relay | Used in shunt trip circuit breaker logic only; coil energized upon a controller fault. |
| FR | Fault Relay | Used with logic diagrams that use an isolation contactor. The fault relay is energized during normal operation and deenergizes if the controller fault contacts open or if the motor thermal switch (if supplied) opens. FR also provides additional contacts for the controller fault output. |

To select control operators (push buttons, pilot lamps, and selector switches), control power transformers, and wire management devices (control and power terminal strips, wire terminations) indicated on the recommended wiring diagram configurations, refer to the latest editions of Square D / Schneider Electric’s full line product catalogs.

Figure 33: Nonreversing with Shunt Trip Fault Isolation




Figure 34: Nonreversing with Isolation Contactor





Figure 35: Reversing with Isolation Contactors



APPENDIX B—RECOMMENDED COMPONENT LISTS

To select control operators (push buttons, pilot lamps, and selector switches), control power transformers, and wire management devices (control and power terminal strips, wire terminations) indicated on the recommended wiring diagram configurations, refer to the latest editions of Square D / Schneider Electric's full line product catalogs.

Table 32: Suggested Components for Standard Duty Applications

| Induction Motor (M) Rated hp ¹ | | | | ATS48 Controller Model | Device Rated Current @ 40 °C ² | Power Burden (VA) | Class CC Control Fuse Size (FU4/FU5 Fuses) | |
|--|-------|-------|-------|------------------------------|--|----------------------|---|--------------------|
| 208 V | 230 V | 460 V | 575 V | | | | @ 208/230 V (A) | @ 460/575 V (A) |
| 3 | 5 | 10 | 15 | ATS48D17Y | 17 | 25 | | 0.25 |
| 5 | 7.5 | 15 | 20 | ATS48D22Y | 22 | 25 | | 0.25 |
| 7.5 | 10 | 20 | 25 | ATS48D32Y | 32 | 25 | | 0.25 |
| 10 | — | 25 | 30 | ATS48D38Y | 38 | 25 | | 0.25 |
| — | 15 | 30 | 40 | ATS48D47Y | 47 | 25 | | 0.25 |
| 15 | 20 | 40 | 50 | ATS48D62Y | 62 | 25 | | 0.25 |
| 20 | 25 | 50 | 60 | ATS48D75Y | 75 | 25 | | 0.25 |
| 25 | 30 | 60 | 75 | ATS48D88Y | 88 | 25 | | 0.25 |
| 30 | 40 | 75 | 100 | ATS48C11Y | 110 | 25 | | 0.25 |
| 40 | 50 | 100 | 125 | ATS48C14Y | 145 | 25 | | 0.25 |
| 50 | 60 | 125 | 150 | ATS48C17Y | 170 | 25 | | 0.25 |
| 60 | 75 | 150 | 200 | ATS48C21Y | 210 | 25 | | 0.25 |
| 75 | 100 | 200 | 250 | ATS48C25Y | 250 | 25 | | 0.25 |
| 100 | 125 | 250 | 300 | ATS48C32Y | 320 | 25 | | 0.25 |
| 125 | 150 | 300 | 350 | ATS48C41Y | 410 | 25 | | 0.25 |
| 150 | — | 350 | 400 | ATS48C48Y | 480 | 25 | | 0.25 |
| — | 200 | 400 | 500 | ATS48C59Y | 590 | 25 | | 0.25 |
| 200 | 250 | 500 | 600 | ATS48C66Y | 660 | 25 | | 0.25 |
| 250 | 300 | 600 | 800 | ATS48C79Y | 790 | 25 | | 0.25 |
| 350 | 350 | 800 | 1000 | ATS48M10Y | 1000 | 25 | | 0.25 |
| 400 | 450 | 1000 | 1200 | ATS48M12Y | 1200 | 25 | | 0.25 |

¹ Motor full load currents through 500 hp @ 460/575 V, 250 hp @ 230 V, and 200 hp @ 208 V are taken from the National Electrical Code (NEC) (NFPA 70-2002, Table 430.150). Above these ratings, motor full load currents are calculated based upon 1.2 A/hp for 460 V and 2.4 A/hp for 230 V. Motors listed are for standard duty applications. For severe duty applications, select the next larger controller size.

² The ambient temperature indicated in the table represents the temperature of the air surrounding the ATS48 controller. Any additional temperature factors associated with the enclosure system or actual installation ambient temperature must be considered when determining the actual rated current (I_{CL}) of the controller. For operating ambient above 40° C without a shorting/bypass contactor and 50° C with a shorting/bypass contactor but not exceeding 60° C, the rated current (I_{CL}) of the controller must be de-rated by 2% per °C.

Table 33: Additional Suggested Components for Standard Duty Applications

| ATS48 Controller Model | IC1 1, 2, 3 | IC2 1, 2, 3 | | SC 1, 2, 3 | Fusible Disconnect ⁴ | | | Thermal Magnetic Circuit Breaker ^{4, 8, 5} |
|------------------------------|------------------------|-------------------------------------|-------------------------|--------------------------------|---------------------------------|-------------------------|------------------------------------|--|
| | Isolation Contactor | Reversing Contactor ⁶ | Mechanical Interlock | Shorting Contactor (AC1) | Power Fuses Class/Rating | Fuse Block ⁷ | Molded Case Switch ⁸ | |
| D17Y | LC1D18 | LC1D18 | ⁹ | LC1D18 | J / 25 | 60308J | FHL36000M | FAL36030 |
| D22Y | LC1D25 | LC1D25 | ⁹ | LC1D25 | J / 30 | 60308J | FHL36000M | FAL36040 |
| D32Y | LC1D32 | LC1D32 | ⁹ | LC1D32 | J / 40 | 60608J | FHL36000M | FAL36050 |
| D38Y | LC1D40 | LC1D40 | ⁹ | LC1D40 | J / 50 | 60608J | FHL36000M | FAL36060 |
| D47Y | LC1D50 | LC1D50 | ⁹ | LC1D50 | J / 60 | 60608J | FHL36000M | FAL36080 |
| D62Y | LC1D65 | LC1D65 | ⁹ | LC1D65 | J / 80 | 61038J | FHL36000M | FAL36090 |
| D75Y | LC1D80 | LC1D80 | ⁹ | LC1D80 | J / 100 | 61038J | FHL36000M | FAL36100 |
| D88Y | LC1D80 | LC1D80 | ⁹ | LC1D80 | J / 120 | 62003J | KHL36000M | KAL36110 |
| C11Y | LC1D115 | LC1D115 | ⁹ | LC1D115 | J / 150 | 62003J | KHL36000M | KAL36150 |
| C14Y | LC1D150 | LC1D150 | ⁹ | LC1D150 | J / 200 | 62003J | KHL36000M | KAL36200 |
| C17Y | LC1F185 | LC1F185 | LA9FF970 | LC1F185 | J / 225 | 64033J | LHL36000M | LAL36225 |
| C21Y | LC1F265 | LC1F265 | LA9FG970 | LC1F265 | J / 300 | 64033J | LHL36000M | LAL36250 |
| C25Y | LC1F265 | LC1F265 | LA9FJ970 | LC1F265 | J / 350 | 64033J | LHL36000M | LAL36350 |
| C32Y | LC1F400 | LC1F400 | LA9FJ970 | LC1F400 | J / 400 | 64033J | LHL36000M | LAL36400 |
| C41Y | LC1F400 | LC1F400 | LA9FJ970 | LC1F400 | J / 500 | 6633J | MHL36000M | MAL36500 |
| C48Y | LC1F500 | LC1F500 | LA9FJ970 | LC1F500 | J / 600 | 6633J | MHL360006M | MAL36600 |
| C59Y | LC1F630 | LC1F630 | LA9FJ970 | LC1F630 | L / 700 | ⁷ | MHL360008M | MAL36800 |
| C66Y | LC1F800 | LC1F800 | LA9FJ970 | LC1F800 | L / 900 | ⁷ | MHL360008M | MAL36900 |
| C79Y | LC1BL33 | LC1BL33 | LA9FL970 | LC1BL33 | L / 1100 | ⁷ | MHL36000M | ¹⁰ |
| M10Y | LC1BL33 | LC1BL33 | LA9FL970 | LC1BL33 | L / 1350 | ⁷ | MHL36000M | ¹⁰ |
| M12Y | LC1BP33 | LC1BP33 | LA9FX970 | LC1BP33 | L / 1600 | ⁷ | NCL3600012M | ¹⁰ |

¹ All coils are selected for 120 V, 60 Hz operation. Refer to the Square D *Digest* for additional coil voltages or auxiliary contact configurations. One block may be added to each contactor.

² Power terminals are not included with LC1-F contactors. Refer to the latest editions of Square D / Schneider Electric's full line product catalogs for additional ordering information.

³ The use of transient suppressors across all contactor coils is recommended. Refer to the latest editions of Square D / Schneider Electric's full line product catalogs for selection of transient suppressors.

⁴ According to the National Electrical Code, branch circuit overcurrent protection must be provided for each controller. Short circuit protective devices recommended in this table are within NEC requirements for Type 1 coordination.

⁵ According to the National Electrical Code, branch circuit overcurrent protection must be provided for each controller. Short circuit protective devices recommended in this table are within NEC requirements for Type 1 coordination.

⁶ Reversing contactors for C11 through M12 controllers must be assembled from components. Parts quantities for a basic contactor assembly, minus the power connection links and terminals, are indicated before each part number. Refer to the latest editions of Square D / Schneider Electric's full line product catalogs for power connector link and terminal kits. Reversing contactor interlock units used for the C79 through M12 controllers are designed for vertical interlocking of the individual contactors. Horizontally interlocked contactors are used for D17 through C59 controllers.

⁷ Fuse holder part number references are for Class J fuses only based on Ferraz Shawmut spring reinforced with box type connectors acceptable for Al/Cu wiring. Class L fuses require bolt-on connections to user-supplied power bus work.

⁸ The molded case switches and circuit breakers selected require the addition of operator mechanisms to allow operation from the exterior of an enclosure. Refer to the latest editions of Square D / Schneider Electric's full line product catalogs for operator mechanism information. When using a shunt trip relay for SCR fault isolation, order a disconnect switch with suffix -1021 for addition of shunt trip coil.

⁹ The D Line contactor is available as a reversing configuration. For these applications, change the IC1 part number prefix from LC1- to LC2- to order the IC1 and IC2 combination complete with mechanical interlocks.

¹⁰ Devices rated above 660 A have not been coordinated with circuit breakers. You must use a Class L fuse for overcurrent protection with ATS48 controller models C79, M10, and M12.

APPENDIX C—OPTIONS AND ACCESSORIES

Tables 34–36 show the accessories available for ATS48 soft start controllers.

Table 34: Documentation

| | |
|-------------|---|
| VVDED302023 | MODBUS Protocol User's Manual (multilingual) |
| DCICD398111 | Communications: Ethernet, FIPIO, DeviceNet, Profibus DP User's Manual (CD-ROM version only) |

Table 35: Remote Keypad Display

| | |
|-----------|--|
| VW3G48101 | <p>Remote mounting kit for keypad display (IP54).</p> <ul style="list-style-type: none"> 7-segment remote keypad display Mounting kit containing cover, screws, and an IP54 seal on the front panel. 9.8 ft (3 m) cable with a 9-way SUB-D connector for keypad display and an RJ-45 connector for connecting to an ATS48 controller. |
|-----------|--|

Table 36: Protective Covers for Power Terminals

| | |
|---------|--|
| LA9F702 | Set of six protective covers for ATS48C14Y to ATS48C17Y. |
| LA9F703 | Set of six protective covers for ATS48C21Y, ATS48C25Y, and ATS48C32Y |

NOTE: The ATS48 controller has 9 unprotected power terminals.

PowerSuite Advanced Dialogue Solutions

PowerSuite solutions are compatible with software version 1.30, build 5.

Table 37: Pocket PC/PDA Kits

| | |
|--|---|
| VW3A8108EN (English) VW3A8108FR (French) VW3A8108SP (Spanish) | <p>Complete PowerSuite Pak includes:</p> <ul style="list-style-type: none"> Palm size HP JORNADA 525 (Palm size PC terminal) with operating system, PC synchronization cable and power supply. PowerSuite CD-ROM setup software [VW3A8014] Connection cable [VW3A8111]. |
| VW3A8102 | <p>Pocket PC/PDA setup kit includes:</p> <ul style="list-style-type: none"> CD-ROM containing setup software. Connection kit for the Palm size PC terminal. <p>Available in English, French, and Spanish operating systems.</p> |
| VW3A8111 | <p>Cable connection kit for the Palm size PC terminal to an ATS48 controller includes:</p> <ul style="list-style-type: none"> (2) connection cables, 9.8 ft (3 m) each with two RJ-45 connectors. (1) RJ-45/9-way SUB-D adaptor. (1) converter marked "RS-232/RS-485 PPC" with one 9-way male SUB-D connector and 1-RJ-45 connector. |

Table 38: PowerSuite Software for Personal Computers

| | |
|----------|--|
| VW3A8104 | PowerSuite Test and Commissioning Software on CD for use with Microsoft® Windows 95, 98, and NT™ and Windows CE v3.0 for Pocket PCs/PDA. |
| VW3A8106 | <p>Cable connection kit for the Personal Computer to an ATS48 controller.</p> <ul style="list-style-type: none"> two connection cables, 9.8 ft (3 m) each with two RJ-45 connectors. one RJ-45/9-way SUB-D adaptor. one converter marked "RS-232/RS-485 PPC" with one 9-way male SUB-D connector and one RJ-45 connector. |

Factory repaired ATS48 controllers are available within 24 hours from a factory exchange pool, or your ATS48 controller can be factory repaired and returned. Contact your local Square D / Schneider Electric Distributor or

Square D / Schneider Electric Customer Service Representative at
919-266-8666 for availability.

INDEX

A

AC2 55
ACC 41
Add 57
AIL 53
AO 53
APC 53
ArS 47
AS2 53
ASC 53
AUL 53

B

brC 43
bSt 49

C

CFF 64
CFI 64
circuit breaker 78
CLF 65
CLP 49
COd 60
contactor
 isolation 78
 reversing 78
 shorting 78
COS 59
CSC 50

D

DCF 63
dE2 56
dEC 42

E

EbA 43
Ed2 56
EdC 42
EEF 63
EtA 59
EtF 66

F

factory settings 69
faults
 auto-reset 65
 manual-reset 66
 non-reset 63
 resettable 64
FCS 50
FOr 57
FrC 50
freewheel stop 41
FrF 65
fuses 14, 77, 78

I

IL2 55
ILt 41
In 41
In2 55
InF 63
INTELE braking stop 32, 41
IPr 52
isolation contactor 23, 78

L

LAP 59
LCr 59
LFt 59
LI3 52
LI4 52
LIA 52
LIC 52
LIE 52
LIH 52
LII 52
LIL 52
Llr 52
LIS 52
Llt 52
LO1 53
LO2 53
LOC 46
LPr 59
LrF 66
LSC 50
Ltr 59
LUL 45

M

menus
 access to 39
 advanced setting (drC) 48
 communication (COP) 57
 I/O (IO) 51
 parameter displayed (SUP) 58
 protection (PrO) 44
 second motor parameters (St2) 54
 settings (SEt) 40

O

O 4 53
OCO 53
OCr 53
OIL 46
OLC 66
OLF 66
OPr 53
OtF 66
OtH 53
Otr 53

P

parameter access 39
PCt 58
PHE 60
PHF 65
PHL 46
PHr 46
PIF 63
PtC 46

R

r1 53
r1F 53
r1I 53
r3 53
reversing contactor 78
rnl 53
rnt 59
rPr 50
rtH 47

S

setting
 factory 69
shorting contactor 78
shunt trip coil 23, 73
SLF 66
soft stopping 41
SSt 49
starter status 40
stop
 freewheel 41
 INTELE braking 32, 41
 soft 41
StY 41

T

tAl 53
tbr 57
tbS 46
tHP 45
tHr 59
tl2 56
tIG 50
tL2 56
tLI 49
tLP 58
tLS 45
tOL 46
tPr 52
tq0 41
tq2 55
tUL 45

U

ULF 66
ULn 50
USF 65

30072-450-61 00



300724506100

Square D Company
8001 Highway 64 East
Knightdale, NC 27545 USA
1-888-SquareD (1-888-778-2733)
www.SquareD.com

Electrical equipment should be serviced only by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this material. This document is not intended as an instruction manual for untrained persons.

30072-450-61 (06/2002)
© 2002 Schneider Electric All Rights Reserved