

ClearSCADA and ScadaPack RTU Time synchronization.

In order to time synchronize scadapack RTU from Clear Scada kindly follow below procedure.

- 1. When using DNP3 serial time sync or DNP3 LAN time sync, use the E Configurator first to set the *Time Update Request Rate* parameter. The RTU will request the time from the Master at this interval to keep its clock synchronized.
- Open the RTU's Configuration file and select the DNP3 property page *DNP3 Comms* (0-3) as shown below. Confirm the default value of 1440 minutes (or once per day) is set. (A value of 0 disables RTU time requests.)



- 2 .Choose the method to use in ClearSCADA by opening the ClearSCADA project from the last exercise and double-clicking the outstation object **sp334E** to edit its properties.
- 3. Select the object's **DNP3** tab and scroll down to the section **Set the Clock**.
- 4. The *Initiate Set Clock* list box selects who initiates setting the clock: the Outstation, ClearSCADA or both.




5. If *ClearSCADA* is selected from the list box above, then ClearSCADA will use the settings defined in the channel object, *DNP3 Direct Channel*, under the *Scan Parameters* tab in the section titled *Set Outstation Clock*. In the screenshot below, ClearSCADA will synchronize the clock of all RTUs on this channel once per day starting at 30 minutes after midnight.



If *Outstation* is selected from the list box, then ClearSCADA will rely solely on the RTU to request the time at the interval set by the *Time Update Request Rate* parameter set in step 1 above.

• If *Outstation and ClearSCADA* is selected from the list box, then both methods are used. Choose this default selection.

6. Now choose the **Set Clock Method** from the next list box:



- •Select *Delay Measurement (FC 23)* for an RTU communicating using serial lines or near-deterministic remote communication networks.
- Select Record Current Time (FC 24) for an RTU communicating on a LAN.