Modicon M340 Firmware

Update procedure

Edition V2.0





www.schneider-electric.com

Purpose

Subject of this
DocumentThis document explains how to update Modicon M340 PLC firmware from
V1.0 or V2.0 to V2.1 for Unity Pro 4.1. In addition, the procedure to update
the firmware of NOE modules is also included.To take benefit of V2.1 features, a V1.0 or V2.0 application has to be changed
into a V2.1 application. This document explains also briefly the operations to
perform in this case.

<u>Summary</u>

1.	Overview
2.	Update a Modicon M340 CPU/NOE module with Unity Loader
2.1.	Prepare the Modicon M340 CPU/NOE module to update6
2.2.	Specific case for some NOE 0100 modules7
2.3.	Update Procedure
2.4.	Upgrade a BMX P34 2010 or 2030 CPU to a BMX P34 20102 or 20302 16
3.	Update a Modicon M340 CPU/NOE module using an SD-Card17
3.1.	Initialize the SD-Card with the firmware17
3.2.	Update a Modicon M340 CPU/NOE module procedure19
4.	Changing an application into a V2.1 application with Unity Pro V4.1
4.1.	Prerequisites
4.2.	Main steps to follow in Unity Pro V4.120
4.3.	Additional capability21

1. Overview

Updating mode	 To benefit from the latest enhancements and evolutions, two operations must be performed: 1. update the M340 CPU and NOE modules by downloading the most recent Firmware file (refer to chapter 2) 2. update the application with Unity Pro V4.1 to configure the latest version of CPU and NOE if needed (refer to chapter 4)
	The update can be performed either using the Unity Loader tool, or using a SD-Card initialized with Unity Loader (see § 3.1. "Initialize the SD-Card with the firmware").
	Note: Unity Loader can also be used to update an expert module (Analog, counting,). This procedure is not described in detail in this document.
Connecting mode between PC and CPU	Modicon M340 CPUs can be connected to a PC via USB cable, or via crossover Ethernet cable (in point to point mode).
Connecting mode between PC and NOE module	NOE modules can be connected to a PC only via crossover Ethernet cable (in point to point mode).



ACAUTION

EQUIPMENT DAMAGE

If using Ethernet connection, only use point to point mode with a crossover cable. Any loss of communication during the update procedure can cause severe damage to the CPU or the module.

Failure to follow these instructions can result in injury or equipment damage.

2. Update a Modicon M340 CPU/NOE module with Unity Loader

Object of this
ChapterThis chapter describes how to update the Modicon M340 CPU or NOE
module using the Unity Loader tool.
The example given shows how to update a BMX P34 2020 processor using
USB protocol. However the procedure is the same for all Modicon M340
CPUs using USB or Ethernet point to point protocol, and for all NOE
modules using Ethernet point to point protocol.

See chapter 2.4 for specific upgrade procedure for CANopen CPU BMX P34 2010 and 2030 with firmware V1.0 or V2.0 to CANopen2 level BMX P34 20102 and 20302.

2.1. Prepare the Modicon M340 CPU/NOE module to update

Prerequisites

In order to proceed with an update, the following elements are required:

- Unity Pro Version 4.0 or upper software must be installed on the PC.
- The firmware is no more provided with Unity Pro but is available on <u>www.schneider-electric.com</u>, both as independent files or included in an electronic CD OS image (.iso file) that can be downloaded.
- The Unity Loader tool (provided with Unity Pro) must be installed on the PC.
- An SD-Card must be plugged in the targeted CPU/NOE and must fit with this target. The free memory available on the SD-Card must be checked (refer to the Unity Loader documentation for the description of the necessary size).

Note: The SD-Card plugged in the CPU or the NOE during the firmware update must be kept in the module after the update because the updated Web pages are stored on it.

2.2. Specific case for some NOE 0100 modules

NOE 0100 with DOM from 0727 to 0803 **Note:** BMX NOE 0100 with firmware V1.0 and DOM (Date Of Manufacturing) from 0727 (27th week of 2007) to 0803 (3rd week of 2008) needs to be patched before upgrading.

• Two files: "patcher.bat" and "patcher.exe" are provided with the last NOE 0100 firmware. The two files have to be copied in the same directory.

The patching procedure is as follows:

- Double click on the "patcher.bat" file.
- In a command prompt window, the following message is displayed:

NOE IP address?, enter the IP address of the NOE (e.g. 138.157.9.53) and press **Enter**

- The following message is displayed: **Connecting to 138.157.9.53...** (for a NOE with IP address 138.157.9.53)
- If connection is possible then the following message is displayed (checking if the NOE needs to be patched): Checking...
 - If the patch is not needed then the following message is displayed: **Patch not needed!**, and the process finishes.
 - If the patch is needed then the following message is displayed: **Patch is done!**, and the process finishes by patching the NOE.

Important notes:

- After the Patch is done and before resetting the NOE, launch the Unity Loader and connect it to the NOE: the NOE can now be upgraded.
- The Patch is only a temporary one (RAM): if you reset the module before upgrading it, the Patch is lost, and the module gets back to its initial state before patching.
- Do not cut the power off during the Patch and before upgrading it.

NOE 0100 V1.0Note: The BMX NOE 0100 with firmware V1.0 equipped with a Web C
cartridge (BMX RWSC016M) must not be upgraded with NOE 0100 V2.0
firmware, but only with NOE 0110 V2.0 or higher firmware.

2.3. Update Procedure

Refer to the "Overview" chapter for details.

Step 1: Connect the PC to the CPU or NOE module

Step 2: Launch the Unity Loader Click on Start→Program/Schneider-Electric→UnityLoader→UnityLoader The following screen appears:

Project Firmware Options About PC Project PC Project Name: Last Build: Version:	PLC Project Image: Enable Transfer Name: East Build: Enable Version: Enable Statement
PC Project Data Name: Last Build: %M: From: To: %MW/: Unlocated Data:	PLC Project Data Enable Transfer %M: From: %MW: From: %MW: From:
PC Project Files	PLC Project Files Files Set Web Files: Data Storage: Memory Card
Media: USB Address: SYS PLC:	State: Free Space:

Step 3: Select the Connection Media

To download the firmware into the PLC, select the communication media (Ethernet or USB for Modicon M340 CPU) in accordance with the selected physical link. If Ethernet is selected enter the address in the "Address" selection item.

🝨 Unity Loader 2,0	
Project Firmware Options About	
PC Project	PLC Project
	Enable Transfer
Name:	Name:
Last Build:	Last Build:
Version:	Version:
PC Project Data	PLC Project Data
	Enable Transfer
Name:	
Last Build:	
%M: From: To:	%M: From: To:
%MW: From: To:	%MW: From: To:
Uniocaled Data.	Unideated Data.
PC Project Files	PLC Project Files
	Enable Transfer
User Web Files: Data Storage:	User Web Files: Data Storage:
	Memory Card
ledia: USB ▼ ddress: SYS PLC:	State: Free Space:
Ethernet	
Scone Connect PC <=> PLC	Transfer Start PLC Close
Connect	
Click on the button to cor	nnect the PC to the PLC. The
Co	nnect
connection is confirmed when the	button changes to
	outton enunges to
Disconnect	
a button. If it does not cha	ange, verify that the PLC is turned on
and the physical connection between PC	and PLC is correctly set
THE REPORT OF A DESCRIPTION OF A DESCRIP	

Select the "firmware" tab to get info on the PC (on the left side of the screen) and the PLC (on the right side of the screen): Verify the CPU

or NOE module	Unity Loader 2.0
to update	Project Firmware Options About
	PCPLC
	🔽 💓 🗆 Save on Memory Card 🔽 Module 📃
	Device Versi Description Device Versi Description
	BMX P34 2030 UT 00 CPU 34U-30 Ethernet CANo BMXCPU-WEB_B 00.00 BMX CPU WEB site - class CANopen Tools 01.00 CANopen Tools CANopen Stack 01.00 CANopen Master embedder
	MAC Address: 00-80-F4-02-E4-DB
	Media: USB Address: SYS PLC: STOP State: Ok Free Space: 16 737 792
	Scan Disconnect PC <=> PLC Iransfer Stagt PLC Close

Verify the CPU/NOE module to be updated is in the PLC firmware properties area on the right (in this example a BMX P34 2030).

Step 5: Select the FW file to download	In the PC firmware properties on the left, select the new FW file with its path. To do this, click on the button to browse to the new FW file.
	Select the *.ldx FW file to download it into the PLC (for example Bmx2030_B.ldx), and click on the per button.

Step 4:

Step 6: Download the FW file

- 1. After selecting the FW file to download, three cases are possible:
- The system detects that the firmware of the PC and the PLC are

compatible. This is indicated by a green arrow . In this case the download will be possible.

🔶 Unity Loader 2.0			
Project Firmware Options About			
PC		PLC	
D:\Firmware\CPU V2\Bmx2030_B.ldx	I I	Save on Memory Card	Module
Device Versi Des	cription	Device Versi	Description
CANopen Stack 01.00 CAN	lopen Master embedde	BMX P34 2030 01.00	CPU 340-30 Ethernet CANc
BMX P34 2030 02.0 CPU BMXWEBCPUB 01.00 BM	J 340-30 Ethernet CAN Z CPU WEB site - Class	BMXCPU-WEB_B 00.00 CANopen Tools 01.00	BMX CPU WEB site - class
BMAWEBCF0B 01.00 BMA		CANopen Stack 01.00	CANopen Master embedde
	~		
		MAC Address: 00-80-F4-02-E4-	DB
L			
Connection		Memory Card	
Media: USB 🖵 Address: SYS	PLC: STOP	State: Ok	Free Space: 16 737 792
<u>S</u> can <u>D</u> isconnect	PC <⇒ P <u>L</u> C	Iransfer Sta <u>r</u> t PL	C Close



Any loss of communication during the update procedure can cause severe damage to the CPU or NOE module.

Failure to follow these instructions can result in injury or equipment damage.

Step 6: Download the FW file (continued) • The system detects that the firmware on the PC is an earlier version than the firmware on the PLC. This is indicated by a yellow

arrow. In this case the download will be possible but will downgrade the firmware on the PLC to the earlier version.

Unity Loader 2.0 Project Firmware Options About PC D:\Firmware\CPU V2\Bmx2020_B.ldx Device Versi Description BMX P34 2020 02.0 CPU 340-20 Modbus Ether BMXWEBCPUB 01.00 BMX CPU WEB site - Class	PLC Save on Memory Card Module Device Versi Description BMX P34 2030 01:00 CPU 340:30 Ethernet CANc BMXCPU-WEB_8 00:00 BMX CPU WEB site - class CANopen Tools 01:00 CANopen Tools CANopen Stack 01:00 CANopen Master embedder MAC Address: 00:80F4:02E4DB
Connection Media: USB ▼ Address: SYS Scan Disconnect	Memory Card STOP State: Dk Free Space: Iransfer Statt PLC Close

Step 6: Download the FW file (continued) • The system detects that the firmware of the PC and the PLC are not

compatible; this is indicated by a red arrow and the transfer button is additionally grayed out. In this case the

download will not be possible.

Project rumware Upt	ons About	tion odbus Ethernet Opt DEO100 WEB site -	PLC Save on Memory Device BMX P34 2030 BMXCPU-WEB, B CANopen Tools CANopen Tools CANopen Stack	Card Versi De 01.00 EF 01.00 BR 01.00 C2 01.00 C2 01.00 C2	Module scription U 340-30 Ethernet CANc KX CPU WEB site - class Nopen Tools Nopen Master embedder Nopen Master embedder
Connection Media: USB 💌	Address: SYS	PLC: ST	DP State:	Card Fr	ee Space: 15 530 496

Solve the issue before continuing.

2. If the download is possible (the transfer arrow is shown in green or yellow), ensure that an SD-Card is plugged in the CPU/NOE module

and click on the **I**ransfer button. The security advice message appears:

Security	Advice	×
٨	Before transferring data to the PLC please make sure, that you are connected to the correct device by verifying the PLC address and the MAC address displayed on the Firmware tab. Transferring data to a wrong device may affect you	r
	Do you want to continue?	
	Yes No	
🗌 Dor	't show this message again in this session	

 After verifying the CPU/NOE module and MAC address click on the Yes button to download of the FW file. Step 6: Download the FW file (continued) 4. During the download the remaining time is displayed. The duration depends on the protocol used and the configuration of the PC.

T	ransferring data to PLC 🛛 🗙	
	Initializing transfer	
	Firmware download started	
	Caculating required space Required space: 5 361 664, available space: 15 530 496	
	Transferring files to the PLC	
	Abort	
	/SDCA/Firmware/Device/vxWorks_bmx2030.bin	

5. When the download has successfully completed, the screen below is displayed.

1	ransferring data to PLC	X
	Initializing transfer	_
	Firmware download started	
	Caculating required space Required space: 5 361 664, available space: 15 530 496	
	Transferring files to the PLC	
	Transfer completed	
	Writing files to Flash memory Flash upgrade completed for channel 2, index 1 Flash upgrade completed for channel 0, index 0	
	Waiting for PLC ready Firmware upgraded successfully	
		/
	7 825 408 of 7 825 408 bytes transferred Flash upgrade completed for channel 0, index 0	
	Close	

Click on the button to quit the transferring screen.

Step 7: Reset the PLC

• When the download of the FW file is complete, the PLC is automatically reset.

Step 8: Verify if the firmware update was successful Verify the new CPU version as follows:

- 1. Connect the PC to PLC with a USB or Ethernet cable
- 2. Open the Unity Loader
- Select the USB or Ethernet protocol (if Ethernet is selected, enter the address in the "Address" selection item).

4.	Click on the button
5.	Select the "firmware" tab
	🖢 Unity Loader 2.0
	Project Firmware Options About PC D:\Firmware\CPU V2\8mx2030_B.ldx PLC Device Versi Description CANopen Master embedde BMX P34 2030 02.0 CPU 340-30 Ethernet CAN BMX/VEBCPUB 01.00 BMX CPU WEB site - Class CANopen Tools 01.00 CANopen Master embedde MAC Address: 00-80-F4-02-E4-DB
	Connection Memory Card Media: USB y Address: SYS PLC: STOP State: Dk Free Space: 15 530 496
	Scan Disconnect PC <=> PLC Iransfer Start PLC Close

In this example the CPU firmware has been updated to version 02.00.

ACAUTION

UNEXPECTED EQUIPMENT BEHAVIOR

After updating the CPU/NOE module do not remove the SD-Card used for the update.

Failure to follow these instructions can result in injury or equipment damage.

2.4. Upgrade a BMX P34 2010 or 2030 CPU to a BMX P34 20102 or 20302

Object of this paragraph	This paragraph describes how to update a Modicon M340 CANopen CPU BMX P34 2010 or 2030 (V1.0 or V2.0) to respectively a CANopen2 CPU BMX P34 20102 or 20302.
	Two new M340 CANopen CPU are commercialized with the following part numbers: BMX P34 20102 and BMX P34 20302.
	We provide the possibility to upgrade CANopen CPU modules BMX P34 2010 and 2030 V1.0 or V2.0 to BMX P34 20102 or 20302.
	Note:If a CPU module is upgraded, the marking on the front panel and on the label is no more consistent.
Update procedure	The CPU P34 2010 or P34 2030 have to be prepared to accept the firmware of a P3420102 or P3420302.
	 The same procedure as described in Chapter 2.3 applies with steps 4 to 6 being repeated twice as follows : Apply the procedure described in Chapter 2.3 from steps 1 to 3. Perform steps 4 to 6 in order to download a patch file to upgrade the CPU module: According to the CPU part number, select the appropriate ldx file: Bmx2010_to_20102_B.ldx or Bmx2030_to_20302_B.ldx". Download the selected file. Now the CPU module is ready to accept the new firmware Start again the procedure from step 4 to download the firmware in the upgraded CPU module and continue the procedure following the different steps for a BMX P34 20102 or 20302 module. Important note: The complete upgrade has to be performed at once (prepare the CPU then download the firmware). Do not cut the power off during the download and before upgrading completely the CPU.

3. Update a Modicon M340 CPU/NOE module using an SD-Card

Object of thisThis chapter describes how to update a Modicon M340 CPU, NOE using an
SD-Card.

The SD-Card must first contain the new FW file before it can be used to perform the update. Therefore the procedure is split into two main phases:

- 1. Initialize the SD-Card using Unity Loader and a PLC that has already been updated
- 2. Use the SD-Card from phase 1 to update a Modicon M340 CPU/NOE module in another PLC

Note:

- If updating a NOE 0100 V1.0 module with DOM (Date Of Manufacturing) from 0727 to 0803, it must be first patched using the procedure detailed previously (see Chapter 2.2 "Specific case for some NOE 0100 modules").
- For BMX P34 2010 or 2030 upgrade to BMX P34 20102 or 20302, the upgrade cannot be performed using a single SD-Card. 2 different SD cards are required in this case:
 - A first SD-Card initialized with Bmx2010_to_20102_B.ldx or Bmx2030_to_20302_B.ldx file (see chapter 3.1).
 - A second SD-Card containing the up-to-date CPU firmware.

3.1. Initialize the SD-Card with the firmware

Prepare a Modicon M340 CPU/NOE SD-Card In order to proceed with an update, the following are required:

- Modicon M340 CPU/NOE module with firmware version V2.0 or higher already installed.
- Unity Pro Version 4.0 or higher software must be installed on the PC.
- The firmware is available on <u>www.schneider-electric.com</u>, both as independent files or included in an electronic CD OS image (.iso file) that can be downloaded.
- The Unity Loader tool (provided with Unity) must be installed on the PC. This tool allows the user to download the PLC firmware.
- The CPU/NOE SD-Card identity must fit with the target and is dedicated to it; the free memory room on the SD-Card must be checked (refer to the Unity Loader documentation for the description of the necessary size).

Initialize the SD-Card using Unity Loader To initialize the firmware file into an SD-Card, follow the same procedure as provided in "Chapter 2.3. Update Procedure" with the following exceptions:

1. At Step 6, insert the SD-Card into the Modicon M340 CPU/NOE module, and check the "Save on Memory Card" box before clicking on the "Transfer" button.

🞐 Unity Loader 2.0				
Unity Loader 2.0 Project Firmware Options About PC D:\Firmware\CPU V2\\Bmx2030_B.ldx Device Versi Description CANopen Stack 01.00 CANopen Master embedde BMX-P34 2030 02.0 BMX:VEBCPUB 01.00 BMX CPU WEB site - Class	PLC Save on Memory Card Module Device MMX P34 2030 BMX P24 2030 BMX P24 2030 BMX P24 2030 BMX P24 2030 BMX P24 2030 BMX P24 303 Ethemet CANc BMX P24 2030 BMX P24 303 Ethemet CANc BMX P24 2030 CANopen Tools CANopen Tools CANopen Tools CANopen Stack 01.00 CANopen Master embedde MAC Address: 00-80-F4-02-E4-DB			
Connection Media: USB 💌 Address: SYS PLC: 🛙	NDCONF Ok Free Space: 15 530 496			
<u>S</u> can <u>D</u> isconnect PC <=> P∐C	Iransfer Start PLC Close			

2. At the end of the procedure, unplug the SD-Card in order to use it for the next phase.

3.2. Update a Modicon M340 CPU/NOE module procedure

Update a Modicon M340 CPU/NOE module	 After initializing the SD-Card, the procedure to update the firmware for Modicon M340 CPU/NOE module using this SD-Card is as follows: It is recommended to stop the PLC to be updated, Insert the SD-Card into the PLC, Reset the PLC. The firmware is automatically downloaded when the PLC restarts.
	Note: The EW file is automatically removed from the SD-Card
	 The FW file is automatically removed from the SD-Card. The SD-Card must remain in the CPU or NOE slot because the updated Web pages are stored on it.
Restart the PLC	 After this phase the PLC is on the stop forced mode. You can start the PLC: Either, by clicking on the Start PLC button with Unity Loader 2.0. Or, if the "Automatic start in Run" is selected in the application, a manual reset will automatically start the PLC.
	A CAUTION
	UNEXPECTED EQUIPMENT BEHAVIOR After updating the CPU/NOE module do not remove the SD-Card used for the update.

Failure to follow these instructions can result in injury or equipment damage.

4. Changing an application into a V2.1 application with Unity Pro V4.1

Object of thisThis chapter describes briefly how to change a V1.0 or V2.0 application into
a V2.1 application (refer to Unity Pro documentation for the detailed
procedure of each step).

4.1. Prerequisites

Before changing application version from V1.0 or V2.0 to V2.1:

Modicon M340 CPU / NOE

Update

- Modicon M340 CPU firmware must be updated to V2.1 (for CANopen CPU modules, refer to chapter 2.4 above).
- NOE module with firmware version V1.0 must be updated to version V2.0 or higher.

4.2. Main steps to follow in Unity Pro V4.1

Changing application version V1.0 or V2.0 to V2.1	 To change an application without any NOE from V1.0 or V2.0 to V2.1, please proceed as follows: Replace the CPU from V1.0 or V2.0 to V2.1 (note that for CANopen CPU, the part number is to be changed, e.g. BMX P34 2010 is to be changed with BMX P34 20102) Build and Transfer.
--	---

In case a NOE is configured in the application:

- Delete the NOE 01x0 module
- Replace the CPU from V1.0 or V2.0 to V2.1
- Add the NOE 01x0.2 module
- Change the Family of the Ethernet Network from 'NOE 0100, NOE 0110' to 'NOE 0100.2, NOE 0110.2'
- Enable the Modules Utilities 'IO Scan' and/or 'Global Data' and/or 'Address Server' as 'YES' if they were previously configured
- Link this Family to the NOE 01x0.2 module
- Build and Transfer



4.3. Additional capability

Updating both Please refer to Unity Loader documentation to build such an SD-Card application with an SD-Card Card