

# DR5TE4U Rectifier Kit Detail

## General Information

This topic details the parts included in the DR5TE4U rectifier kit. Some of the parts in the kit are not used when it is applied to a LC1F800 contactor. The following picture topics make it clear what parts are used (or not used) for the various rectifier mounting options. No matter how the rectifier is mounted, the rectifier terminals are hard wired to the coil terminals.


## Parts List




## Rectifier Mounting Methods

- ▶ [Direct mounting the rectifier directly to the side of the coil assembly](#)
- ▶ [Panel mounting the rectifier](#)
- ▶ [DIN rail mounting the rectifier](#)

# DR5TE4U Direct Mounting



# DR5TE4U Panel Mounting



# DR5TE4U DIN Rail Mounting

