




Transport & handling



High
centre of
gravity




Use all four lifting points

Use lifting lugs
ONLY to lift
Ringmaster



Do not put anything on Ringmaster



Do not stand on Ringmaster

Units can be carried on open topped trucks or stored outside for short periods provided that all apertures are covered. Units should not be considered weatherproof until the paint work has been inspected and, if necessary any damage should be re-touched. Please refer to paintwork on page 7 for repairing damaged paintwork.

If units are to be stored for long periods of time they should be stored in a warm, dry location and protected against dust and debris.

All units can be off loaded by fork lift truck using the transport pallet. They can also be off loaded using the lifting lugs fitted at the top of the unit.

Storage



Ringmaster is only suitable for outdoor storage when packaged correctly or fully commissioned.

The type of gland supplied will vary in accordance with specific contract requirements.

The style of packaging will vary in accordance with the method of transportation and specific contract requirements.

Please consult your commercial documentation to see how this equipment is packed.