




Ready Modes Configuration – Android



Ready Modes Configuration Wiser Air Website Account


01. Profile and settings



02. Click on the arrow and then on Ready Modes.

Devices & Device Permissions

+ Sync Devices



03. Here you can change the setpoints for the 3 modes. (this will be applied on your schedule)

Ready Mode Setpoints

This is for year-round comfort while you're home, away, and sleeping. We suggest a setting that is for warmer in the summer and cooler in the winter to complement your body's natural temperature correction.

