



YEDU.E95463 Uninterruptible Power-supply Equipment

[Page Bottom](#)

Uninterruptible Power-supply Equipment

[See General Information for Uninterruptible Power-supply Equipment](#)

SCHNEIDER ELECTRIC IT CORPORATION, FKA APC AMERICAN POWER CONVERSION

E95463

132 Fairgrounds Rd
PO BOX 278
West Kingston, RI 02892 USA

Trademark and/or Tradename: "3N94" , "42C2" , "55K6" , "APC" , "APC By Schneider Electric" , "American power Conversion" , "E163088" , "E87247" , "E95463" , "MGE UPS System" , "Schneider Electric"

Accessories, external batteries Model(s) FJX120RMBPJ2U, NMX120RMBPJ2UB

Accessories, remote battery cabinets Model(s) RT72RMBP, SRT72BP, SRT96RMBP

Auxiliary cabinet maintenance bypass assemblies, for use with transfer switches and maintenance bypass cabinets Model(s) 72-132378-00, 72-132738-01

Maintenance bypass cabinets, for use with transfer switches Model(s) 72-131703-##, 72-131742-##, 72-131743-##, 72-13201#-##

Maintenance Bypass Single Wall Cabinet Model(s) SBPSU10K15F-WP, SBPSU20K30F-WP

Transfer switches, for use with optional bypass cabinets Model(s) 72-131695-##, 72-13201#-##, 72-131736-##, 72-131900-##, 72-13200#-##, 72-13202#-##, 72-1346XX-XX

Uninterruptible power supplies "Smart-UPS " Model(s) APC3R120, SMC1500C

Uninterruptible power supplies Model(s) 72-174001-00 G5K+, 72-1740XX-XX+, Galaxy VX 500 kW, Galaxy VX 625 kW, Galaxy VX 750 kW, Galaxy VX 750 kW N+1, NMM1200RMJ1UB, NMT3000RMJ2UB, NMX3000RMHV2UB, NMX3000RMLV2UB, SMT1500NC, SMT1500RM2UNC, SMT2200RM2UNC, SMT3000RM2UNC, SMX750NC (b), SRT10KRMXLTX781, SRT2200RMXLA, SRT2200RMXLA-NC, SRT2200XLA, SRT3000RMXLA, SRT3000RMXLA-NC, SRT3000XLA

Uninterruptible power supplies "Smart-UPS Model(s) SMT750RM2UNC

Investigated to ANSI/UL 1778 (Second Edition)

Accessories "Smart-UPS " Model(s) SU24XLBPX114, SU48XLBPX114

Accessories, batteries "Smart-UPS" Model(s) SU48R3XLBP

Accessories, battery cabinets "Symmetra RM" Model(s) SYRMXR4

Accessories, battery cabinets Model(s) SYXR12, SYXR4, SYXR4J-BM

Accessories, battery pack options " " Model(s) SURT192XLBP, SURT192XLBPJ

Accessories, battery pack options Model(s) DLRT192RMXLBP3U

Accessories, external batteries " " Model(s) SURTA48RMXLBP2U, SURTA48XLBP, SURTA48XLBPJ

Accessories, external batteries Model(s) FJRT192XLBPJ, HTRT192RMXLBPJ, SURT192RMXLBP3U, SURT192XLBP, SURT192XLBPJ

Accessories, master control panels (MCP) Model(s) 72-132116-2 thru -6, 72-13217X-XX+

Accessories, PDU panels " " Model(s) 0N-0262

Accessories, remote status monitor panels Model(s) 20-00029-XX+, 20-00048-XX+, 20-00121-XX+, 20-00165-XX+, 20-120100-XX+, 20-120101-XX+, 20-120102-XX+, 20-120103-XX+, 20-120105-XX+, 20-120106-XX+, 5-00369-XX+, 5-00643-XX+, 5-00644-XX+, 6-00875-XX+, 6-00938-XX+, 7-00396-XX+, 72-130142-XX+, 72-131820-XX+, 72-133XXX-XX+, 72-140528-XX+, 72-161408-XX+, 72-501168-XX+, 76-141101-XX+, 76-161408-XX+, QRM12674

Accessories, step-down transformers Model(s) AP9621, AP9621X215, AP9626, AP9626J, AP9627, AP9627J, AP9628, AP9628J, APTF10KJ01, APTF10KT01, APTF10KW01, APTF20KW01, FJTF2J, SRT10KRMTF, SRT5KRMTF, SRT5KTF, SRT5KTFJ, SURT005, SURT006, SUTF2, SUTF3, SUTF3-PSX, SUTF3J, SUTF3J-PSX, SYTF2, SYTF2J, SYTF2JX215, SYTF2X215, SYTF3, SYTF3-PSX, SYTF3J, SYTF3J-PSX, SYTF4

Accessories, step-up/down transformers Model(s) SURT003, SURT004

Accessories, synchronization box modules Model(s) 72-13315X-XX+

Accessories, transformer cabinet with maintenance bypass panels (MBP) "Smart-UPS" Model(s) 2130-3JX, 2130-3RX, 2130-4JX, 2130-4RX, 39Y8842, 39Y8853, 40K9778, 40K9780, DLRT8000RMXL6U, EMC7500XLU, EMCRT10000XLU, EMCRT7500XLU, FJRT10000XLJ, FJRT10000XLJ-M, FJRT10000XLJQ, IBMR10000RTH6U, IBMR10000RTHJ6U, IBMR7500RTH6U, IBMR7500RTHJ6U, IBMUPS10000XHV/2130-8RX /25R5584, IBMUPS7500XHV/2130-6RX/25R5583, NECRT10000XLJ-M, NMRT10000XLJ, NMRT8000UJX6UW, SURT10000RMXL6U, SURT10000XLJ, SURT10000XLT, SURT10000XLTW, SURT7500XLJ, SURT7500XLT, SURT7500XLTW, SURT8000RMXL6U, SURT8000XLI, SURT8000XLJ, SURT8000XLT, SURT8000XLTW

Accessories, transformer cabinet with maintenance bypass panels (MBP) Model(s) QDLO17927, QMCA77573

Accessories, uninterruptible power dupply module Model(s) SYPM Symmetra Power Module

Auxiliary cabinet assemblies Model(s) A2716-60000, A2717-60000

Auxiliary cabinets Model(s) 0M-11481, 0M-814800

72-1315, followed by 0, 1, 2, 3, 4, 5 or 6, followed by 1, 2, 3, 4, 5, 6, 7 or 8, followed by 0, 1, 2, 3, 4, 5, 6 or 7, followed by 0, 1, 2 or 4, followed by 0 or 1.

72-131562-###, 72-132378-##, 72-13242#-00, 72-133077-00, 72-133077-35, 72-133077-70, 72-133110-01, 72-133110-21, 72-133110-31, 72-133110-41, 72-133110-51, 72-133110-61, 72-135186-##, 72-160 4XX-XXX+, 72-160 5XX-XXX+, 72-160 8XX-XXX+, 72-1601, 72-16011X-XXX, 72-16013X-XXX, 72-17050X-10, 72-17050X-X0*, 72-1708XX-XX*, 72-1730##-##

Battery cabinet assemblies Model(s) 891056, 891057, 891076, 891077, 891101, 891102

Battery cabinets "XR Battery Frame" Model(s) SYBFXR3RM, SYBFXR9, SYBFXR9RM

Battery cabinets Model(s) 72-170400-XX*, 72-17305#-##, 72-17308#-##, 72-17402#-##, 72-174022-16, 72-174022-26, BDP 310E 208V/1000, BDP 310E 208V/800, BDP 310E 480V/1000, BDP 310E 480V/800, BDP 320E 208V/1000, BDP 320E 208V/800, BDP 320E 480V/1000, BDP 320E 480V/800, BDP 340E 208V/1000, BDP 340E 480V/1000, BDP 340E 480V/800, BDP 360E 480V/1000, BDP 380E 480V/1000, BDP2*, BDP4*

ISB10, followed by -30K, -60K, -80K or -100K, followed by 1 thru 6, followed by C1, C2 or C3.

ISVTBXR (e), Pulsar EXB 2200/3200, SL*, SLB*, SUVTBXR (e)

battery cabinets Model(s) SYB400K1000GXR-NEG, SYB400K1000GXR-POS

Battery disconnect cabinets Model(s) MCCB-310E-208, MCCB-310E-480, MCCB-3120E-480, MCCB-3160E-480, MCCB-320E-208, MCCB-320E-480, MCCB-3240E-480, MCCB-3320E-480, MCCB-3400E-480, MCCB-340E-208, MCCB-340E-480, MCCB-3500E-480, MCCB-360E-208, MCCB-360E-480, MCCB-380E-280, MCCB-380E-480, SBB10K20G, SBB10KF, SBB120K160G, SBB15K20F, SBB240K320G, SBB30K40F, SBB30K60G, SBB400K500G, SBB400K600G, SBB60K80F, SBB800K1000G, SBB80KG

Battery packs "Smart-UPS" Model(s) SU48RMXLBP3U

Battery packs Model(s) BT170410, PULSAR ESVB

Extended run battery packs Model(s) 32P1692, SUM48RMXLBP2U

External battery cabinets Model(s) 72-1313, followed by 00, 01, 02, 04 or 05, followed by -00, -01, -02 or -03.

72-16025X-XXX+, 72-1602XX-00+, 72-1602XX-10+, PULSAR EXB 1500 RT

External battery packs "Smart-UPS " Model(s) SU24R2XLBP, SU24RMXLBP2U, SU24XLBP, SU48BP, SU48XLBP

External bypass switches Model(s) AP019 UPS Hot Swap-Out Box

Field upgrade kits Model(s) 81-17XXXX-XX*

I/O sidecar cabinets Model(s) QJR37710, QPLI46100

Isolation transformer modules Model(s) DP310E 208V, DP310E 480V, DP315E/320E 208V, DP315E/320E 480V, DP330E/340E 208V, DP330E/340E 480V, DP360E/380E 208V, DP360E/380E 480V

Isolation transformers Model(s) 72-153703-02, 72-153704-03, 72-153704-04, 72-153704-05, 72-153705-02, 89032, 891085, 891086, 891087, 891088

Maintenance by-pass panel and by-pass static switch assemblies Model(s) SYMBP1000C1G12L-100, SYMBP800C1G12L-100

Maintenance bypass assemblies Model(s) 72-170600-XX*, 72-1708XX-XX*

Maintenance bypass cabinets Model(s) 72-13181, 72-16001, 72-16002, 72-16004, 72-16005, 72-160400-44, 72-160402-42, 72-160402-45, 72-160402-48, 72-16602, 72-16702*, 72-16703*, 72-16704*

Maintenance bypass switches Model(s) SBP-40A-SS, SBP-80A-SS, SBP10KFR2M1, SBP10KGR2M1, SBP15KFR2M1, SBP15KGR2M1, SBP20KFR2M1, SBP20KGR2M1, SBP30KFR2M1, SBP30KGR2M1, SBP40KFC1M1, SBP40KFR2M1, SBP40KGR2M1, SBP60KFC1M1, SBP60KGR2M1, SBP80KFC1M1, SBP80KGR2M1

MBP Model(s) Series 0M-E8TH, followed by letters and numbers.

Optional hardwiring kits Model(s) SURT009

Output option panel accessories "Smart-UPS " Model(s) SU027, SU027RM, SU028, SU028RM, SU029, SU029RM, SU029RM3U

Paralleling cabinet modules Model(s) ISPARCAB1, ISPARCAB2, ISPARCAB3

Power distribution unit accessories Model(s) AP7580, AP7581, AP7582, AP7583, AP7584, AP7630, EMC750R1, EMC750R1J, EMC750RM1U, EMC750RMJ1U, NEC750RMJ1U, NECA750RMJ1U, SU750RMJ1U, SUA1000RM1U, SUA750RM1U, SUA750RMJ1U, SUA750RMJ1UB

Power switches "Power-UPS" Model(s) SU040, SU041, SU042-1, SU042-2, SU042-4, SU042X163, SU043, SU044-1, SU044-2, SU045-1,

SU045X163, SU045X237, SU045X283, SU045X449

Q5N Model(s) Series 0M-E8TG, followed by letters and numbers.

Rectifiers/Chargeres Model(s) 72-130102-51

Remote battery cabinets Model(s) M EXB

Service bypass switches Model(s) SBPSU10K15FC1M1, SBPSU10K30FC1M1-FP, SBPSU10K30FC1M1-WP, SBPSU20K30FC1M

Uninterruptible power supplies " " Model(s) RWRTA2000XL, SURTA1000RML2U, SURTA1000XL, SURTA1500RML2U, SURTA1500RML2U-NC, SURTA1500XL, SURTA1500XLJ, SURTA2000RML2U, SURTA2000XL, SURTA2200RML2U, SURTA2200RML2U-NC, SURTA2200XL

Uninterruptible power supplies "Back-UPS PRO" Model(s) 280SIX38, 280SUS, 420SUS, 650SUS, BP350U, BP350UC, BP500CLR, BP500U, BP500UC, BP700U, BP700UC, CNB700X, CNB900X

Uninterruptible power supplies "BackUPS PRO" Model(s) RW350DR*, RW350DRI*, RW500DR*, RW500DRI*, SP500DR*, SU500DR*, SU500IDR*, SUA500PDRI*

Uninterruptible power supplies "Power-Stack" Model(s) 250 & 450, 450I, 450IX231, EMC350RMU1U, SC250RM1U, SC450R1X542, SC450RM1U

Uninterruptible power supplies "Smart-UPS" Model(s) 2419-RU1, 420NET, 620INET, 620NET, 700RM2U, DL5000RMT5U, DLRT5000RMLJ3U, DLRTD5000RMLT3U, EMC6000R3XLU, FJRT5000XLJ3U, FJRT5000XLJ3U-M, FJRT5000XLJ3UQ, HTRT5000RMLXJ, IBMR5000RTH3U, NECRT5000XLJ3U, NECRT5000XLJ3UM, NECRT5000XLJ3UW, RWRT5000XLU, RWRTD5000XLU, SC420, SC620, SC620X565, SMC1000I, SMC1000I-2U, SMC1500I, SMC1500I-2U, SMT1000I, SMT1000RMI2U, SMT1500I, SMT750I, SMT750RMI2U, SSURT6000XLJ, SU2200RML3U, SU3000RML3U, SU3000RML3U-PSX, SU5000R5TBX114, SU5000R5TBX114, SU5000R5TBX135, SU5000R5TBX168, SU5000RMLXLT5U, SU5000T, SUOL1000XLI, SUOL2000XLI, SURT1000XLI, SURT1000XLIX155, SURT2000XLI, SURT3000UXI, SURT3000XLI, SURT3000XLIX322, SURT3000XLIX554, SURT3000XLT, SURT3000XLTW, SURT5000RMLJ, SURT5000UXI, SURT5000XLI, SURT5000XLIX438, SURT5000XLJ, SURT5000XLT, SURT5000XLTW, SURT6000RMLT3U, SURT6000XLI-CC, SURT6000XLIX155, SURT6000XLIX547, SURT6000XLJ, SURT6000XLT, SURTD3000RMLT3U, SURTD3000XLI, SURTD3000XLI322, SURTD3000XLT, SURTD5000RMLXLP3U, SURTD5000RMLXLP3U, SURTD5000RMLT3U, SURTD5000XLI, SURTD5000XLJ, SURTD5000XLT, SURTD6000RMLXLP3U, SURTD6000RMLXLP3U, UPS SU5000RMT5U

Uninterruptible power supplies "Smart-UPS " Model(s) 1000, 1000J, 1000RM, 1000RM2U, 1000RMJ, 1000RMNET, 1000XL, 1000XLRM, 1200J, 1400, 1400J, 1400JX114, 1400R2X180, 1400RM, 1400RM2U, 1400RMIX134, 1400RMJ, 1400RMJ2U, 1400RMJBX135, 1400RMNET, 1400RMX138, 2200, 2200J, 2200NET, 2200RM, 2200RMJ, 2200RMLNET, 2200XL, 2200XLX114, 3000, 3000J, 3000RM, 3000RMJ, 450, 450D, 450J, 500J, 700, 700J, 700JX114, 700RM, 700RMNET, 700XLX114, 900J, 90P4811, APC2R120, APC2RA, APC3RA, APC3TA, APCR208, DIG1400RM, DIG3000RM3U, DL1400, DL1400R2, DL1400RM, DL1400RM2U, DL1400RMBX135, DL1400RMJ, DL1400RMJ2U, DL2200RM3U, DL3000RM, DL3000RM3U, DL3000RMJ3U, DL700, DL700J, DLA1500, DLA1500RM2U, DLA1500RMJ2U, DLA2200, DLA2200J, DLA2200RM2U, DLA3000, DLA3000J, DLA3000RM2U, DLA3000RMJ, DLA3000RMT2U, DLA750, DLA750J, DLT1500J, DLT1500RMJ2U, DLT3000RMJ2U, DLT750J, FJ1500RMJ2U, FJ1500RMJ2U-M, FJ3000J, FJ3000RMJ3U, FJ3000RMJ3U-M, FJ3000RMJ, FJ700J, FJ750J, FJ750J-M, FJ750J-MB, FJ750J-MBQ, FJC500J, FJC500J-M, FJT1500J, FJT1500RMJ2U, FJT1500RMJ2U-M, FJT750J, HTA3000RMJ2UB, HTA750JB, HTT1000J, HTT1500J, HTT1500RMJ2U, HTT3000RMJ2U, HTT750J, IBM1500RM2U, NEC3000R3JBX135, NEC3000RMJ3UW-M, NECA1500JW-M, NECA1500RMJ2UW, NECA1500RMJ2UWM, NECA3000JW-M, NECA500JW, NECA500JW-M, NECA750JW-M, NMA3000RA3UW, NMA3000RA3UW-M, NMA3000RJ2UW, NMA3000RJ2UW-M, NMA3000RMLXJ3U, NMT1000J, NMT1000J-M, NMT1500J, NMT1500J-M, NMT1500RMJ2U, NMT1500RMJ2U-M, NMT1500RMJ2UB, NMT3000J, NMT3000J-M, NMT3000RMJ2U, NMT3000RMJ2U-M, NMT500J, NMT500J-M, NMT750J, NMT750J-M, NS2200RM3U, NS3000RM3U, NS3000RMT3U, RWA1000, RWA1500, RWA750, SMC1000, SMC1000-2U, SMC1000-2UC, SMC1000C, SMC1500, SMC1500-2U, SMC1500-2UC, SMT1000, SMT1000C, SMT1000J, SMT1000R2X122, SMT1000RM2U, SMT1000RM2UC, SMT1000US, SMT1500, SMT1500C, SMT1500J, SMT1500JX713, SMT1500R2X122, SMT1500R2X180, SMT1500RM2U, SMT1500RM2UC, SMT1500RMI2U, SMT1500RMJ2U, SMT1500RMUS, SMT1500US, SMT1500X413, SMT1500X448, SMT1500X713, SMT2200, SMT2200J, SMT2200R2X106, SMT2200R2X180, SMT2200R2X658, SMT2200RM2U, SMT2200RMUS, SMT2200US, SMT3000, SMT3000J, SMT3000R2X145, SMT3000R2X180, SMT3000RM2U, SMT3000RMJ2U, SMT3000RMT2U, SMT500J, SMT750, SMT750J, SMT750R2X122, SMT750RM2U, SMT750US, SMT2200RMLTNET, SU1000B, SU1000BX120, SU1000NET, SU1000RM2U, SU1000RMBX120, SU1000RMX176, SU1000RMLXB120, SU1000US, SU1000X127, SU1000X93, SU1000XLNET, SU1400B, SU1400BX120, SU1400JX172, SU1400R2BX135, SU1400R2JBX135, SU1400R2X138, SU1400R2X217, SU1400R3XL171, SU1400R3XLJX171, SU1400RM2U, SU1400RMBX120, SU1400RMJX172, SU1400RMX106, SU1400RMX176, SU1400RMLX3U, SU1400RMLX3U-PSX, SU1400RMLXB3U, SU1400RMLXB120, SU1400RMLXJ3U, SU1400RMLTNET, SU1400US, SU1400X106, SU1400X114, SU1400X145, SU1400X93, SU1400XLNET, SU1500RMX155, SU2000R3X155, SU2200BX120, SU2200NET, SU2200R3BX120, SU2200R3X167, SU2200R3X275, SU2200RM3U, SU2200RMBX120, SU2200RMJ3U, SU2200RMNET, SU2200RMLTX153, SU2200RX3X258, SU2200X106, SU2200X111, SU2200X115, SU2200X180, SU2200X93, SU2200XLNET, SU2200XLT, SU2200XLNET, SU2200XLTX153, SU3000NET, SU3000R2X345, SU3000R3BX120, SU3000R3BX135, SU3000R3JBX120, SU3000R3X145, SU3000RM3U, SU3000RMBX120, SU3000RMJ3U, SU3000RMJBX135, SU3000RMNET, SU3000RMT3U, SU3000RMTX136, SU3000RMX228, SU3000TNET, SU3000X177, SU700B, SU700BX120, SU700NET, SU700R2IX38, SU700RM2U, SU700RMBX120, SU700RMX176, SU700RMLXB120, SU700RMLXNET, SU700US, SU700X114, SU700X167, SU700X93, SU700XLNET, SUA1000I, SUA1000IX38, SUA1000RMUS, SUA1000US, SUA1000X127, SUA1000X219, SUA1000X93, SUA1000XL, SUA1000XLX558, SUA1500I, SUA1500IX38, SUA1500R2X106, SUA1500R2X122, SUA1500R2X138, SUA1500R2X176, SUA1500R2X180, SUA1500R2X93, SUA1500RM2U, SUA1500RMJ2U, SUA1500RMJ2UB, SUA1500RMUS, SUA1500US, SUA1500X114, SUA1500X145, SUA1500X180, SUA1500X219, SUA1500X413, SUA1500X448, SUA1500X93, SUA1500X99, SUA2200, SUA2200J, SUA2200JB, SUA2200R2X106, SUA2200R2X147, SUA2200R2X152, SUA2200R2X180, SUA2200RM2U, SUA2200RMUS, SUA2200RMLX3U, SUA2200US, SUA2200XL, SUA3000, SUA3000J, SUA3000JB, SUA3000R2IX38, SUA3000R2X145, SUA3000R2X180, SUA3000R2X195, SUA3000R2X93, SUA3000RM2U, SUA3000RMJ2U, SUA3000RMJ2UB, SUA3000RMT2U, SUA3000RMUS, SUA3000RMLX3U, SUA3000RMLX3U, SUA3000RMLX3U, SUA3000RMTX136, SUA3000US, SUA3000XL, SUA3000XLT, SUA5000RMT5U, SUA5000T, SUA500J, SUA500JB, SUA750, SUA750I, SUA750IX38, SUA750J, SUA750JB, SUA750R2IX38, SUA750R2X122, SUA750RM2U, SUA750RMI2U, SUA750RMUS, SUA750US, SUA750X93, SUA750XL, SUA750XLX320, TBA500JB

Uninterruptible power supplies "Symmetra" Model(s) MW 1000KW, MW 1000KW-IP, MW 1200KW, MW 1400KW, MW 1600KW, MW 400KW, MW 600KW, MW 800KW, MW 800KW-IP

Uninterruptible power supplies "Symmetra LX Frame" Model(s) SYA12K16PX442, SYA16K16PX441, SYAF16KBXRMT, SYAF16KRMJ, SYAF16KRMT, SYAF16KT, SYAF16KXR3J, SYAF16KXR9T, SYAF8KRMJ, SYAF8KRMT, SYAF8KT

Uninterruptible power supplies "Symmetra PX" Model(s) SYCF40KF, SYCF80KF

Uninterruptible power supplies "Symmetra RM" Model(s) SY12K12RMT, SY4K12RMT, SY4KRMT, SY8K12RMT, SYPF12KT

Uninterruptible power supplies "Symmetra RM Frame" Model(s) FJH4K6RMJ, SYHF6KJ, SYHF6KJ-PSX, SYHF6KT, SYHF6KT-PSX

Uninterruptible power supplies "Symmetra RM Power" Model(s) SYPM2KU

Uninterruptible power supplies Model(s) 0M-E8T, followed by U, M or P, followed by 1125, followed by G, GT or G-US.

2130-1TX, 2130-3TX, 2130-5TX, 2130-7TX, 2130-8TX, 2130-9TX, 2130-R1X, 2130-R3X, 2130-R5X, 2130-R7X, 2130-R8X, 2130-R9X, 32P1681, 32P1682, 350J, 350JB, 350JC, 39Y8872, 39Y8876, 39Y8881, 39Y8885, 39Y8887, 39Y8889, 500JS, 500JSB, 500JSC

72-13, followed by 0 or 1, followed by 101, 102, 103, 104 or 106, followed by 00 thru 99.

72-13, followed by 0 or 1, followed by 108, 114 or 115, followed by 44, 33 or 66, may be followed by alphanumeric characters.

72-130116-44, 72-130116-66, 72-130117*, 72-131117*, 72-160010-00, 72-160010-01, 72-160030-00, 72-160030-01, 72-1605XX-XX, 72-1608XX-XX, 72-1700XX-XX*, 72-1701XX-XX*, 72-1702XX-XX*, 72-1703XX-XX*, 72-171XXX-XX*, 72-17300#-## (0P-9440, 0P-9441), 74P4902, 74P4904, 74P4906, 90P4812, 90P4814, 90P4816, A24R2410HCR

APC Silcon, followed by 10, 15, 20, 30, 40, 60 or 80, followed by KW, followed by 208V or 480V, followed by UPS.

APC Silcon, followed by 60, 80, 120, 160, 240, 320, 400 or 500, followed by KW, followed by 208V or 480V, followed by UPS.

Back-UPS PRO 1000, Back-UPS PRO 1100, Back-UPS PRO 1400, BBK500EX114, BE325 (c), BE350C, BE350R, BE350TW, BE350U, BE350Uxxxx, BE500C, BE500JP, BE500R, BE500TW, BE500U, BE500Uxxxx, BE550R, BE650BB, BE650Rxxxxxxxxxx, BE725BB, BE725JP, BE750BB, BH500NET, BK300, BK300B, BK300C

BK350 or BK500, may be followed by BLK (enclosure is black)and/or TW (markings are also in Chinese).

BK350EIX290, BK400, BK400B, BK400C, BK500M, BK500MB, BK500MC, BK500MUS, BK500MUSB, BK500MUSC, BK650M, BK650MC, BK650MUS, BK650MUSC, BN1050 (b)(c), BN1250 (b)(c), BN600xxxxxxxxxx, BR1000 (b)(c), BR1200 (b)(c), BR1500 (b)(c), BR500 (c), BR800 (c), BR800BLKX509 (c), BR900 (c), BR900X509 (c), BT1000 (b)(c), BT1500 (b)(c), BX1000 (b)(c), BX1200 (b)(c), BX1500 (b)(c), BX800 (c), BX900 (c), CEN-UPS1250 (c), CNB325 (c), CNB325-JP (c), CNB750 (c), CNB950 (c), DL650xxxxxxxxxx, DL725xxxxxxxxxx, DLRTA3000RML3U, DP310 (a), DP3100 (a), DP3120 (a), DP315 (a), DP3160 (a), DP320 (a), DP3220 (a), DP330 (a), DP340 (a), DP360 (a), DP380 (a), ESP014, ESP030, ESP031, ESP040, ESP045, ESP060, ESP090, FJ1500J, FJ1500J-M, FJ1500J-MQ, IBM1000, IBM1000J, IBM1500, IBM1500J, IBM3000XRH2U, IBM3000XRL2U, IBM750, IBM750J, IBMR1000, IBMR1000J, IBMR1500, IBMR1500J, IBMR750, IBMR750J, IS100KG, IS10KG, IS20KG, IS30KG, IS40KG, IS60KG, IS80KG, ISVT10KF (d), ISVT15KF (d), ISVT20KF (d), ISVT30KF (d), ISVTP10KF (d), ISVTP15KF (d), ISVTP20KF (d), ISVTP30KF (d), J10 (b), J15 (b)

MATRIX 3000 or MATRIX 5000, may be followed by W, J, ES or option code X-YY (Y=number).

MTMN 2130-R30, MTMN 2130-R31, RLC1080 (c), S10 (b), S15 (b), S20 (b), S20 (c), SC1000, SC1500

Series 0M-E8T, followed by U,M or P, followed by 1125, 1100, 1000 followed by G,L or S, followed by T or -US.

Smart-UPS v/s 1000, Smart-UPS v/s 1400, SN1000, SUA1000, SUA1000J, SUA1000JB, SUA1500, SUA1500J, SUA1500JB, SUA500XLJ, SUM1500RML2U, SUM3000RML2U, SURT3000XLICH, SURTA2400XLJ, SURTA3000RML3U, SURTA3000RML3U-NC, SURTA3000XL, SURTA3000XLTW, SUVT10KF (d), SUVT15KF (d), SUVT20KF (d), SUVT30KF (d), SUVT30KF (d), SUVTP10KF (d), SUVTP15KF (d), SUVTP20KF (d), SUVTR20KG (d), SUVTR30KF (d), SUVTR30KG (d), SUVTRT20KF (d), SUVTRT30KF (d)

SY, may be followed by any letter, followed by 400K400G, 600K600G, 800K800G, 1000K1000G, 1200K1200G, 1400K1400G or 1600K1600G.

SYA1500RM2U, SYA3000RM2U, SYMINIF, SYMINIF-PD Symmetra Power Array, SYMINIFJ, SYMSTRF, SYMSTRF-PD, SYMSTRFJ

Uninterruptible power supplies "Smart-UPS Model(s) SMT750C, SMT750RM2UC

Uninterruptible power supplies, distributions and bypass "InfraStruXure 20kW All-In-One, Symmetra PX" Model(s) ISX-20KF

Uninterruptible power supplies, extended run frames "Symmetra PX" Model(s) SYCF8BF, SYCFXR8

UPS accessories "XR Battery Frame" Model(s) SYBFXR3RMJ, SYBFXR9RM

UPS accessories Model(s) 72-1740##-##, HTBP5000RMT2U, SBP10KRMT4U, SBP16KP, SBP16KPX474, SBP16KPX518, SBP16KRMP4U, SBP16KRMP4U-HW, SBP16KT, SBP3000, SBP3000RM2U, SBP5000RMT2U, SBP6KRMT2U, SL-ISE, SYMWSU, SYMWSU2

UPS conversion kits Model(s) 81-165068-00

UPS equipment cabinets Model(s) 72-1315-0

UPS power distribution units, for use only with MATRIX Series UPS equipment Model(s) MXA100*-MXA199*

UPS solid state external bypass switches Model(s) 50, followed by W or X, followed by A to Z, followed by five numbers or letters.

72-13, followed by 0 or 1, followed by 111, 112 or 113, may be followed by numbers and letters.

BK350EIXXXXX, BK350XXXXXXX, MW SSW1000 B, MW SSW1000 T

MW SSW2000, 3000 or 4000, followed by T or B, may be followed by X489.

UPS transformer cabinets Model(s) G35TXFM10K30L, QDLO41312, QRMI33746, QRMI44222, QRMI48890, QWWA14329

Investigated to ANSI/UL 1778 (Fourth Edition)

Accessories battery breakers/junction cabinets Model(s) Battery Breaker Enclosure

Accessories, external batteries Model(s) DLRT192RMBP, DLRT192RMBP2, DLX120RMBPJ2U, HTX120RMBPJ2U, SMX120BP, SMX120RMBP2U, SMX120RMBPJ2U, SRT192BP, SRT192RMBP

Accessories, remote battery cabinets Model(s) SRT96BP

Accessory, Transformer Cabinet Model(s) Model GVMTF225KGF

Battery breaker boxes "Galaxy VM " Model(s) 180 kVA/168 kW, 225 kVA/203 kW

Battery cabinets "Evolution S" Model(s) EXB 1250/1750 RT 2U, EXB 2500/3000 RT 2U, EXB 2500/3000 RT 3U

Battery cabinets Model(s) SYCFXR48

Battery packs Model(s) SURT192SR2XLBF

Maintenance bypass cabinets "Symmetra PX " Model(s) PDPM100

Remote battery supply cabinets "Galaxy VM " Model(s) Modular Battery Cabinet, Narrow, Modular Battery Cabinet, Wide, classical battery cabinet

Remote battery supply cabinets Model(s) SYCFXR9, Wide 225 kVA/203 kW

System bypass cabinets "Galaxy VM" Model(s) GVMSBC675KG

System bypass cabinets "Galaxy VM " Model(s) GVMSBC450KG, GVMSBCLB675KG

Uninterruptible power supplies "Galaxy VM" Model(s) 160 kVA, 180 kVA, 225 kVA

Uninterruptible power supplies "Symmetra PX " Model(s) 100 kW, 250KVA (d), 500KVA (d)

Uninterruptible power supplies Model(s) BE750G, BE750GX782, DLRT5KRMXLT, DLRT8KRMXLT, DLT1200RMJ1U, DLX3000RMLVJ2U, FJM1200RMJ1U, FJM1200RMJ1U-M, FJM1200RMJ1U-MQ, FJM1200RMJ1UQ, FJX3000RMLV2U, FJX3000RMLV2UQ, HTM1200RMJ1U, HTX3000RMHV2U, HTX3000RMLV2U, HTX3000RMLV2U-M, NMM1200RMJ1U, NMX3000RMLV2U, NMX3000RMLV2U-M, SMT1200RMJ1U, SMT1500RM1U, SMX1000 (b), SMX1500RM2U (b), SMX1500RM2UNC (b), SMX2000LV, SMX2000LVNC, SMX2000RMLV2U, SMX2000RMLV2UNC, SMX2200RMHV2U, SMX2200RMLV2U, SMX3000HVT, SMX3000LV, SMX3000LVNC, SMX3000RMHV2U, SMX3000RMHV2UNC, SMX3000RMJ2U, SMX3000RMLV2U, SMX3000RMLV2UNC, SMX750 (b), SRT10KRMXLT, SRT10KRMXLT-IEC, SRT10KXLT, SRT10KXLT-IEC, SRT3000RMXLT, SRT3000RMXLT-IEC, SRT3000RMXLT-NC, SRT3000RMXLW-IEC, SRT3000RMXLW-NC, SRT3000XLT, SRT3000XLT-IEC, SRT3000XLW-IEC, SRT5KRMXLT, SRT5KRMXLT-IEC, SRT5KRMXLW-HW, SRT5KXLT, SRT5KXLT-IEC, SRT6KRMXLT, SRT6KRMXLT-IEC, SRT6KXLT, SRT6KXLT-IEC, SRT8KRMXLT, SRT8KRMXLT-IEC, SRT8KXLT, SRT8KXLT-IEC, SURT5KSR3UXIX438, TDM3000R2XLI

UPS accessories, maintenance bypass panel (MBP) Model(s) QSBPPX-QMLE916-xxx (f)

Investigated to ANSI/UL 1778 (Fifth Edition)

Distribution cabinets Model(s) UNC5-10600-XXX (g), UNC5-10601-XXX (g), UNC5-10602-XXX (g)

Transformer Cabinet Model(s) UNC5-10703xxx, UNC5-10746xxx, UNC5-10747, UNC5-10748, UNC5-10749xxx, UNC5-10750xxx, UNC5-10751xxx, UNC5-10752xxx

- Where # indicates number.

(a) - May be followed by two alpha characters or a dash and two alpha characters.

(b) - May be followed by BLK denotes that the enclosure is black.

(c) - May be followed by up ten alphanumeric, "-" or blank.

(d) - May be followed by up to ten alpha characters or a dash and up to nine alpha characters.

(e) - May be followed by up to eleven alpha characters or a dash and up to ten alpha characters.

(f) - where xxx is an optional 1 to 3 digit suffix, with x=0-9

(g) - Where XXX can be any number.

* - Followed by numbers and letters.

+ - Where X represents alphanumeric character.

[Click here to view the Colombia Market Access Certification](#)

Last Updated on 2016-05-13

[Questions?](#)

[Print this page](#)

[Terms of Use](#)

[Page Top](#)

© 2016 UL LLC

The appearance of a company's name or product in this database does not in itself assure that products so identified have been manufactured under UL's Follow-Up Service. Only those products bearing the UL Mark should be considered to be Certified and covered under UL's Follow-Up Service. Always look for the Mark on the product.

UL permits the reproduction of the material contained in the Online Certification Directory subject to the following conditions: 1. The Guide Information, Assemblies, Constructions, Designs, Systems, and/or Certifications (files) must be presented in their entirety and in a non-misleading manner, without any manipulation of the data (or drawings). 2. The statement "Reprinted from the Online Certifications Directory with permission from UL" must appear adjacent to the extracted material. In addition, the reprinted material must include a copyright notice in the following format: "© 2016 UL LLC".