



How should the AR7701 be oriented for installation?

The AR7701 is intended to be a universal bracket that can be installed in either orientation depending on which fits the installation best.

THIS

or

THIS



When installing the bracket in this orientation the castors must be removed.