

NetShelter SX Castor Removal Instructions

The NetShelter SX castors can be removed.

Tools required: socket wrench, 10mm socket.

- Simply remove the four M6 serrated flange hex nuts that hold the castors in place.
- When reattaching the castors please reuse the M6 serrated flange nuts and torque them to 70-75 IN-LBS (7.9 – 8.5 N-m)

