

How to Permanently Lock the NetShelter SX Side Panel

ILLUSTRATION 1

- 1) Start with the side latch in the LOCKED position.
- 2) Using a Phillips screwdriver remove the screw and lock washer on the rear of the side latch.
- 3) Remove the lock cylinder from the front of the side latch.




ILLUSTRATION 2

- 4) Turn the lock cylinder 180 degrees and re-insert into the side latch.
- 5) Reattach the screw to the rear of the side latch. Keep the plastic lock washer facing the same direction as it originally came off.

