XUSL4E light curtain - cabling

- How to replace the obsolete XUSLP by the new XUSL4E SLC by using the old cabling
- Old & new parts use the same M12 5or8-pin connectors and the same conductor number (difference = colour)
- Wires need to be changed on the 24Vdc power supply




Obsolete XUSLP type 4 light curtain

Cabling details in the stand-alone solution

Figure 15: XUSLPZ/XUSLPB with Force-Guided Relays

XUSLPZ Receiver/XUSLPB Transceiver



Obsolete XUSLP type 4 light curtain


XSZPCR pre-wired connector pin-out

Electrical Connections

The XUSLPB system only has a transceiver. It connects the same as the XUSLPZ receiver.

Figure 13: Receiver/Transceiver Connections (M12, 8-Pin)






M12

Receiver Terminal Block

NOTE: As viewed from the M12 connection on the endcap of the receiver/transceiver.

Receiver

Pre-wired connector of receiver (XUS LPZ) and pre-wired connector of transmitter-receiver (XUS LPB)



Pin-Wire Color	Terminal Block#	Description
1-White	6	+24 Vdc
2-Brown	7	0 Vdc
3-Green	8	Earth ground
4–Yellow	2	OSSD 2
5-Gray	4	Start
6-Pink	5	EDM/MPCE
7-Blue	3	Auxiliary Output
8-Red	1	OSSD 1


NOTE: OSSD = Output Safety Switching Device



Obsolete XUSLP type 4 light curtain

XSZPCT pre-wired connector pin-out


Figure 14: Transmitter Connections (M12, 5-Pin)



XUS LPZ/LPB

Transmitter

Pre-wired connector of transmitter (XUS LPZ)



NOTE: As viewed from the M12 connection on the endcap of the transmitter.


Pin-Wire Color	Terminal Block#	Description
3 Blue	4	MTS
4 Black	5	MTS Return
2 White	6	24 Vdc
1 Brown	7	0 Vdc
5 Green	8	Earth

NOTE: MTS = Machine test signal.




指配

Cabling details in the stand-alone solution



- Pre-wired connector pin-out
 - Receiver connections

This figure describes the receiver connections:



NOTE: As viewed from the M12 connection on the endcap of the receiver.


This table describes the pin-wire connections for the M12, 8-Pin, master primary connector, or single pair models:

M12, 8-PIN Single pair models (XUSL4E or XUSL2E) or Master models primary connector (XUSL4E)			
Pin Number	Pin-Wire Color	Description	
1	White	OSSD1	
2	Brown	+24 Vdc	
3	Green	OSSD2	
4	Yellow	Configuration_A	
5	Grey	K1_K2 Feeback/Restart	
6	Pink	Configuration_B	
7	Blue	0 Vdc	
8	Yellow/Green (or Red)	FE	

| 10算

- Pre-wired connector pin-out
 - Transmitter connections

This figure describes the transmitter connections:



NOTE: As viewed from the M12 connection on the endcap of the receiver.


This table describes the pin-wire connections for the M12, 5-Pin transmitter connections:

M12, 5-Pin (XUSL2E and XUSL4E)			
Pin Number	Pin-Wire Color	Description	
1	Brown	+24 Vdc	
2	Black/White	Configuration_0 or Master/Slave_A	
3	Blue	0 Vdc	
4	Black	Configuration_1 or Master/Slave_B	
5	Yellow/Green (or Red)	FE	

- Tioti Heat
- Correspondance table to connect the XUSLP cabling to the new XUSL4E
 - Receiver M12 8-pin


Pin nb	Old pre-wired connector	New pre-wired connector	
1	Brown BN	White	
2	White WH	Brown	
3	Blue BU Green		
4	Pink PK	Yellow	
5	Grey GY Grey		
6	Yellow YE	Pink	
7	Green GN	Blue	
8	Red RD	Red	

Receiver Connections (M12, 8-Pin)



NOTE: As viewed from the M12 connection on the pre-wired connector

- Correspondance table to connect the XUSLP cabling to the new XUSL4E
 - Transmitter Connections (M12, 5-Pin)
 - Transmitter M12 5-pin




NOTE: As viewed from the M12 connection on the pre-wired connector

Pin nb	Old pre-wired connector	New pre-wired connector
1	White WH	Brown
2	Brown BN	Black/White
3	Black BK	Blue
4	Blue BU	Black
5	Green GN	Yellow/Green or Red

TIT!

- Wire connection changing on the 24Vdc power supply
 - M12 8-pin connector (receiver)

Receiver Connections (M12, 8-Pin)




NOTE: As viewed from the M12 connection on the pre-wired connector

Pin nb	Old pre-wired	Old connection	New connection
PIIIIID	connector (color)	Old Confidential	New Connection
1	Brown BN	0V	K2 load - 0V
2	White WH	24V	No changing
3	Blue BU	PLC input	K1 load - 0V
4	Pink PK	Feedback – 0V	Feedback - 24V
5	Grey GY	Start – 0V	0V
6	Yellow YE	K2 load - 0V	24V
7	Green GN	GND (FE connection)	0V
8	Red RD	K1 load - 0V	GND (FE connection)



- Wire connection changing on the 24Vdc power supply
 - M12 5-pin connector (transmitter)

Transmitter Connections (M12, 5-Pin)



NOTE: As viewed from the M12 connection on the pre-wired connector

Pin nb	Old pre-wired connector (color)	Old connection	New connection
1	White WH	24V	No changing
2	Brown BN	0V	24V
3	Black BK	Test loop	0V
4	Blue BU	Test loop	0V
5	Green GN	GND (FE connection)	No changing