


Enabling or If they want to temporarily disable the IEEE 802.15.4 can be done from webpage through this window:



Enabling or If they want to temporarily disable the Wi-Fi can be done from webpage through this window

