

Symmetra[®] PX

10 - 40 kW, 208 V

Basic Operation Guide

APC

IMPORTANT SAFETY INSTRUCTIONS

SAVE THESE INSTRUCTIONS

This guide contains important instructions for the UPS that should be followed during the





(ŮĽ

Figure 2

After the Symmetra has been electrically wired, it is ready for start-up. This guide will allow you to quickly start up the UPS. It contains information on Safety, System Components, Securing the UPS, Module Installation, Network Cable Installation, Start-Up Procedure, and Basic Troubleshooting. For advanced operation please refer to the Product Manual CD shipped with the unit, or to our website www.apc.com.

Intelligence Modules (2)

> Power Module Bays

Module



Battery 1 Init



Introduction

PowerView Display Battery Module Bays System Power Supply Cards DC Disconnect Switch System Enable Switch Smart Slots (2) Web Management Card Switch Gear Monitor Card Input / Output Chassis System ID Card Display / Computer Battery Monitor Card Interface Card **Documentation Storage Tray** Static Switch Module XR Comm Card Figure 5

System Components





Fron	n the Powe	rView I	Display:			
0	<pre>> Control > Status > Setup > Accessories</pre>	Logging Display Diags Help		2	Web/SNMP Mngmnt Card Network Setup View Network Setup	Ð
I	Top-Level	Menu			Accessories Menu	
3	IP>>159.21 Mask>>255.25 Gway>>159.21 Accept	5.086.082 5.255.000 5.086.001 changes		4	IP>>159.215.086 Mask>>255.255.255.000 Gway>>159.215.086.001 ◆ Accept changes	Ð
	Network Set-	up Screen	-		Network Set-up Screen	Figure 1

Note: If a Default Gateway is unavailable, use the IP address of a computer located on the same subnet as the Management Card that is usually running. The Management Card uses the Default Gateway to test the network when traffic is very light. See "Watchdog Features" in the "Introduction" of the Network Management Card User's Guide CD (.\doc\usrguide.pdf) for more information about the watchdog role of the Default Gateway. The Management Card User's Guide CD is located in the documentation tray.

Basic Troubleshooting

This Basic Troubleshooting section will allow you to solve most problems using the PowerView display.

> If a problem is reported, ensure that the system component in question is correctly installed (refer to Module Replacement, Section 8).

General Status

Display Message	Meaning	Corrective Action
Input Freq outside config- ured range	The input frequency to the Symmetra is outside the configured range. The out- put frequency will not synchronize with the input frequency. Normal bypass is not available.	Option #1: Improve the frequency of the incoming voltage. Option #2: Widen range of acceptable incoming frequency with the Power- View. (Path: Startup-Setup- Output Freq Select. Option #3: Proceed with startup. Normal bypass is not available.
AC adequate for UPS but not for bypass	The Symmetra will func- tion online with the input voltage, but in the event that bypass is required, the input voltage is not adequate to power the load equipment.	Option #1 : Improve the incoming voltage. Option #2 : Proceed with startup. Normal bypass is not available.

Display Message	Meaning	Corrective Action
Redundancy has been lost	The Symmetra no longer detects redundant power modules. Either power module(s) have failed, or the load has increased.	Option #1: If possible, install additional power modules. Option #2: Decrease the load Option #3: Disable the redundancy alarm by setting redundancy to zero (Path: Startup-Setup- Alarms-Redundancy-selec zero)
Runtime is below alarm threshold	The predicted runtime is lower than the user-speci- fied minimum runtime alarm threshold. Either the battery capacity has decreased, or the load has increased.	 Option #1: Allow the battery modules to recharge. Option #2: If possible, increase the number of battery modules. Option #3: Decrease the load. Option #4: Use the display to decrease the minimum runtime alarm threshold (Path: Startup-Setup-Alarms-Runtime-select).

Bypass

Display Message	Meaning	Corrective Action
Bypass is not in range (either freq or voltage)	The frequency and/or voltage is out of acceptable range for bypass. This message occurs when the Symmetra is online, and indicates that the bypass mode may not be available if required.	Option #1: Decrease the sensitivity to input frequency. (Path: Startup- Setup-OutputFreq-select). Option #2: Correct input voltage to provide acceptable voltage and/or frequency.

General Fault

Display Message	Meaning	Corrective Action
Need Bat Replacement	One or more battery modules are in need of replacement	Refer to Module Replace- ment Section for procedures.

The Redundan gence Module

If the problem persists, note UPS model #, serial #, and date purchased before calling Tech Support at: 1 (800) 800 4272.

For advanced configuration, refer to Product Manual CD (shipped with unit) and/or our website @ www.apc.com.





Replacing Intelligence Modules

Loosen the 2 Phillips screws at both sides of the module (top of module). Push down the small tab on the left side of the module to de-activate the module. Using the handle, carefully pull out the module. Reverse procedures for installation. Display shows message saying it has registered the new module.



t Intelli- is in control	The main intelligence module has failed, and the redundant intelligence module is functioning as the primary intelligence module.	Replace the intelligence module. Refer to Module Replacement Section for procedures.
-----------------------------	--	---

Modular Component Replacement

WARNING!

Only trained persons familiar with the construction and operation of the equipment, and the electrical and mechanical hazards involved, may install and remove system components.

One intelligence module can be replaced without interrupting power to the connected equipment provided another functioning intelligence module is installed.







Replacing Power Modules



To de-activate the module, turn Locking Latch (with arrow pointing towards the module) counter-clockwise until it points downwards.

Unscrew spring-activated knobs on both sides of the module until they pop out. Standing on either side of the UPS, 2 people can now pull the module almost free of the UPS (the lock mechanism prevents the module from being pulled clear of the UPS). With the module still resting in the UPS, release the lock by pushing the black plastic tab on either side of the module.

Pull out the module. Reverse procedures for installation. Display shows message saying it has registered the new module.

Power Module will not start unless Locking Latch is engaged.

Replacing Battery Units



Holding the handle, gently push the Battery Unit upwards and pull it halfway out of the UPS. A lock mechanism prevents it from being pulled all the way out. To release it from the lock mechanism, gently push the battery upwards again and pull out while supporting the battery with the other hand.

2

Reverse procedure for installation. Display shows message saying it has registered the new unit.



Replacing Cards

Loosen the 2 Phillips screws at both sides of the card. Carefully pull out the card. Reverse procedures for installation. Display shows message saying it has registered the new card.

Replacement Parts and Numbers

No

SYCF40KF

SYPM10KF

SYBT4

SYBTU1

SYMIM4

SYCSPS

SYSSW40KF

Part

Card

Display and Computer

Battery Monitoring Card

Switch Gear Monitoring

XR Communication Card

XR Battery Enclosure only

Interface Card

System ID Card

Web Card SNMP



No

SYCDCI

SYCBTMON

SYCSGMON

SYCSYSID

SYCXRCOM

AP9606 Web/

Management

Slot Card

SYCFXR8





Figure 26

3	Disc ALI Unit or pu Disc
Figur	e 27

Figure 28



Part

40kW Enclosure Only

10kW Power Module

Intelligence Module

Switch Module

Symmetra 3-Phase Static

System Power Supply Card

Battery Module

Battery Unit

CAUTION!

A battery can present a risk of electric shock and high short-circuit current. The following precautions should be observed when working on batteries:

- Remove watches, rings or other metal objects
- Use tools with insulated handles
- Wear rubber gloves and boots
- Do not lay tools or metal parts on top of batteries

When replacing batteries, replace with same number and type as installed. For customer-supplied external batteries, see manufacturer's installation and safety instructions.

2

Figure 22



Appendix A: Total Power OFF Procedure

