This document provides mounting features and key dimensions of the rack rails used for mounting many Dell enterprise systems and peripheral devices in a rack enclosure.

Dell | Rail Solutions Engineering



Dell	<b>Enterprise</b>	Systems	Rail	Szina	and	Rack	Compatil	hility	Matrix
Dell	LILEI DI 13C	Systems	ıvalı	G ZIII U	anu	i vacr	Willipatii	JIIILV	IVIALITA

This document is for informational purposes only and may contain typographical errors and technical inaccuracies. The content is provided as is, without express or implied warranties of any kind.

©2014 Dell Inc. All rights reserved. Reproduction of this material in any manner whatsoever without the express written permission of Dell Inc. is strictly forbidden.

Dell, the DELL logo, PowerEdge, PowerVault, ReadyRails, RapidRails, VersaRails, EqualLogic and Compellent are trademarks of Dell Inc. Other trademarks and trade names may be used in this document to refer to either the entities claiming the marks and names or their products. Dell Inc. disclaims any proprietary interest in trademarks and trade names other than its own.

August 2014 | Version 2.7

## Contents

Introduction	n	1
Considerati	ons	1
Mounting in	terface	2
Rail types		3
Backward c	ompatibility	4
Definitions.		4
Figures		
Figure 1.	Top view of right front EIA mounting flange	1
Figure 2.	System offset for round-hole racks.	2
Figure 3.	ReadyRails II self-adjusting mechanism	3
Tables		
Table 1.	Dell server rails compatibility chart	4
Table 2.	Dell rail sizing matrix	6
Table 3.	Dell rack compatibility matrix	2

### Introduction

This document provides information on the mounting features and key dimensions of the rack rails used for mounting many Dell™enterprise systems and peripheral devices in a rack enclosure. This document also provides a compatibility summary for all generations of Dell racks as well as some common third-party racks. Note that the product list is not all-inclusive, but updates will be made as needed.

The dimensions provided in this document are for reference only. Some minor deviations due to manufacturing tolerances and variances may be expected. All Dell rail kits are designed for compliance with the EIA-310-E specification for 19-inch racks.

#### Considerations

Please pay attention to the footnotes indicated in the tables, because they provide important information on using the rails in different racks and circumstances.

Dell rail kits are designed to be installed in Dell rack enclosures, which have square mounting holes for tool-less installation, and may also be compatible with racks from other vendors, including square-hole, round-hole, and threaded-hole racks. Note that Dell rail kits with a Rail Identifier code have been designed to be compliant with the Server System Infrastructure (SSI) Specification for Computer Server Cabinet Enclosures & Racks, which specifies a minimum offset distance for return flanges on the rack mounting flanges to allow sufficient room for mounting the rail kits, as indicated in Figure 1. For more information about the Server System Infrastructure (SSI) Specification for Computer Server Cabinet Enclosures & Racks, see the SSI Forum at siforum.org.

8.5mm [0.335"]
MINIMUM

16.7mm [0.658"]
MINIMUM

KEEP-OUT ZONE FOR RAIL MOUNTING

INSTALLED
SERVER

RETURN FLANGE

RETURN FLANGE

Figure 1. Top view of right front EIA mounting flange

1

Some third-party racks may not meet this requirement, and although Dell has made extensive efforts to accommodate as many third-party racks as possible, it is not feasible to provide a solution for every circumstance.

# Mounting interface

The ReadyRails™II mounting interface supports tool-less installation in 4-post square-hole and unthreaded round-hole racks as well as native support for tooled installation in threaded-hole racks. Note that installing this mounting interface in a square-hole rack allows the bracket to be placed flush against the mounting post, while installation in a round-hole rack results in a slight offset of approximately 6 mm from the mounting post; refer to Figure 2 to see how the system bezel profile appears in this deployment.

ReadyRails II in Square-Hole Rack

ReadyRails II in Round-Hole Rack

The original **ReadyRails** mounting interface is used for both static and sliding rails, and supports tool-less installation in 4-post square-hole and unthreaded round-hole racks. Static ReadyRails kits also support tooled installation in threaded-hole racks and 2-post racks. In order to install sliding ReadyRails kits into a threaded-hole rack, adapter brackets are required. 1U and 2U adapter bracket kits are available that support systems ranging from 1U to 5U in height.

The adapter bracket kits include six brackets to accommodate different rail lengths, plus four sets of custom screws in 10-32, 12-24, M5 and M6 thread sizes. The design of the brackets has been optimized to limit the forward shift of the system in the rack to only 17.3 mm. Depending on the depth of the rack used and the position of the mounting rails within the rack, it may be necessary to remove the system's bezel in order to close the front door of the rack. For the front door to close with the system bezel installed, you need a minimum clearance of 58 mm between the back surface of the door panel and the front face of the  $\Box$ A flange.

The **RapidRails**™mounting interface supports tool-less installation in 4-post square-hole racks only, while the **VersaRails**™mounting interface supports tooled installation in 4-post square-hole and unthreaded round-hole racks. Mounting the VersaRails in threaded-hole racks is not recommended and is not supported by Dell.

The **generic** mounting interface provides flanges with clearance holes for screws and supports tooled installation in all types of racks including threaded-hole racks with appropriate hardware (screws are not included in kits with a rail identifier code). The generic interface can be incorporated on the same rail kit with a tool-less mounting solution, and usually requires the reconfiguration of the rail to remove or reorient the mounting brackets. Instructions are provided in the rail kit documentation shipped with the rails.

## Rail types

Sliding rails allow you to fully extend the system out of the rack for service. To help manage the numerous cables associated with rack-mounted servers, use the optional cable management arm (CMA) with the sliding rails that you can attach on either the right or left side without tools. Note that using a CMA with a deeper system may interfere with access to power distribution units (PDUs) in certain racks. If your configuration does not require CMA support, you can remove the outer CMA mounting brackets from some of the sliding rail kits to reduce the overall length of the rails and eliminate potential interference with rear-mounted PDUs or the rack rear door.

1U and 2U sliding rails have been standardized with a slim drop-in design that holds a wide system chassis to accommodate more features and functions. They also have a self-adjusting mechanism that accommodates different depths of systems, offering compatibility across multiple platform models. Refer to Figure 3 for an illustration of how the self-adjustment works.




Figure 3. ReadyRails II self-adjusting mechanism

**Static rails** do not support the ability to service the system in the rack and are not compatible with the CMA. However, they do offer more flexibility in the types of racks and installations supported.

# Backward compatibility

Some systems may offer backward compatibility with the rail kits from previous-generation systems. This is not always possible, because changes to chassis features, dimensions or weight can prevent older rail kits from being used with newer systems. Please refer to Table 1 for compatibility of Dell 13<sup>th</sup> generation servers with 12<sup>th</sup> generation system rails as well as Dell 12<sup>th</sup> generation servers with 11<sup>th</sup> generation system rails.

Table 1. Dell server rails compatibility chart

13 <sup>th</sup> Generation	Backward compat	ibility with 12 <sup>th</sup> gene	eration rails/CMAs
product	Silding rails	CMA	Static rails
R630	1	1	1
R730/R730xd	<b>✓</b>	<b>✓</b>	✓
T630	X	✓	N/A

2 <sup>th</sup> Generation	Backward compa	atibility with 11 <sup>th</sup> gener	ation rails/CMAs
product	Sliding rails	CMA	Static rails
R320	1	<b>√</b> *	✓
R420	✓	<b>√</b> *	1
R520	✓	<b>√</b> *	✓
R620	X	X	X
R720/R720xd	X	X	X
R820	X	X	N/A
R920	X	X	N/A
T320	✓ (T610)	✓ (T610)	N/A
T420	✓ (T610)	✓ (T610)	N/A
T620	<b>✓</b>	✓	N/A

<sup>✓ -</sup> Compatible X – Not

### Definitions

Rail identifier is a two-character code used on some rail kits to indicate compatibility between rails and systems.

Mounting interface describes the type of rail bracket design used for mounting the rail in the rack.

Rail adjustability range represents the allowable distance between the outside-facing surfaces of the front and rear mounting posts of the rack. This does not include the portion of the rail kit that may extend beyond the mounting posts.

X-Not compatible

<sup>\*</sup>Only with the previous generation sliding rails

**Rail depth** represents the minimum depth of the rail as measured from the rack front mounting posts when the rail rear bracket is positioned all the way forward. The rail may extend beyond the rear bracket, particularly for sliding rail kits to support CMA attachment.

**SRB** (Strain Relief Bar) is offered on select systems as an optional method for managing cables at the rear of the system due to the potential of a cable bundle size that exceeds the capacity of the CMA. The rail depth with a SRB is significantly less than that of a CMA, in many cases enabling fitment of the rails in less deep racks.

Table 2. Dell rail sizing matrix

							Rack ty	/pes supp	orted			Rail ad	justabil	ity rang	e (mm)		Rail dep	oth (mm)
		Product	Rail identifier	Mounting interface	Rail type		4-Post		2-	Post	Squ	uare	Ro	und	Thre	aded	without	with
						Square	Round	Thread	Flush	Center	Min	Max	Min	Max	Min	Max	CMA/SRB	CMA(SRB)
		R320/R420 R620 (8-HDD)	A7	ReadyRails II	Sliding	1	<b>✓</b>	√a,c,d	X	X	631	868	617	861	631	883	720 <sup>b</sup>	845
		R630 (8-HDD)	A8	ReadyRails	Static	1	1	√a,c	√a,c	<b>√</b> c	608	879	594	872	604	890	622	•
		R620 (10-HDD)	A7	ReadyRails II	Sliding	1	1	√a,c,d	X	X	681	868	667	861	681	883	770 <sup>5</sup>	895
		R630(10/24-HDD)	A8	ReadyRails	Static	1	1	√a,c	√a,c	√c	608	879	594	872	604	890	622	
		R520	<b>B</b> 6	ReadyRails II	Sliding	~	1	√a,c,d	x	x	631	868	617	861	631	883	714 <sup>b</sup>	845
		R720/R720xd R730/R730xd	B4	ReadyRails	Static	~	~	√a,c	√a,c	√c	608	879	594	872	608	890	622	
			<b>B</b> 6	ReadyRails II	Sliding	<b>V</b>	~	√a,c,d	X	x	676	868	662	861	676	883	759 <sup>b</sup>	890
		R820	B4	ReadyRails	Static	<b>✓</b>	<b>✓</b>	√a,c	√a,c	<b>√</b> c	608	879	594	872	608	890	622	-
		R920	<b>B</b> 8	ReadyRails II	Sliding	<b>✓</b>	<b>✓</b>	√a,c,d	x	X	686	883	674	876	686	898	794 <sup>b</sup>	883(834)
83	PowerEdge™	T630	C4	ReadyRails II	Siding	<b>V</b>	<b>✓</b>	√a,c,d	X	х	686	756	672	749	686	771	756	840
SERVERS	verE	T320/ T420/ T620	C2	ReadyRails II	Sliding	1	<b>✓</b>	√a,c,d	x	х	686	756	672	749	686	771	760	840
o,	Po	VRTX	<b>C</b> 3	ReadyRails II	Sliding	1	<b>✓</b>	√a,c,d	х	x	608	915	594	908	608	930	756	845
			A4	ReadyRails	Static	1	~	√a,c	√a,c	√c	608	879	594	872	604	890	622	-
		R210/R210 II	A6	ReadyRails	Static	~	~	√a,c	√a,c	<b>√</b> c	508 <sup>j</sup>	751	494	744	519 <sup>j</sup>	762	515 <sup>j</sup> 376 <sup>k</sup>	
		P040/P440/P445	A3	ReadyRails	Siding	~	~	√e	x	X	686	883	672	876	651	897	714 <sup>b</sup>	835
		R310/R410/R415	A4	ReadyRails	Static	1	<b>✓</b>	√a,c	√a,c	<b>√</b> c	608	879	594	872	604	890	622	•
		DE40/DE45	<b>B</b> 3	ReadyRails	Siding	<b>✓</b>	1	√f	х	х	686	883	672	876	651	897	714 <sup>b</sup>	845
		R510/R515	B4	ReadyRails	Static	<b>V</b>	<b>*</b>	√a,c	√a,c	√c	608	879	594	872	608	890	622	.=:
			A1	ReadyRails	Sliding	1	1	√e	x	х	692	756	678	749	657	770	768 <sup>b</sup>	887
		R610	A2	ReadyRails	Static	1	1	√a,c	√a,c	√c.	588	828	574	821	592	846	608	-

		Dell Liliterprise Sys						ypes supp	orted	1		Rail ad	justabil	ity rang	e (mm)		Rail dep	th (mm)
		Product	Rail identifier	Mounting interface	Rail type		4-Post		2-	Post	Squ	iare	Ro	und	Thre	aded	without	with
						Square	Round	Thread	Flush	Center	Min	Max	Min	Max	Min	Max	CMA/SRB	CMA(SRB)
		R710	B1	ReadyRails	Siding	~	~	✓1	X	X	692	756	678	749	657	770	751	840
		N/10	A2	ReadyRails	Static	1	1	√a,c	√a,c	√c	588	828	574	821	592	846	608	-
		R715/R810 R815/R910	B2	ReadyRails	Sliding	<b>*</b>	~	√f	X	X	686	883	672	876	651	897	755 <sup>b</sup>	883
		T610/T710	C1	ReadyRails	Sliding	<b>✓</b>	~	<b>√</b> f	X	X	692	756	678	749	657	770	760	840
		M1000e		RapidRails	Static	1	X	X	X	X	712	755		-	-	-	703	
		WIOODE	•	VersaRails	Static	1	~	X	X	X	706	755	706	755	-	-	703	-
		C1100	-	Tool-less	Sliding	<b>✓</b>	<b>✓</b>	X	X	X	665	950	665	950	-	-	685	-
	ပ	<b>C</b> 2100	•	Generic	Sliding	<b>✓</b>	<b>✓</b>	<b>✓</b>	X	X	664	1110	664	1110	664	1110	720	•
		C410x	•	Versa-style	Siding	1	1	X	X	X	737	972	737	972		-	734	
	PowerEdge	C5xxx		Tool-less	Static	~	~	X	X	X	708	947	708	947		•	705	•
		C610x/C6145 C6220	: <b>-</b> :	Tool-less	Static	<b>✓</b>	~	X	X	X	615	925	615	925	8.5		606	( <b></b> )
		C8000	-	Tool-less	Static	1	~	X	X	x	708	946	708	946	12	-	713	-
		1081AD/2161AD 1082DS/2162DS 4322DS	<b>A</b> 5	ReadyRails	Static	1	1	~	1	<b>~</b>	470	770	456	763	462	794	480	
ES	KVM	180AS/2160AS 2161DS/2161DS-2 4161DS	•	Generic	Static	<b>~</b>	<b>✓</b>	<b>~</b>	~	x	686	737	686	737	686	737	686	
SWITCHES		2321DS		Generic	Static	<b>✓</b>	~	<b>✓</b>	1	X	533	737	533	737	533	737	533	s <b>.</b>
8	king	PC8132/PC8132F PC8164/PC8164F	<b>A</b> 5	ReadyRails	Static	1	1	<b>~</b>	1	1	470	770	456	763	462	794	480	-
	Networking	S4820T/S6000	<b>A</b> 5	ReadyRails	Static	~	~	1	1	~	470	770	456	763	462	794	480	-
	Š	\$5000	•	Generic	Static	~	~	<b>~</b>	X	X	680	830	680	830	680	830	680	•

1

		Dell' Eliterprise Oys	1					/pes supp	orted	1		Rail ad	justabil	ity rang	e (mm)	i i	Rail dep	oth (mm)
		Product	Rail identifier	Mounting interface	Rail type		4-Post		2-	Post	Squ	are	Ro	und	Thre	aded	without	with
						Square	Round	Thread	Flush	Center	Min	Max	Min	Max	Min	Max	CMA/SRB	CMA(SRB)
	WORKS ATTOMS	T7600/T7610	C2	ReadyRails II	Sliding	~	<b>✓</b>	√a,c,d	x	x	686	756	672	749	686	771	760	840
	WORKS	R5500/R7610	<b>B</b> 2	ReadyRails	Sliding	<b>~</b>	1	√f	x	x	686	883	672	876	651	897	755 <sup>b</sup>	883
		FPM185 (without KVM)	•	ReadyRails II	Sliding	~	~	√a,c,d	x	X	604	900	590	893	604	914	8	611
	MININ	FPM185 (with KVM)	•	ReadyRails II	Sliding	~	~	√a,c,d	x	X	705	900	691	893	705	914	ä	715
		17FP		RapidRails	Siding	~	X	X	X	X	714	755	-	-	:: <b>-</b> :		-	787
		W.F.		VersaRails	Siding	~	1	X	X	X	709	755	709	755	S=	-		787
	S <sub>D</sub>	Dell Rack Mount UPS Family	<b>B</b> 5	ReadyRails	Static	<b>✓</b>	<b>✓</b>	√f	х	x	518	769	504	762	483	783	526	•
	OTHER	1U Fixed Equipment Shelf	A4	ReadyRails	Static	<b>~</b>	<b>√</b>	√a,c	√a,c	√c	608	879	594	872	604	890	622	
		NYOOOANYAOO	A7	ReadyRails II	Siding	~	1	√a,c,d	х	X	631	868	617	861	631	883	720 <sup>b</sup>	845
		NX3300/NX400	A8	ReadyRails	Static	~	1	√a,c	√a,c	√c	608	879	594	872	604	890	622	
			<b>B</b> 6	ReadyRails II	Sliding	~	~	√a,c,d	X	X	631	868	617	861	631	883	714 <sup>b</sup>	845
	TW.	NX3200	B4	ReadyRails	Static	~	~	√a,c	√a,c	√c	608	879	594	872	608	890	622	
STORAGE	Vault		A3	ReadyRails	Siding	1	1	√e	Х	X	686	883	672	876	651	897	714 <sup>b</sup>	835
STO	Power Vault TM	NX3500 Controller	A4	ReadyRails	Static	<b>✓</b>	1	√a,c	√a,c	√c	608	879	594	872	604	890	622	
	Δ.	NX3500 UPS	A4	ReadyRails	Static	~	~	√a,c	√a,c	√c	608	879	594	872	604	890	622	•
			A4	ReadyRails	Static	<b>✓</b>	<b>✓</b>	√a,c	√a,c	√c	608	879	594	872	604	890	622	(-)
		DX6000G	<b>A</b> 6	ReadyRails	Static	~	1	√a,c	√a,c	<b>√</b> c	508°	751	494°	744	519°	762	515 <sup>c</sup> 376 <sup>d</sup>	-

8

						Rack ty	ypes supp	orted			Rail ad	justabil	ity rang	e (mm)		Rail dep	oth (mm)
	Product	Rail identifier	Mounting interface	Rail type		4-Post		2-	Post	Squ	ıare	Ro	und	Thre	aded	without	with
					Square	Round	Thread	Flush	Center	Min	Max	Min	Max	Min	Max	CMA/SRB	CMA(SRB)
	NX300/DX6004S	A3	ReadyRails	Sliding	~	<b>✓</b>	√e	Х	X	686	883	672	876	651	897	714 <sup>b</sup>	835
	NA300/ DA00045	A4	ReadyRails	Static	~	<b>✓</b>	√a,c	√a,c	<b>√</b> c	608	879	594	872	604	890	622	
	NY2000/BYCOO	B1	ReadyRails	Sliding	<b>✓</b>	1	√f	X	х	692	756	678	749	657	770	751	840
	NX3000/DX6000	A2	ReadyRails	Static	1	1	√a,c	√a,c	√c	588	828	574	821	592	846	608	3-3
	NX3100/DL2200	<b>B</b> 3	ReadyRails	Siding	1	~	√f	X	X	686	883	672	876	651	897	714 <sup>b</sup>	845
	DX6012S/DR4000	B4	ReadyRails	Static	<b>V</b>	<b>V</b>	√a,c	√a,c	√c	608	879	594	872	608	890	622	•
	MD3060e/MD3660	•	Versa-style	Static	1	1	x	X	x	611	791	611	791			620	•
		<b>B</b> 9	ReadyRails II	Static	~	<b>✓</b>	√a,c,d	X	х	595	914	581	907	595	929	600	
	MD12xx/32xx/36xx NX36xx		RapidRails	Static	1	x	X	X	X	732	758	-	-		-	729	1.00
	2000	•	VersaRails	Static	1	1	X	X	X	714	758	714	758	•	•	721	(*)
	MD1120	-	RapidRails	Static	<b>*</b>	X	X	X	X	732	759	-	=	: <u>-</u>	12	729	-
	WID1120	•	VersaRails	Static	~	~	X	X	X	714	759	714	759	•	•	721	•
	MD4000/MD2000		RapidRails	Static	~	X	X	X	X	732	758	-	-	. <u></u>		735	
	MD1000/MD3000	-	VersaRails	Static	1	<b>✓</b>	x	X	x	714	758	714	758	-	-	735	1-1
		B7	ReadyRails	Static	1	~	√a,c	√a,c	√c	588	828	574	821	592	846	608	-
	PV114T/PV114X	•	RapidRails	Sliding	<b>V</b>	х	X	X	X	722	750	÷	64 58	-	•	792	870
		•	VersaRails	Sliding	1	1	X	X	X	701	745	701	745	-		792	870
	PV124T	3 <b>-</b> 3	RapidRails	Static	~	X	X	X	X	729	755	-	-	.=		732	ş <b>.</b>
	F V 12-7 1	•	VersaRails	Static	1	1	X	X	X	711	755	711	755	•	•	732	•
Equal Logic TM	FS7500 Controller	A1	ReadyRails	Siding	<b>✓</b>	1	√e	X	x	692	756	678	749	657	770	768 <sup>b</sup>	887
Equal	. c. 300 Controller	A2	ReadyRails	Static	~	~	√a,c	√a,c	<b>√</b> c	588	828	574	821	592	846	608	•

						Rack ty	pes supp	orted			Rail ad	justabil	ity rang	e (mm)		Rail dep	th (mm)
	Product	Rail identifier	Mounting interface	Rail type		4-Post		2-	Post	Squ	iare	Ro	und	Thre	aded	without	with
					Square	Round	Thread	Flush	Center	Min	Max	Min	Max	Min	Max	CMA/SRB	CMA(SRB)
	FS7500 UPS	A4	ReadyRails	Static	~	~	√a,c	√a,c	√c	608	879	594	872	604	890	622	
		<b>B</b> 9	ReadyRails II	Static	1	1	√a,c,d	X	X	595	914	581	907	595	929	600	•
	FS76xx/PS41xx PS61xx	•	RapidRails	Static	~	X	X	X	X	732	758	9	-	700	-	729	*
	FSOTAX	-	VersaRails	Static	1	1	X	X	x	714	758	714	758	-	-	721	-
	PS6500/6510		ReadyRails	Siding	~	~	√a,c	X	x	597	793	583	786	605	817	885	885
	PS4000/6000/6010		Generic	Static	~	√a	√a	x	x	616	914	616	914	616	914	616	*
		<b>B</b> 6	ReadyRails II	Sliding	1	<b>~</b>	√a,c,d	X	Х	631	868	617	861	631	883	714 <sup>b</sup>	845
	SC8000	B4	ReadyRails	Static	~	1	√a,c	√a,c	√c	608	879	594	872	608	890	622	
		<b>B</b> 9	ReadyRails II	Static	1	~	√a,c,d	X	x	595	914	581	907	595	929	600	
Compellent™	SC2xx/FS86xx		RapidRails	Static	~	X	X	X	X	732	758	9			•	729	•
mpell		.=:	VersaRails	Static	<b>✓</b>	~	X	X	x	714	758	714	758	2-	-	721	-
Col	Series 40		Generic	Sliding	1	√9	√0	X	х	669	923	669	923	707 <sup>g</sup>	961 <sup>g</sup>	693	12
Dell	Fibre Channel		Generic	Static <sup>h</sup>	<b>✓</b>	~	<b>✓</b>	X	x	606	910	606	910	606	910	598	
	SAS (new rails)	•	Generic	Static <sup>h</sup>	~	~	X	X	X	606	910	606	910	606	910	598	
	SAS (old rails)	-	Generic	Static <sup>h</sup>	<b>✓</b>	1	<b>✓</b>	X	X	682	885	682	885	682	885	598	
	NAS Gen3	•	Generic	Siding	√l	√ <sup>i</sup>	√ <sup>i</sup>	X	X	652	854	652	854	652	854	810	•

#### Notes:

- <sup>a</sup> Minor conversion required
- <sup>b</sup> With outer CMA brackets removed
- <sup>c</sup> Mounting screws not included in the kit
- <sup>d</sup> Mounting screw head diameter must be 10 mm or less
- e Requires the 1U Threaded Rack Adapter Brackets Kit (Dell PN 8Y19G), which shifts the system forward in the rack by 17.3 mm
- f Requires the 2U Threaded Rack Adapter Brackets Kit (Dell PN PKCR1), which shifts the system forward in the rack by 17.3 mm
- <sup>g</sup> Requires adapter kit (included)
- $^{\rm h}\,$  System fully serviceable while in the rack
- <sup>i</sup> Requires additional rail guide (included in kit) for full serviceability
- <sup>j</sup> With middle brackets removed
- <sup>k</sup> With rear brackets removed (applies to 2-post or cantilever mount only)

						Dell-branded APC Racks (AF3100X717/AF3104X717)	Dell xx20/xx20D/xx20S	Dell xx20W	Dell xx10	HP 10XXX	HP/Compaq 9XXX	IBM S2	APC Netshelter SX (600mm Wide x 1070mm Deep)	EMC Clariion	Liebert Foundation	Chatsworth Teraframe	Wrightline Vantage S2
	13	Product	Rail Identifier	Mounting Interface	Rail Type	Dell (AR3	Dell						, (600m)			Cha	WE
		R320/R420 R620 (8-HDD)	A7	ReadyRails II	Sliding	√2	~	<b>~</b>	<b>\</b>	>	1	1	12	X	~	<b>V</b>	<b>~</b>
		R630 (8-HDD)	<b>A</b> 8	ReadyRails	Static	~	1	~	1	1	~	1	1	~	~	<b>~</b>	~
		R620 (10-HDD)	A7	ReadyRails II	Sliding	✓3,4	√2	<b>Y</b>	√9	<b>&gt;</b>	<b>√</b> ¹	1	√3,4	X	~	<b>~</b>	<b>✓</b>
		R630 (10/24-HDD)	A8	ReadyRails	Static	~	1	<b>V</b>	~	<b>V</b>	~	1	~	1	<b>✓</b>	<b>✓</b>	<b>~</b>
		R520 R720/R720xd	<b>B</b> 6	ReadyRails II	Siding	√2	<b>~</b>	1	1	1	1	1	12	X	*	<b>~</b>	<b>✓</b>
		R730/R730xd	B4	ReadyRails	Static	~	1	<b>V</b>	1	1	~	1	1	~	~	~	1
SERVERS	PowerEdge	R820	<b>B</b> 6	ReadyRails II	Sliding	√3,4	12	1	<b>V</b>	<b>V</b>	1	1	√3,4	X	1	<b>V</b>	1
SE.	Powe	NO20	B4	ReadyRails	Static	~	<b>V</b>	<b>&gt;</b>	>	>	<b>~</b>	1	1	~	~	<b>&gt;</b>	<b>✓</b>
		R920	<b>B</b> 8	ReadyRails	Sliding	✓3,5,12	√2	<b>~</b>	<b>\</b>	>	<b>~</b>	1	√3,5	X	~	<b>&gt;</b>	<b>✓</b>
		T630	C4	ReadyRails	Sliding	√2	1	~	<b>~</b>	<b>~</b>	<b>√</b> 1	1	√2	X	1	<b>~</b>	<b>✓</b>
		T320/T420/T620	C2	ReadyRails II	Sliding	√2	1	<b>&gt;</b>	<b>*</b>	>	1	1	√2	X	*	<b>~</b>	<b>✓</b>
		VRTX	СЗ	ReadyRails II	Sliding	√2	1	<b>*</b>	<b>V</b>	<b>V</b>	1	1	12	X	1	<b>V</b>	1
		R210/R210 II	A4	ReadyRails	Static	~	~	<b>✓</b>	1	<b>✓</b>	<b>✓</b>	1	1	1	~	<b>✓</b>	<b>✓</b>
			A6	ReadyRails	Static	<b>✓</b>	~	<b>V</b>	<b>✓</b>	<b>✓</b>	<b>✓</b>	✓	<b>✓</b>	1	~	✓	12

 CII L	interprise systems	vall uzing	and rack compa	actionity waters												- 0
	R310/R410/R415	<b>A</b> 3	ReadyRails	Siding	√2	<b>✓</b>	>	<b>*</b>	<b>✓</b>	√1	<b>\</b>	√2	X	>	<b>✓</b>	✓
	K310/K410/K413	A4	ReadyRails	Static	1	×	~	1	1	~	1	~	1	~	~	~
	R510/R515	<b>B</b> 3	ReadyRails	Sliding	12	<b>V</b>	1	1	1	V1	1	12	X	~	~	~
	K310/K315	B4	ReadyRails	Static	1	1	<b>✓</b>	1	<b>√</b>	<b>~</b>	1	1	<b>✓</b>	<b>V</b>	<b>✓</b>	<b>✓</b>
	R610	A1	ReadyRails	Sliding	√3	12	<b>V</b>	1	<b>✓</b>	1	<b>✓</b>	√3	X	1	<b>✓</b>	✓
	KO10	A2	ReadyRails	Static	1	1	~	1	1	~	1	~	1	1	<b>✓</b>	1
	R710	B1	ReadyRails	Sliding	12	<b>V</b>	<b>V</b>	1	~	V1	1	12	X	1	~	1
	R/10	A2	ReadyRails	Static	1	1	<b>~</b>	1	<b>~</b>	~	1	×	1	1	1	1
	R715/R810	<b>B</b> 2	De adu Della	Cidian	√3	√2	1	1	1	1	1	√3	X	1	1	1
	R815/R910	DZ.	ReadyRails	Sliding	ž.	*	•	*	*		•	•	^	*	*	•
	T610/T710	C1	ReadyRails	Sliding	12	<b>V</b>	<b>*</b>	1	1	<b>√</b> 1	<b>~</b>	12	X	1	~	~
	M1000e		RapidRails	Static	√4,5	1	~	1	1	~	1	<b>√</b> 4,5	X	1	~	1
		-	VersaRails	Static	√4,5	1	<b>✓</b>	1	1	1	1	<b>√</b> 4,5	X	1	~	<b>✓</b>
	C1100	-	Tool-less	Sliding	1	<b>✓</b>	<b>~</b>	1	1	~	1	1	X	<b>✓</b>	~	✓
	C2100	2	Generic	Siding	1	~	· ✓	<b>V</b>	V	<b>V</b>	1	~	X	1	<b>V</b>	~
o e	C410x		Versa-type	Siding	√8	√8	√8	√8	V	~	√8	√8	X	X	X	<b>✓</b>
PowerEdge	C5xxx		Tool-less	Static	1	<b>*</b>	1	1	1	1	1	~	X	1	V	<b>V</b>
Pov	C610x/C6145		Tool-less	Static	<b>√</b> 4	1	1	1	1	~	1	<b>V</b> 4	x	1	~	/
	<b>C</b> 6220	-	1001-1ess	Static		V	V	•	•	·	V	V -		•	*	×
	C8000	50 50	Tool-less	Static	✓4,6	√4, 11	<b>√</b> 11	>	~	~	~	√4,6	X	>	~	1
																100

	Dell I	Enterprise Systems	rall azing	and Rack Compa	allibility Matrix					_							
		1081AD/2161AD 1082DS/2162DS 4322DS	A5	ReadyRails	Static	1	¥	<b>*</b>	<b>*</b>	<b>✓</b>	<b>✓</b>	1	<b>√</b>	1	<b>√</b>	<b>*</b>	<b>~</b>
SWITCHES	KVM	180AS/2160AS 2161DS/2161DS-2 4161DS	-	Generic	Static	<b>✓</b>	<b>✓</b>	<b>✓</b>	<b>✓</b>	<b>✓</b>	<b>~</b>	<b>✓</b>	<b>✓</b>	x	✓	<b>~</b>	<b>~</b>
S		2321 <b>DS</b>	-	Generic	Static	~	~	~	1	~	~	1	1	~	1	~	~
	Networking	PC8132/PC8132F PC8164/PC8164F	A5	ReadyRails	Static	1	~	<b>~</b>	~	~	~	<b>~</b>	~	<b>~</b>	1	<b>*</b>	~
	Netwo	\$4820T/\$6000	<b>A</b> 5	ReadyRails	Static	1	1	1	1	V	<b>V</b>	1	1	1	1	<b>✓</b>	<b>V</b>
		<b>\$</b> 5000	-	Generic	Static	<b>✓</b>	1	<b>V</b>	1	1	<b>✓</b>	<b>✓</b>	1	X	1	<b>✓</b>	<b>V</b>
	WORKSTATIONS	T7600/T7610	C2	ReadyRails II	Sliding	√2	√11	<b>√</b> 11	>	~	1	1	√2	X	~	>	1
	WORKS	R5500/R7610	<b>B</b> 2	ReadyRails	Siding	√3	√2	>	>	>	7	>	√3	x	<b>~</b>	>	~
		FPM185 (without KVM)	-	ReadyRails II	Siding	~	~	<b>~</b>	~	✓	~	✓	~	~	x	<b>✓</b>	~
	<b>E</b>	FPM185 (with KVM)	<b>4</b> (	ReadyRails II	Sliding	~	~	~	1	<b>V</b>	~	1	~	X	x	~	1
		47ED		RapidRails	Sliding	1	1	~	1	1	<b>V</b>	~	1	X	1	~	~
		17FP	-	VersaRails	Sliding	~	~	~	<b>~</b>	1	~	1	1	X	1	✓	1

Dell Bitter prise Systems Rain Sizing and Rack Compatibility Matrix																
5	Dell Rack Mount UPS Family	<b>B</b> 5	ReadyRails	Static	<b>✓</b>	<b>&gt;</b>	<b>~</b>	<b>&gt;</b>	>	>	<b>√</b>	<b>~</b>	>	>	>	<b>✓</b>
	1U Fixed Equipment Shelf	<b>A</b> 4	ReadyRails	Static	<b>✓</b>	<b>&gt;</b>	<b>✓</b>	<b>~</b>	>	>	✓	<b>✓</b>	>	>	>	<b>✓</b>
	NX3300/NX400	<b>A</b> 7	ReadyRails II	Siding	√2	✓	✓	✓	✓	√1	✓	√2	X	✓	✓	✓
		<b>A</b> 8	ReadyRails	Static	<b>✓</b>	<b>✓</b>	<b>✓</b>	<b>✓</b>	<b>✓</b>	<b>✓</b>	<b>✓</b>	<b>✓</b>	✓	<b>✓</b>	<b>✓</b>	✓
	NX3200	<b>B</b> 6	ReadyRails II	Siding	√2	<b>✓</b>	<b>✓</b>	<b>✓</b>	<b>✓</b>	√1	<b>✓</b>	√2	X	<b>✓</b>	<b>*</b>	✓
		B4	ReadyRails	Static	<b>✓</b>	✓	<b>✓</b>	<b>✓</b>	<b>✓</b>	<b>✓</b>	✓	<b>✓</b>	✓	<b>✓</b>	<b>&gt;</b>	✓
werVault	NX3500 Controller	<b>A</b> 3	ReadyRails	Silding	√2	<b>✓</b>	<b>✓</b>	<b>✓</b>	<b>✓</b>	√1	<b>✓</b>	√2	х	<b>✓</b>	<b>✓</b>	<b>✓</b>
		<b>A4</b>	ReadyRails	Static	<b>✓</b>	✓	<b>✓</b>	✓	✓	✓	✓	✓	<b>✓</b>	✓	<b>✓</b>	✓
	NX3500 UPS	A4	ReadyRails	Static	<b>✓</b>	<b>√</b>	<b>✓</b>	<b>~</b>	<b>&gt;</b>	<b>~</b>	✓	<b>√</b>	<b>&gt;</b>	<b>&gt;</b>	>	✓
	DX6000G	<b>A</b> 4	ReadyRails	Static	✓	>	<b>✓</b>	<b>&gt;</b>	>	>	✓	<b>✓</b>	>	>	>	✓
P		<b>A</b> 6	ReadyRails	Static	✓	>	<b>✓</b>	<b>~</b>	>	>	✓	✓	>	>	>	✓
	NX300/DX6004S	А3	ReadyRails	Siding	√2	<b>~</b>	<b>✓</b>	<b>~</b>	<b>&gt;</b>	7	✓	√2	X	>	>	✓
		A4	ReadyRails	Static	✓	<b>&gt;</b>	<b>✓</b>	<b>~</b>	>	>	✓	<b>✓</b>	>	>	>	✓
	NX3000/DX6000	B1	ReadyRails	Siding	√2	<b>√</b>	<b>✓</b>	<b>~</b>	<b>&gt;</b>	√1	✓	√2	X	<b>&gt;</b>	>	✓
		A2	ReadyRails	Static	<b>✓</b>	✓	<b>✓</b>	✓	✓	✓	✓	✓	✓	✓	✓	✓
	NX3100/DL2200	<b>B</b> 3	ReadyRails	Sliding	√2	✓	✓	✓	✓	√1	✓	√2	X	✓	<b>&gt;</b>	✓
	DX60125/ DR4000	B4	ReadyRails	Static	<b>✓</b>	✓	<b>✓</b>	<b>✓</b>	✓	✓	✓	<b>✓</b>	✓	✓	<b>✓</b>	✓
	Power/Vault	Dell Rack Mount UPS Family  1U Fixed Equipment Shelf  NX3300/NX400  NX3200  NX3500 Controller  NX3500 UPS  DX6000G  NX300/DX60004S  NX3000/DX60000  NX3100/DL2200	Dell Rack Mount UPS Family  1U Fixed Equipment Shelf  NX3300/NX400  A8  B6  NX3200  B4  NX3500 Controller  A4  NX3500 UPS  A4  NX3500 UPS  A4  NX300/DX60004  A6  NX300/DX60004  A1  NX300/DX60000  A2  NX3100/DL2200  B3	Dell Rack Mount   B5	Dell Rack Mount   UPS Family	Dell Rack Mount   B5	Dell Rack Mount   UPS Family	Dell Rack Mount   UPS Family	Dell Rack Mount   Dell Rack	Dell Rack Mount   Dell ReadyRails   Static   Static   Static   Static   Dell ReadyRails   Dell Ready	Dell Rack Mount   UPS Family	Dell Rack Mount   UPS Family	Dell Rack Mount   UPS Family   B5   ReadyRails   Static   V   V   V   V   V   V   V   V   V	Deli Rack Mount   UPS Family	Dell Rack Mount   UPS Family	Dell Rack Mount   UPS Family   10   FeadyRails   Static   V   V   V   V   V   V   V   V   V

I	Dell Enterprise Systems Rail Sizing and Rack Compatibility Matrix																
		MD3060e/MD3660		Versa-style	Static	<b>√</b> 4,6	√4	<b>✓</b>	<b>√</b> 10	<b>√</b> 10	X	<b>√</b> 10	<b>√</b> 4,6	X	<b>✓</b>	<b>√</b> 10	X
		MD12xx/32xx/36x x	<b>B</b> 9	ReadyRails II	Static	<b>✓</b>	<b>√</b>	<b>✓</b>	<b>✓</b>	✓	<b>√</b>	>	✓	<b>✓</b>	<b>~</b>	<b>✓</b>	<b>✓</b>
		NX36xx	•	RapidRails	Static	✓	<b>~</b>	<b>✓</b>	<b>~</b>	✓	X	>	✓	X	X	>	✓
			•	Versa <b>R</b> ails	Static	✓	<b>~</b>	<b>~</b>	<b>~</b>	✓	<b>~</b>	>	✓	X	>	>	✓
		MD1120	•	RapidRails	Static	✓	<b>&gt;</b>	<b>~</b>	<b>✓</b>	✓	X	>	✓	X	X	<b>&gt;</b>	✓
			•	Versa <b>R</b> ails	Static	✓	<b>&gt;</b>	<b>~</b>	<b>✓</b>	✓	<b>&gt;</b>	>	✓	X	<b>✓</b>	<b>&gt;</b>	✓
		MID1 000/ MID3 000	-	RapidRails	Static	✓	>	<b>✓</b>	✓	✓	<b>&gt;</b>	<b>&gt;</b>	✓	X	✓	<b>✓</b>	✓
			-	VersaRails	Static	✓	<b>&gt;</b>	<b>✓</b>	✓	✓	<b>&gt;</b>	<b>~</b>	✓	X	✓	<b>✓</b>	✓
			B7	ReadyRails	Static	✓	<b>✓</b>	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
		PV114T/PV114X	-	RapidRails	Sliding	√2	<b>✓</b>	<b>✓</b>	✓	✓	√1	<b>✓</b>	√2	X	✓	<b>✓</b>	✓
			-	Versa <b>R</b> ails	Siding	√²	<b>√</b>	✓	✓	✓	√1	<b>✓</b>	√2	X	✓	<b>✓</b>	✓
		PV124T	-	RapidRails	Static	✓	<b>✓</b>	✓	✓	✓	<b>✓</b>	<b>✓</b>	✓	X	✓	<b>✓</b>	✓
		1 41641	-	Versa <b>R</b> ails	Static	✓	<b>✓</b>	✓	✓	✓	<b>✓</b>	<b>✓</b>	✓	X	✓	✓	✓
		FS7500 Controller	A1	ReadyRails	Sliding	√3	√2	✓	✓	✓	√1	✓	<b>√</b> 3	X	✓	✓	✓
		FS/500 Controller	A2	ReadyRails	Static	<b>✓</b>	✓	✓	✓	✓	✓	✓	✓	✓	<b>✓</b>	✓	✓
	EqualLogic	F\$7500 UPS	A4	ReadyRails	Static	<b>~</b>	<b>√</b>	<b>√</b>	<b>✓</b>	<b>✓</b>	<b>√</b>	<b>✓</b>	<b>✓</b>	<b>√</b>	<b>✓</b>	<b>✓</b>	✓
	Equa	FS76xx/PS41xx	<b>B</b> 9	ReadyRails II	Static	<b>✓</b>	✓	✓	<b>✓</b>	✓	✓	✓	✓	✓	<b>✓</b>	✓	✓
		PS61xx	•	RapidRails	Static	✓	✓	✓	✓	✓	X	<b>√</b>	✓	X	X	✓	✓
			-	VersaRails	Static	✓	<b>✓</b>	✓	✓	✓	<b>✓</b>	✓	✓	X	✓	✓	✓

 Den Litterprise Systems van den den Sombattom y wat na																
	PS6500/6510	-	ReadyRails	Siding	<b>√</b> <sup>7</sup>	√²	✓	✓	✓	X	✓	<b>√</b> <sup>7</sup>	X	<b>✓</b>	<b>✓</b>	✓
	P\$4000/6000 6010		Generic	Static	>	<b>√</b>	<b>*</b>	>	<b>*</b>	<b>*</b>	>	<b>*</b>	x	<b>*</b>	<b>*</b>	<b>✓</b>
	SC8000	<b>B</b> 6	ReadyRails II	Siding	<b>√</b> <sup>2</sup>	✓	<b>√</b>	>	<b>√</b>	√1	>	√2	X	<b>✓</b>	<b>&gt;</b>	✓
		B4	ReadyRails	Static	<b>~</b>	✓	✓	<b>&gt;</b>	✓	✓	<b>~</b>	✓	✓	<b>✓</b>	✓	✓
	SC2xx/FS86xx	<b>B</b> 9	ReadyRails II	Static	>	<b>✓</b>	<b>~</b>	>	<b>&gt;</b>	<b>✓</b>	>	<b>&gt;</b>	✓	<b>&gt;</b>	<b>&gt;</b>	✓
벋		•	RapidRails	Static	>	<b>&gt;</b>	>	>	>	X	>	>	X	X	>	<b>✓</b>
npelle		•	VersaRails	Static	>	>	>	>	>	<b>✓</b>	>	>	X	>	>	✓
Dell Compellent	Series 40	•	Generic	Sliding	>	<b>✓</b>	<b>~</b>	>	<b>&gt;</b>	<b>✓</b>	>	<b>&gt;</b>	X	<b>&gt;</b>	>	✓
ă	Fibre Channel	-	Generic	Static	<b>&gt;</b>	<b>✓</b>	<b>&gt;</b>	>	<b>&gt;</b>	<b>✓</b>	>	<b>&gt;</b>	X	>	>	<b>✓</b>
	SAS (new rails)	-	Generic	Static	>	<b>√</b>	<b>✓</b>	>	<b>√</b>	<b>√</b>	>	<b>✓</b>	X	<b>*</b>	<b>&gt;</b>	<b>√</b>
	SAS (old rails)		Generic	Static	<b>&gt;</b>	<b>√</b>	<b>√</b>	<b>&gt;</b>	<b>√</b>	<b>√</b>	>	<b>√</b>	X	<b>✓</b>	<b>✓</b>	✓
	NAS Gen3	-	Generic	Siding	<b>√</b> 6	<	<b>✓</b>	<b>✓</b>	<	<	<b>✓</b>	<b>√</b> 6	X	<	<	✓

#### Notes:

- A rear door extension kit is required to accommodate the CMA.
- $^{2}\,$  CMA may impede access to forward bank of rear-mount PDUs.
- <sup>3</sup> CWA and outer CWA brackets must be removed in order to access the forward bank of rear-mount PDUs.
- $^4\,$  Rear-mount PDUs may impede extraction of some rear system modules.
- <sup>5</sup> The strain relief bar interferes with the forward bank of rear-mount PDUs.
- $^{\rm 6}\,$  Rails/ system block the forward bank of rear-mount PDUs.
- Rails/ system block both the forward and rearward banks of rear-mount PDUs.
- <sup>8</sup> The rear mounting flanges of the rack must be moved rearward.
- $^{\rm 9}\,$  The CMA tray interferes with rear door lock rod in top U and bottom U.
- $^{\rm 10}$  Space for external cable routing is limited.
- 11 May need to adjust the rack's mounting posts back to allow the front door to close.
- 12 CMA blocks both the forward and rearward banks of rear-mount PDUs.